

AIR TO WATER

Comfort series

SERVICE MANUAL

OUTDOOR



WOYA100KLT

FUJITSU GENERAL LIMITED

Notices:

- Product specifications and design are subject to change without notice for future improvement.
- For further details, please check with our authorized dealer.

CONTENTS

1. GENERAL INFORMATION UNIT

2. TECHNICAL DATA AND PARTS LIST

3. TROUBLESHOOTING

4. FIELD WORKING



1. GENERAL INFORMATION UNIT

CONTENTS

1. GENERAL INFORMATION UNIT

1. Specifications.....	01-1
1-1. Outdoor unit.....	01-1
2. Dimensions.....	01-6
2-1. Outdoor unit.....	01-6

1. Specifications

1-1. Outdoor unit

■ Nominal capacity and nominal input

Model name		Hydraulic indoor unit			WSYA100ML3
		Outdoor unit			WOYA100KLT
Power supply					1 Ø 230 V ~ 50 Hz
-15°C/+45°C		Heating capacity	Nominal	kW	7.50
		Input power	Nominal	kW	3.75
		COP	Nominal		2.00
-10°C/+55°C		Heating capacity	Nominal	kW	7.10
		Input power	Nominal	kW	4.06
		COP	Nominal		1.75
-10°C/+35°C		Heating capacity	Nominal	kW	8.20
		Input power	Nominal	kW	3.35
		COP	Nominal		2.45
-7°C/+35°C		Heating capacity	Nominal	kW	8.90
		Input power	Nominal	kW	3.36
		COP	Nominal		2.65
-7°C/+55°C		Heating capacity	Nominal	kW	8.00
		Input power	Nominal	kW	4.10
		COP	Nominal		1.95
+2°C/+35°C	COP priority	Heating capacity	Nominal	kW	4.50
		Input power	Nominal	kW	1.14
		COP	Nominal		3.95
	Capacity priority	Heating capacity	Nominal	kW	9.30
		Input power	Nominal	kW	3.08
		COP	Nominal		3.02
+7°C/+35°C		Heating capacity	Minimum	kW	3.56
			Nominal		9.50
			Maximum		15.29
		Input power	Nominal	kW	2.11
		COP	Nominal		4.50
+7°C/+45°C		Heating capacity	Nominal	kW	9.00
		Input power	Nominal	kW	2.475
		COP	Nominal		3.45
+7°C/+55°C		Heating capacity	Nominal	kW	9.00
		Input power	Nominal	kW	3.33
		COP	Nominal		2.70
NOTE: Test conditions are complied with EN14511-2					

NOTE: Test conditions are complied with EN14511-2

Technical specifications

Outdoor unit model name				WOYA100KLT		
Enclosure		Material		Steel sheet		
		Color		Beige Approximate color of Munsell 10YR 7.5/1.0NN		
Dimensions (H × W × D)	Net		mm	998 × 940 × 320		
	Gross			1,176 × 1,027 × 445		
Weight	Net		kg	65		
	Gross			71		
Heat exchanger		Dimensions (H × W × D)		966 × 905 × 36.38		
		Fin pitch		1.45		
		Rows × Stages		2 × 46		
		Pipe type		Copper		
		Fin type		Type (Material)	Corrugate (Aluminum)	
			Surface treatment	Corrosion resistance		
Fan	Airflow rate		Heating	m³/h		
	Type × Q'ty				Propeller fan × 1	
	Discharge direction				Horizontal	
	Motor quantity				1	
	Motor output		W		120	
Compressor	Type				DC 2 rotary × 1	
	Motor output		W		2,180	
Operation range	Heating	Minimum	°CDB		-20	
		Maximum	°CWB		35	
	Sanitary water	Minimum	°CDB		-20	
		Maximum	°CWB		35	
Refrigerant		Type (Global Warming Potential)		R32 (675)		
		Charge	g		1,630	
		Control			Expansion valve (electric type)	
		Number of circuits		1		
Refrigerant oil		Type		RmM68AF		
		Charged volume	l		0.80	
Connection pipe	Connection method	Liquid	mm	Flare connection		
		Gas		Flare connection		
	Size (standard)	Liquid	mm	Ø9.52		
		Gas		Ø15.88		
	Pre-charge length		m	20		
	Max. length			30		
	Min. length			3.0		
	Additional refrigerant charge		g/m		20	
	Max. height difference		m		20	
	Defrost method				Reverse cycle	
Defrost control				Outdoor unit heat exchanger temperature sensor		
Capacity control method				Inverter control		

Product fiche

Model name	Hydraulic indoor unit		WSYA100ML3	
	Outdoor unit		WOYA100KLT	
Temperature application		°C	55	35
Declared load profile			—	—
Seasonal space heating energy efficiency class			A++	A+++
Water heating energy efficiency class			—	—
Rated heat output		kW	8	9
Supplementary heater		kW	3	3
Annual energy consumption		kWh	5,083	3,875
Annual electricity consumption		kWh	—	—
Annual fuel consumption		GJ	Not applicable	
Seasonal space heating energy efficiency		%	130	178
Water heating energy efficiency		%	—	—
Sound power level	Hydraulic unit	dB	40	—
Work only during off-peak hours			Not applicable	
Specific precautions in assembled, installed, or maintained			Refer to the installation and operating manuals.	
Rated heat output	Colder climate	kW	—	—
	Warmer climate	kW	8	8
Annual energy consumption	Colder climate	kWh	—	—
	Warmer climate	kWh	2,632	1,795
Annual electricity consumption	Colder climate	kWh	—	—
	Warmer climate	kWh	—	—
Seasonal space heating energy efficiency	Colder climate	%	—	—
	Warmer climate	%	162	235
Water heating energy efficiency	Colder climate	%	—	—
	Warmer climate	%	—	—
Sound power level	Outdoor unit	dB	62	—
NOTES: <ul style="list-style-type: none"> Product fiche according to Commission Delegated Regulation (EU) 811/2013 Acoustic noise information: <ul style="list-style-type: none"> The maximum sound pressure level is less than 70 dB (A) for both hydraulic unit and outdoor unit. According to IEC 704-1 and ISO 3744. If the air to water heat pump is operated under higher temperature conditions than those listed, the built-in protection circuit may operate to prevent internal circuit damage. Also, during cooling modes, if the unit is used under conditions of lower temperatures than those listed above, the heat exchanger may freeze, leading to water leakage and other damage. Do not use this unit for any purposes other than the Heating and Cooling. 				

Product information

Model name		Hydraulic indoor unit		WSYA100ML3	
		Outdoor unit		WOYA100KLT	
Air-to-water heat pump				Yes	
Water-to-water heat pump				No	
Brine-to-water heat pump				No	
Low-temperature heat pump				No	
Equipped with a supplementary heater				Yes	
Heat pump combination heater				No* ¹	
Temperature application		°C	55	35	
Rated heat output* ²	P _{rated}	kW	8	9	
Seasonal space heating energy efficiency	η _s	%	130	178	
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T _j					
T _j = −7°C	P _{dh}	kW	7.3	7.5	
T _j = +2°C	P _{dh}	kW	4.4	4.6	
T _j = +7°C	P _{dh}	kW	3.6	3.9	
T _j = +12°C	P _{dh}	kW	7.3	7.5	
T _j = bivalent temperature	P _{dh}	kW	7.1	7.3	
T _j = operation limit temperature	P _{dh}	kW	55	35	
T _j = −15°C (if TOL < −20°C)	P _{dh}	kW	—	—	
Bivalent temperature	T _{biv}	°C	-7	-7	
Cycling interval capacity for heating	P _{cych}	kW	Not applicable		
Degradation co-efficient* ³	C _{dh}		0.9	0.9	
Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T _j					
T _j = −7°C	COP _d		2.05	2.98	
T _j = +2°C	COP _d		3.24	4.46	
T _j = +7°C	COP _d		4.47	5.89	
T _j = +12°C	COP _d		5.97	7.14	
T _j = bivalent temperature	COP _d		2.05	2.98	
T _j = operation limit temperature	COP _d		1.72	2.71	
T _j = −15°C (if TOL < −20°C)	COP _d		—	—	
Operation limit temperature	TOL	°C	-10	-10	
Cycling interval efficiency	COP _{cyc}		Not applicable		
Heating water operating limit temperature	WTOL	°C	55	55	
Power consumption in modes other than active mode					
Off mode	P _{OFF}	kW	0.004	0.004	
Thermostat-off mode	P _{TO}	kW	0.021	0.020	
Standby mode	P _{SB}	kW	0.008	0.008	
Crankcase heater mode	P _{CK}	kW	0.000	0.000	
Supplementary heater					
Rated heat output* ²	P _{SUP}	kW	1.1	1.2	
Type of energy input	Electric				
Other items					
Capacity control			Variable		
Sound power level	Indoor unit	L _{WA}	40	—	
	Outdoor unit	L _{WA}	62	—	
Annual energy consumption		Q _{HE}	5,083	3,875	
Emissions of nitrogen oxides		NO _x	mg/kWh		
Rated airflow rate	Outdoor unit		m ³ /h	4,130	4,130
Declared load profile					
Daily electricity consumption		Q _{elec}	kWh	—	
Annual energy consumption		AEC	kWh	—	
Water heating energy efficiency		η _{wh}	%	—	
Daily fuel consumption		Q _{fuel}	kWh	Not applicable	
Contact details			FUJITSU GENERAL (EURO) GmbH Fritz-Vomfelde-Straße 26-32, 40547 Düsseldorf, Germany		
NOTES:					
<ul style="list-style-type: none">• Product information according to Commission Delegated Regulation (EU) 811/2013• Product information is based on the average climate condition.• *1: When using an optional component, this function is available.• *2: For heat pump space heaters and heat pump combination heaters, the rated heat output P_{rated} is equal to the design load for heating P_{designh}, and the rated heat output of a supplementary heater P_{sup} is equal to the supplementary capacity for heating sup (T_j).• *3: If C_{dh} is not determined by measurement then the default degradation coefficient is C_{dh} = 0.9.					

● Energy efficiency value

Application: 35°C			
Model name	Hydraulic indoor unit		WSYA100ML3
	Outdoor unit		WOYA100KLT
Seasonal energy efficiency of heat pump for space heating		%	178
Type of temperature control			
Outdoor sensor (included in the package)			II —
Modulating room thermostat (outdoor sensor included in the package)			— IV
Bonus		%	2 4
Seasonal space heating energy efficiency of package in average climate conditions		%	180 182
Energy class of the packages			A+++ A+++
Seasonal space heating energy efficiency of package in warmer climate conditions		%	237 239
Seasonal space heating energy efficiency of package in colder climate conditions		%	— —

Application: 55°C			
Model name	Hydraulic indoor unit		WSYA100ML3
	Outdoor unit		WOYA100KLT
Seasonal energy efficiency of heat pump for space heating		%	130
Type of temperature control			
Outdoor sensor (included in the package)			II —
Modulating room thermostat (outdoor sensor included in the package)			— IV
Bonus		%	2 4
Seasonal space heating energy efficiency of package in average climate conditions		%	132 134
Energy class of the packages			A++ A++
Seasonal space heating energy efficiency of package in warmer climate conditions		%	164 166
Seasonal space heating energy efficiency of package in colder climate conditions		%	— —

● Class of temperature controller

Controller class		II	VI
Contribution to energy efficiency	%	2	4
NOTE: Controller class VI: UTW-C55XA, UTW-C58XD, UTW-C74TXF, UTW-C74HXF, UTW-C78XD			

■ Electrical specifications

Outdoor unit model name			WOYA100KLT
Available voltage range			198—264 V
Power supply	Voltage	V	1 Ø 230
	Frequency	Hz	50
Maximum operating current*1	Heating	A	19.0
Wiring spec.*2	Main fuse (circuit breaker) current	A	30
	Power cable	mm ²	4.0 or more
	Transmission cable	Size	1.5 or more
		Max. length	31
Wiring connections quantity*3	For power supply		3
	For connection with indoor		4

NOTES:


- *1: Maximum operating current is the total current of the indoor unit and the outdoor unit.
- *2: Selected based on Japan Electrotechnical Standard and Codes Committee E0005.
- *3: Included earth wiring.

2. Dimensions


2-1. Outdoor unit

■ Model: WOYA100KLT

Unit: mm




Top view




Front view

Side view



Rear view



Bottom view

Pipe & Cable port



2. TECHNICAL DATA AND PARTS LIST

CONTENTS


2. TECHNICAL DATA AND PARTS LIST

1. Outdoor unit parts list.....	02-1
1-1. Model: WOYA100KLT	02-1

1. Outdoor unit parts list


1-1. Model: WOYA100KLT

■ Exterior parts and chassis



Item no.	Part no.	Part name	Service part
1	9383880001	Top panel assy	◆
2	9381013005	Protective net	◆
3	9375361013	Net rubber	◆
4	9900984038	Thermistor (Heat exchanger)	◆
5	9900727154	Thermistor assy	◆
6	9383607004	Thermo holder	◆
7	9383874017	Right panel sub assy	◆
8	9383879005	Rear pipe cover	◆
9	9709684115	Inverter PCB	◆
10	9900203061	Terminal	◆
11	9711431370	Main PCB	◆
12	313166024302	Drain cap	◆
13	9303029015	Drain assy	◆
14	9350255009	Base assy	◆
15	9383876011	Service panel sub assy	◆
16	9383878008	Front pipe cover	◆
17	9351355005	Emblem rear	◆
18	9383863011	Front panel assy	◆
19	9383604003	Blow grille	◆
20	9383689000	Blow grille insulation	◆
21	9383882012	Left panel sub assy	◆
22	9383336003	Propeller fan	◆
23	9603733018	Brushless motor	◆
24	9383862021	Motor bracket assy	◆
25	9374420636	Condenser sub assy	◆
—	9711332004	Wire with terminal (Power wire L)	◆
—	9711332011	Wire with terminal (Power wire N)	◆
—	9711205001	Wire with connector (P350 on Main PCB—P351 on Inverter PCB)	◆
—	9711203007	Wire with connector (P660 on Main PCB—P662 on Inverter PCB)	◆
—	9711204004	Wire with connector (P661 on Main PCB—P663 on Inverter PCB)	◆
—	9711214003	Wire with connector (Pressure switch)	◆
—	9711213006	Wire with connector (P770 on Inverter PCB [for Pressure switch])	◆
—	9711212009	Wire with connector (P650 on Inverter PCB—Fan motor)	◆
—	9711198006	Wire with terminal (P400 [U], P401 [V], P402 [W] on Inverter PCB— Compressor)	◆
<i>a</i>	—	Separate wall assy	—
<i>b</i>	—	Control box unit	—

Compressor



Item no.	Part no.	Part name	Service part
50	9383858017	Sound insulation unit	◆
51	9900565091	Thermistor (Outdoor temp.)	◆
52	9900186029	Pressure switch	◆
53	9374425709	4-way valve assy	◆
54	9970110153	Solenoid	◆
55	9970178122	Pressure sensor	◆
56	9384848024	Accumulator assy	◆
57	9970095030	Expansion valve coil	◆
58	9370947366	Expansion valve assy	◆
59	9901065026	Thermistor (EEV)	◆
60	9379079013	3-way valve assy	◆
61	9377958037	3-way valve assy	◆
62	9900985028	Thermistor (Compressor)	◆
63	9810791009	Compressor	◆
64	9379179089	Rubber washer F	◆
65	9377973016	Special nut	◆
<i>a</i>	—	Thermistor spring	—
<i>b</i>	—	Joint pipe D	—
<i>c</i>	—	Thermistor spring	—
<i>d</i>	—	Wiring fixation unit	—



3. TROUBLESHOOTING

1 ERROR DISPLAY

1-1 HYDRAULIC UNIT DISPLAY





figure 1 - Location of DIP switches and diodes on the hydraulic unit interface card

LED display		Error contents	Troubleshooting
LED 2 (green)	LED 1 (red)		
◆ 1	◆ 1	Serial communication error	1, 2
◆ 2	◆ 3	Combination error	3
◆ 3	◆ 2	UART communication error	4
◆ 4	◆ 2	Hydraulic unit heat exchanger thermistor error	5
◆ 6	◆ 2	Outdoor unit main PCB error	6
◆ 6	◆ 3	Inverter PCB error	7
◆ 6	◆ 5	IPM error	8
◆ 7	◆ 1	Discharge thermistor error	9
◆ 7	◆ 2	Compressor thermistor error	10
◆ 7	◆ 3	Outdoor unit heat exchanger thermistor error	11
◆ 7	◆ 4	Outdoor thermistor error	12
◆ 7	◆ 7	Heatsink thermistor error	13
◆ 7	◆ 8	Electric expansion valve thermistor error	14
◆ 8	◆ 4	Current sensor error	15
◆ 8	◆ 6	Pressure sensor error	16
◆ 9	◆ 4	Trip detection	17
◆ 9	◆ 5	Compressor motor control error	18
◆ 9	◆ 7	Outdoor unit fan motor error	19
◆ 10	◆ 1	Discharge temperature error	20
◆ 10	◆ 3	Compressor temperature error	21
◆ 10	◆ 5	Pressure error	22
◆ 10	◆ 12	Heatsink temperature error	23

◆1 ~ ◆12 : 1~ 12 Times Blinking

1-2 OUTDOOR UNIT DISPLAY

You can determine the operating status by the lighting up and blinking of the LED lamp.



Display when an error occurs.

POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE			PEAK CUT		
		(L1)	(L2)	(L3)	(L4)	(L5)	(L6)	
●	Blink (Hi speed)	○	○	○	○	○	○	

Sign "○": Lights off, "●": Lights on

- (1) Check that the "ERROR" LED blinks, then press the "ENTER" button once.
- (2) For details, refer to the following table.

Check that the "ERROR" LED blinks, then press the [Enter] button once.
For details, refer to the following table.

○ : Light OFF ● : Light ON ◆1 ~ ◆12 : 1~ 12 Times Blinking

LED display								Error contents	TROUBLE-SHOOTING
POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE		PEAK CUT				
		(L1)	(L2)	(L3)	(L4)	(L5)	(L6)		
◆(2)	●	◆(1)	◆(1)	○	○	●	●	Serial communication error	2
◆(2)	●	◆(1)	◆(1)	○	●	○	○		
◆(2)	●	◆(2)	◆(3)	○	○	○	●	Combination error	3
◆(2)	●	◆(6)	◆(2)	○	○	○	●	Outdoor unit main PCB error	6
◆(2)	●	◆(6)	◆(3)	○	○	○	●	Inverter PCB error	7
◆(2)	●	◆(6)	◆(5)	○	○	○	●	IPM error	8
◆(2)	●	◆(6)	◆(5)	○	○	●	●		
◆(2)	●	◆(7)	◆(1)	○	○	○	●	Discharge thermistor error	9
◆(2)	●	◆(7)	◆(2)	○	○	○	●	Compressor thermistor error	10
◆(2)	●	◆(7)	◆(3)	○	○	●	○	Outdoor unit heat exchanger thermistor error	11
◆(2)	●	◆(7)	◆(3)	○	○	●	●		
◆(2)	●	◆(7)	◆(4)	○	○	○	●	Outdoor thermistor error	12
◆(2)	●	◆(7)	◆(7)	○	○	○	●	Heatsink thermistor error	13
◆(2)	●	◆(7)	◆(8)	○	○	○	●	Electric expansion valve thermistor error	14
◆(2)	●	◆(8)	◆(4)	○	○	○	●	Current sensor error	15
◆(2)	●	◆(8)	◆(6)	○	●	○	○	Pressure sensor error 1	16-1
◆(2)	●	◆(8)	◆(6)	○	●	●	○	Pressure sensor error 2	16-2
◆(2)	●	◆(9)	◆(4)	○	○	○	●	Trip detection	17
◆(2)	●	◆(9)	◆(5)	○	○	○	●	Compressor motor control error	18
◆(2)	●	◆(9)	◆(7)	○	○	●	●	Outdoor unit fan motor error	19
◆(2)	●	◆(10)	◆(1)	○	○	○	●	Discharge temperature error	20
◆(2)	●	◆(10)	◆(3)	○	○	○	●	Compressor temperature error	21
◆(2)	●	◆(10)	◆(5)	○	○	○	●	Pressure error	22
◆(2)	●	◆(10)	◆(12)	○	○	●	●	Heatsink temperature error	23

2 TROUBLESHOOTING WITH ERROR CODE

Troubleshooting 1
OUTDOOR UNIT Error Method:
Serial communication error
(Serial Reverse Transfer Error)

Indicate or Display:

Hydraulic unit :

Green	Red
◆ 1	◆ 1

◆ n : n times blinking

Outdoor unit : No indication

Detective Actuators:

Outdoor unit Main PCB
 Outdoor unit fan motor

Detective details:

When the hydraulic unit cannot receive the serial signal from Outdoor unit more than 2minutes after power ON, or the hydraulic unit cannot receive the serial signal more than 15seconds during normal operation.

Forecast of Cause:

1. Connection failure 2. External cause 3. Main PCB failure 4. Outdoor unit fan motor failure

Check Point 1-1 : Reset the power and operate

• Does Error indication show again?

NO

YES

Check Point 2 : Check Connection

• Check any loose or removed connection line of Hydraulic unit and Outdoor unit.
 >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**

Check Point 1-2: Check external cause such as noise

• Check the complete insulation of the grounding.
 • Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).

OK

Check Point 3 : Check the voltage of power supply


• Check the voltage of power supply
 >> **Check if AC198V (AC220V -10%) - 264V (AC240V +10%) appears at Outdoor Unit Terminal L - N.**



OK

Check Point 4 : Check Serial Signal (Reverse Transfer Signal)

• Check Serial Signal (Reverse Transfer Signal)
 >> **Check if Indicated value swings between AC90V and AC270V at Outdoor Unit Terminal 1 - 3.**
 >> **If it is abnormal, Check Outdoor unit fan motor (PARTS INFORMATION 4)**
 >> **If Outdoor fan motor is abnormal, replace Outdoor unit fan motor and Main PCB.**
 >> **If Outdoor fan motor is normal, replace Main PCB.**



<div><div>Troubleshooting 3</div><div><u>HYDRAULIC UNIT Error Method:</u></div><div>Combination error</div></div>	<div><div>Indicate or Display:</div><div>Hydraulic unit :</div><table><tr><td>Green</td><td>Red</td></tr><tr><td>◆2</td><td>◆3</td></tr></table><div>◆n: n times blinking</div></div> <div><div>Outdoor unit :</div><table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆2</td><td>◆3</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table><div>○: Light OFF ●: Light ON ◆n: n times blinking</div></div>	Green	Red	◆2	◆3	Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆2	◆3	○	○	○	●
Green	Red																				
◆2	◆3																				
Mode	Error	L1	L2	L3	L4	L5	L6														
◆2	●	◆2	◆3	○	○	○	●														

Detective Actuators: Hydraulic unit	Detective details: 1. The outdoor unit receives the serial signal of applied refrigerant information from hydraulic unit. When the refrigerant is R410a. 2. The combination of hydraulic unit and outdoor unit isn't allowed.
---	--

Forecast of Cause: 1. The combination of hydraulic unit and outdoor unit is incorrect

Check Point 1 : Check the type of hydraulic unit
· Check the type of the connected hydraulic unit and outdoor unit. >> If abnormal condition is found, correct it.




Check Point 2 : Replace Main PCB
► If Check Point 1 do not improve the symptom, replace Main PCB of Outdoor unit.

Troubleshooting 4 <u>HYDRAULIC UNIT Error Method:</u> UART communication error	<u>Indicate or Display:</u> <div style="display: flex; justify-content: space-between;"> <div> Hydraulic unit : <table border="1" style="border-collapse: collapse; text-align: center;"> <tr> <td style="padding: 2px 10px;">Green</td><td style="padding: 2px 10px;">Red</td></tr> <tr> <td style="padding: 2px 10px;">◆3</td><td style="padding: 2px 10px;">◆2</td></tr> </table> <small>◆n : n times blinking</small> </div> <div> Outdoor unit : No indication </div> </div>	Green	Red	◆3	◆2
Green	Red				
◆3	◆2				

<u>Detective Actuators:</u> Hydraulic unit Interface PCB Hydraulic unit Main PCB	<u>Detective details:</u> When the UART connection fails for 25 seconds.
---	--


<u>Forecast of Cause:</u> <div style="display: flex; justify-content: space-around; padding: 5px;"> 1. Connection failure 2. External cause 3. Main PCB failure 4. Interface PCB failure </div>



<div>Troubleshooting 6</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Outdoor unit main PCB error</div>	<div><u>Indicate or Display:</u></div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆6</td><td>◆2</td></tr></table> <div>◆n : n times blinking</div>	Green	Red	◆6	◆2	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆6</td><td>◆2</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table> <div>○ : Light OFF ● : Light ON ◆n : n times blinking</div>	Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆6	◆2	○	○	○	●
Green	Red																					
◆6	◆2																					
Mode	Error	L1	L2	L3	L4	L5	L6															
◆2	●	◆6	◆2	○	○	○	●															

Detective Actuators: Outdoor unit Main PCB	Detective details: Access to EEPROM failed due to some cause after outdoor unit started.
--	--

Forecast of Cause: 1. External cause (Noise, temporary open, voltage drop) 2. Main PCB failure



Inverter PCB error

Green	Red
-------	-----

◆n: n times blinking

○: Light OFF ●: Light ON ◆n: n times blinking

Outdoor unit Inverter PCB

- Error information received from Outdoor unit Inverter PCB

1. External cause.
2. Power supply to Inverter PCB wiring disconnection, open
3. Outdoor unit Inverter PCB failure
4. Outdoor unit Main PCB failure



Troubleshooting 8

OUTDOOR UNIT Error Method:

IPM error

Indicate or Display:

Hydraulic unit :

Green	Red
◆6	◆5

◆n : n times blinking

Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆6	◆5	○	○	○	●

○ : Light OFF ● : Light ON ◆n : n times blinking

<u>Detective Actuators:</u> Outdoor unit Inverter PCB	<u>Detective details:</u> When the signal from FO terminal of IPM is "L"(=0V) while the compressor stops.
---	---

<u>Forecast of Cause:</u> 1. Outdoor unit Inverter PCB failure
--

Check Point 1 : Replace Inverter PCB
► <u>Replace Outdoor unit Inverter PCB.</u>

Troubleshooting 9

OUTDOOR UNIT Error Method:

Discharge Thermistor Error

Indicate or Display:
Hydraulic unit :

Green	Red
♦7	♦1

◆n: n times blinking

Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆7	◆1	○	○	○	●

○: Light OFF ●: Light ON ◆n: n times blinking

Detective Actuators:

Discharge temperature thermistor

Detective details:

- Discharge temperature thermistor short or open detected

Forecast of Cause :

1. Connector connection failure, open
2. Thermistor failure
3. Main PCB failure

Check Point 1 : Check the connector connection and cable open

- ❑ Connector connection state check
- ❑ Cable open check

OK


Check Point 2 : Check the thermistor

- ❑ Thermistor characteristics check
(Disconnect the thermistor from the PCB and check.)
* For the thermistor characteristics, refer to the "Service Parts Information 5".

OK

Check Point 3 : Check voltage of Main PCB (DC5.0V)

❑ Main PCB P15:3-4 voltage value =5V
Remove the thermistor from Main PCB, check the voltage.



► If the voltage does not appear, replace Main PCB, and execute the check operation again.

DC



Troubleshooting 10 OUTDOOR UNIT Error Method: Compressor Thermistor Error	Indicate or Display: Hydraulic unit :		Outdoor unit :							
	Green	Red	Mode	Error	L1	L2	L3	L4	L5	L6
	◆7	◆2	◆2	●	◆7	◆2	○	○	○	●

◆n: n times blinking ○: Light OFF ●: Light ON ◆n: n times blinking

Detective Actuators: Compressor temperature thermistor	Detective details: <ul style="list-style-type: none"> Compressor temperature thermistor short or open detected
--	---

Forecast of Cause :	1. Connector connection failure, open 2. Thermistor failure 3. Main PCB failure
----------------------------	---

Check Point 1 : Check the connector connection and cable open

☐ Connector connection state check
☐ Cable open check

OK

Check Point 2 : Check the thermistor

☐ Thermistor characteristics check
(Disconnect the thermistor from the PCB and check.)
* For the thermistor characteristics, refer to the "Service Parts Information 5".

OK

DC

Check Point 3 : Check voltage of Main PCB (DC5.0V)

☐ Main PCB P10:1-3 voltage value =5V
Remove the thermistor from Main PCB, check the voltage.

THERMISTOR (COMPRESSOR)

BLACK

BLACK

1

2

3

1

2

3

P10

► If the voltage does not appear, replace Main PCB, and execute the check operation again.

03-12

Outdoor unit Heat Exchanger Thermistor Error

◆n: n times blinking

○: Light OFF ●: Light ON ◆n: n times blinking

Troubleshooting 12 <u>OUTDOOR UNIT Error Method:</u> Outdoor Thermistor Error	<u>Indicate or Display:</u>		Outdoor unit :																						
	Hydraulic unit :		<table><tr><th>Mode</th><th>Error</th><th>L1</th><th>L2</th><th>L3</th><th>L4</th><th>L5</th><th>L6</th></tr><tr><td>◆2</td><td>●</td><td>◆7</td><td>◆4</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table>							Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆7	◆4	○	○	○	●
	Mode	Error	L1	L2	L3	L4	L5	L6																	
	◆2	●	◆7	◆4	○	○	○	●																	
<table><tr><th>Green</th><th>Red</th></tr><tr><td>◆7</td><td>◆4</td></tr></table>		Green	Red	◆7	◆4	O : Light OFF ● : Light ON ◆n : n times blinking																			
Green	Red																								
◆7	◆4																								
◆n : n times blinking																									

Detective Actuators: Outdoor temperature thermistor	Detective details: • Outdoor temperature thermistor short or open detected
---	--

Forecast of Cause :	1. Connector connection failure, open 2. Thermistor failure 3. Main PCB failure
----------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 5".



Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> DC </div>
<input type="checkbox"/> Main PCB P5:1-3 voltage value =5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;"> </div> <p>► <u>If the voltage does not appear, replace Main PCB, and execute the check operation again.</u></p>	

<div>Troubleshooting 13</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Heatsink Thermistor Error</div>	<div>Indicate or Display:</div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆7</td><td>◆7</td></tr></table> <div>◆n: n times blinking</div>		Green	Red	◆7	◆7	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆7</td><td>◆7</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table> <div>O: Light OFF ●: Light ON ◆n: n times blinking</div>							Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆7	◆7	○	○	○	●
	Green	Red																											
	◆7	◆7																											
	Mode	Error	L1	L2	L3	L4	L5	L6																					
◆2	●	◆7	◆7	○	○	○	●																						

Detective Actuators: Heatsink temperature thermistor	Detective details: • Heatsink temperature thermistor short or open detected
--	---

Forecast of Cause :	1. Connector connection failure, open 2. Thermistor failure 3. Inverter PCB failure
----------------------------	---


Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the thermistor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 5".



Check Point 3 : Check voltage of Inverter PCB (DC5.0V)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> DC </div>
<input type="checkbox"/> Main PCB P700:1-3 voltage value =5V <u>Remove the thermistor from Inverter PCB, check the voltage.</u>	



► **If the voltage does not appear, replace Inverter PCB, and execute the check operation again.**

Troubleshooting 14
OUTDOOR UNIT Error Method:

Electric expansion valve Thermistor Error

Indicate or Display:

Hydraulic unit :

Green	Red
◆7	◆8

◆n : n times blinking

Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆7	◆8	○	○	○	●

○ : Light OFF ● : Light ON ◆n : n times blinking

Detective Actuators:

Expansion valve temperature thermistor

Detective details:

- Expansion valve temperature thermistor short or open detected

- Forecast of Cause :**
1. Connector connection defective, open
 2. Thermistor failure
 3. Main PCB failure

Check Point 1 : Check the connector connection and cable open

- ☐ Connector connection state check
- ☐ Cable open check




Check Point 2 : Check the thermistor

- ☐ Thermistor characteristics check (Disconnect the thermistor from the PCB and check.)
 * For the thermistor characteristics, refer to the "Service Parts Information 5".



Check Point 3 : Check voltage of Main PCB (DC5.0V)

- ☐ Main PCB (PA1:4-6) voltage value = 5V
Remove the thermistor from Main PCB, check the voltage.



Expansion valve temperature thermistor (PA1:4-6)

- **If the voltage do not appear, replace Main PCB, and execute the check operation again.**

Troubleshooting 15

OUTDOOR UNIT Error Method:

Current sensor error

Indicate or Display:

Hydraulic unit :

Green	Red
◆8	◆4

◆n : n times blinking


Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆8	◆4	○	○	○	●

○ : Light OFF ● : Light ON ◆n : n times blinking

Detective Actuators: Outdoor unit Inverter PCB	Detective details: When Input Current Sensor has detected 1A or less, while Inverter Compressor is operating at higher than 50rps, after 1minute upon starting the Compressor. (Except during the defrost operation)
--	---

Forecast of Cause : 1. Defective connection of electric components 2. External cause 3. Inverter PCB failure
--



<div>Troubleshooting 16-1</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Pressure sensor error</div>	<div><u>Indicate or Display:</u></div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆8</td><td>◆6</td></tr></table> <div>◆n : n times blinking</div>	Green	Red	◆8	◆6	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆8</td><td>◆6</td><td>○</td><td>●</td><td>○</td><td>○</td></tr></table> <div>○ : Light OFF ● : Light ON ◆n : n times blinking</div>	Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆8	◆6	○	●	○	○
Green	Red																					
◆8	◆6																					
Mode	Error	L1	L2	L3	L4	L5	L6															
◆2	●	◆8	◆6	○	●	○	○															

Detective Actuators: High pressure switch	Detective details: When the power was turned on, "high pressure switch : open" was detected.
---	--

Forecast of Cause : <ol style="list-style-type: none"> 1. High pressure switch connector disconnection, open 2. High pressure switch characteristics failure 3. Inverter PCB failure
--


Check Point 1 : Check the high pressure switch connection state
<ul style="list-style-type: none"> • Connector and wiring connection state check • Cable open check



Check Point 2 : Check the high pressure switch characteristics
<ul style="list-style-type: none"> • Switch characteristics check * For the characteristics of high pressure switch, refer to below.



Check Point 3 : Replace Inverter PCB
<ul style="list-style-type: none"> • Change Inverter PCB, and execute the check operation again.

<ul style="list-style-type: none"> • Type of contact <div data-bbox="180 1653 424 1776" data-kind="parent" data-rs="2">  </div> <ul style="list-style-type: none"> • Characteristics of pressure switch (P770) <table border="1" data-bbox="172 1881 782 2078"> <tr> <td></td><td>Pressure switch</td></tr> <tr> <td>Contact : Short ⇒ Open</td><td>4.2±0.1MPa</td></tr> <tr> <td>Contact : Open ⇒ Short</td><td>3.2±0.15MPa</td></tr> </table>			Pressure switch	Contact : Short ⇒ Open	4.2±0.1MPa	Contact : Open ⇒ Short	3.2±0.15MPa
	Pressure switch						
Contact : Short ⇒ Open	4.2±0.1MPa						
Contact : Open ⇒ Short	3.2±0.15MPa						

<div>Troubleshooting 16-2</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Pressure sensor error</div>	<div>Indicate or Display:</div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆8</td><td>◆6</td></tr></table> <div>◆n: n times blinking</div>	Green	Red	◆8	◆6	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆8</td><td>◆6</td><td>○</td><td>●</td><td>●</td><td>○</td></tr></table> <div>○: Light OFF ●: Light ON ◆n: n times blinking</div>	Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆8	◆6	○	●	●	○
Green	Red																					
◆8	◆6																					
Mode	Error	L1	L2	L3	L4	L5	L6															
◆2	●	◆8	◆6	○	●	●	○															

Detective Actuators: Outdoor unit Main PCB Pressure sensor	Detective details: 30 seconds or more after power-on, when pressure sensor detection value detects the condition below continuously for 30 seconds or more. ・ $P_s \leq 0$ or $P_s \geq 5$ [MPa]
---	---

Forecast of Cause : 1. Connector connection failure 2. Pressure sensor failure 3. Main PCB failure
--

Check Point 1 : Check connection of the Pressure sensor <ul style="list-style-type: none"> • Check if the terminal connection is loose. • Check if connector is removed. • Check if connector is erroneous connection. • Check if cable is open. >> Upon correcting the removed connector or mis-wiring, reset the power.
--



Check Point 2 : Check output voltage of Main PCB <ul style="list-style-type: none"> • Check voltage of Main PCB. (Measure at Main PCB side connector) >>1 pin(Red) - 3 pin(Black) DC5V \pm 5% <div data-bbox="172 1272 764 1422"> </div> <p>► If the voltage is not correct, replace Main PCB.</p>	
---	--



Check Point 3 : Check output voltage of Pressure Sensor <ul style="list-style-type: none"> • Check voltage of Main PCB. (Measure at Main PCB side connector) >>2 pin(White) - 3 pin(Black) Voltage is refer to the following graph. <div data-bbox="172 1747 774 2072"> </div> <p>► If the voltage is not correct, replace Presure Sensor.</p>	
--	--

Troubleshooting 17

OUTDOOR UNIT Error Method:

Trip detection

Indicate or Display:

Hydraulic unit :

Green	Red
◆9	◆4

◆n : n times blinking

Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆9	◆4	○	○	○	●

○ : Light OFF ● : Light ON ◆n : n times blinking

Detective Actuators: Outdoor unit Inverter PCB Outdoor unit Main PCB Compressor	Detective details: ▪ "Protection stop by overcurrent generation after inverter compressor start processing completed" generated consecutively 10 times. *The number of generations is reset if the start-up of the compressor succeeds.
---	---

Forecast of Cause : <ol style="list-style-type: none"> 1. Outdoor unit fan operation defective, foreign matter on hear exchanger, excessive rise of ambient temperature 2. Main PCB 3. Inverter compressor failure (lock, winding short) 4. Inverter PCB

Check Point 1 : Check the outdoor unit fan operation, heat exchanger, ambient temperature <ul style="list-style-type: none"> • No obstructions in air passages? • Heat exchange fins clogged • Outdoor unit fan motor check • Ambient temperature not raised by the effect of other heat sources? • Discharged air not sucked in?
--

↓
OK

Check Point 2 : Replace Inverter PCB ► If Check Point 1 do not improve the symptom, change Inverter PCB.

↓
OK

Check Point 3 : Replace Main PCB ► If Check Point 1,2 do not improve the symptom, change Main PCB.

↓
OK

Check Point 4 : Replace Compressor ► If Check Point 3 do not improve the symptom, change Compressor.

Troubleshooting 18

OUTDOOR UNIT Error Method:

Compressor motor control error

Indicate or Display:

Hydraulic unit :

Green	Red
◆9	◆5

◆n : n times blinking


Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆9	◆5	○	○	○	●

○ : Light OFF ● : Light ON ◆n : n times blinking

Detective Actuators: Outdoor unit Inverter PCB Outdoor unit Main PCB Compressor	Detective details: "Protection stop by "overcurrent generation at inverter compressor starting" restart" generated consecutively 10 times x 3 sets (total 30 times)
---	---

Forecast of Cause : 1. Defective connection of electric components 2. Inverter PCB failure 3. Main PCB failure 4. Compressor failure



Troubleshooting 19 OUTDOOR UNIT Error Method:

Outdoor Unit Fan Motor Error

Indicate or Display:

Hydraulic unit :

Green	Red
◆9	◆7

◆n: n times blinking

Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆9	◆7	○	○	●	●

○: Light OFF ●: Light ON ◆n: n times blinking

Detective Actuators:

Outdoor unit Inverter PCB
Outdoor unit Main PCB
Outdoor unit fan motor

Detective details:

- ① When outdoor fan rotation speed is less than 100rpm in 20 seconds after fan motor starts, fan motor stops.
- ② After fan motor restarts, if the same operation within 60sec is repeated 3 times in a row, compressor and fan motor stops.
- ③ If ① and ② repeats 5 times in a row, compressor and fan motor stops permanently.

Forecast of Cause:

1. Fan rotation failure
2. Motor protection by surrounding temperature rise
3. Inverter PCB failure
4. Main PCB failure
5. Outdoor unit fan motor failure

Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
- >>**If Fan or Bearing is abnormal, replace it.**



Check Point 2 : Check ambient temp. around motor

- Check excessively high temperature around the motor.
(If there is any surrounding equipment that causes heat)
- >>**Upon the temperature coming down, restart operation.**




Check Point 3 : Check Outdoor unit fan motor

- Check Outdoor unit fan motor. **(PARTS INFORMATION 4)**
- >>**If Outdoor Fan Motor is abnormal, replace Outdoor fan motor and Main PCB.**



Check Point 4 : Check Output Voltage of Inverter PCB

- Check outdoor unit circuit diagram and the voltage. (Measure at Inverter PCB side connector)



Read wire	DC voltage
Red - Black	280V (AC220V-10%) ~ 373V (AC240+10%)
White - Black	15 ± 1.5V



- **If the voltage is not correct, replace Inverter PCB.**



Check Point 5 : Replace Main PCB

- **If Check Point 1~4 do not improve the symptom, change Main PCB.**

<div>Troubleshooting 20</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Discharge Temperature Error</div>	<div>Indicate or Display:</div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆10</td><td>◆1</td></tr></table> <div>◆n: n times blinking</div>								Green	Red	◆10	◆1											
	Green	Red																					
	◆10	◆1																					
	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆10</td><td>◆1</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table> <div>○: Light OFF ●: Light ON ◆n: n times blinking</div>								Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆10	◆1	○	○	○
Mode	Error	L1	L2	L3	L4	L5	L6																
◆2	●	◆10	◆1	○	○	○	●																

Detective Actuators: Discharge temperature thermistor	Detective details: ▪ "Protection stop by "discharge temperature $\geq 110^{\circ}\text{C}$ during compressor operation"" generated 2 times within 24 hours.
---	---

Forecast of Cause :	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation failure, foreign matter on heat exchanger 4. Discharge temperature thermistor failure 5. Insufficient refrigerant
----------------------------	--

<Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open. <input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM, oil return) Refer to "Service Parts Information 3"



Check Point 3 : Check the outdoor unit fan,heat exchanger <input type="checkbox"/> Check for foreign object at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check(PARTS INFORMATION 4)



Check Point 4 : Check the discharge temp. thermistor <input type="checkbox"/> Discharger temp. thermistor characteristics check (Check by disconnecting thermistor from PCB. Refer to the Troubleshooting 9)




Check Point 5 : Check the refrigerant amount <input type="checkbox"/> Leak check
--

<Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open. <input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.
--



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM, oil return) Refer to "Service Parts Information 3"



<div>Troubleshooting 21</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Compressor Temperature Error</div>	<div>Indicate or Display:</div>													
	<div>Hydraulic unit :</div>					<div>Outdoor unit :</div>								
	<div>Green</div>		<div>Red</div>			<div>Mode</div>		<div>Error</div>	<div>L1</div>	<div>L2</div>	<div>L3</div>	<div>L4</div>	<div>L5</div>	<div>L6</div>
	<div>◆10</div>		<div>◆3</div>			<div>◆2</div>		<div>●</div>	<div>◆10</div>	<div>◆3</div>	<div>○</div>	<div>○</div>	<div>○</div>	<div>●</div>
	<div>◆n: n times blinking</div>					<div>○: Light OFF ●: Light ON ◆n: n times blinking</div>								

Detective Actuators: Compressor temperature thermistor	Detective details: ▪ "Protection stop by "compressor temperature $\geq 108^{\circ}\text{C}$ during compressor operation"" generated 2 times within 24 hours.
--	--

Forecast of Cause :	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation failure, foreign matter on heat exchanger 4. Compressor temperature thermistor failure 5. Insufficient refrigerant
----------------------------	---

<Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open. <input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM, oil return) Refer to "Service Parts Information 3"



Check Point 3 : Check the outdoor unit fan,heat exchanger <input type="checkbox"/> Check for foreign object at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check(PARTS INFORMATION 4)



Check Point 4 : Check the compressor temp. thermistor <input type="checkbox"/> Compressor temp. thermistor characteristics check (Check by disconnecting thermistor from PCB. Refer to the Troubleshooting 10)




Check Point 5 : Check the refrigerant amount <input type="checkbox"/> Leak check
--

<Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open. <input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.
--



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM, oil return) Refer to "Service Parts Information 3"




<div>Troubleshooting 22</div> <div><u>OUTDOOR UNIT Error Method:</u></div> <div>Pressure Error</div>	<div><u>Indicate or Display:</u></div> <div>Hydraulic unit :</div> <table><tr><td>Green</td><td>Red</td></tr><tr><td>◆10</td><td>◆5</td></tr></table> <div>◆n: n times blinking</div>	Green	Red	◆10	◆5	<div>Outdoor unit :</div> <table><tr><td>Mode</td><td>Error</td><td>L1</td><td>L2</td><td>L3</td><td>L4</td><td>L5</td><td>L6</td></tr><tr><td>◆2</td><td>●</td><td>◆10</td><td>◆5</td><td>○</td><td>○</td><td>○</td><td>●</td></tr></table> <div>○: Light OFF ●: Light ON ◆n: n times blinking</div>	Mode	Error	L1	L2	L3	L4	L5	L6	◆2	●	◆10	◆5	○	○	○	●
Green	Red																					
◆10	◆5																					
Mode	Error	L1	L2	L3	L4	L5	L6															
◆2	●	◆10	◆5	○	○	○	●															


Detective Actuators: Pressure sensor	Detective details: ▪ "Protection stop by suction pressure $\leq 0.02\text{MPa}$ continued for 5 minutes" repeats 5 times within 2 hours.
--	--

Forecast of Cause : <ol style="list-style-type: none"> 1. 3-way valve not opened 2. Outdoor unit ambient temperature too low 3. Outdoor unit fan operation defective, foreign matter at heat exchanger 4. EEV defective, strainer clogged 5. Solenoid valve defective 6. Low pressure sensor characteristics defective 7. Insufficient refrigerant
--

<Cooling operation>



<Heating operation>



Troubleshooting 23

OUTDOOR UNIT Error Method:

Heatsink Temperature Error

Indicate or Display:

Hydraulic unit :

Green	Red
◆10	◆12

◆n : n times blinking


Outdoor unit :

Mode	Error	L1	L2	L3	L4	L5	L6
◆2	●	◆10	◆12	○	○	●	●

○ : Light OFF ● : Light ON ◆n : n times blinking

Detective Actuators: Outdoor unit Inverter PCB Heatsink temperature thermistor	Detective details: ▪ "Protection stop by "heatsink temp. $\geq 80^{\circ}\text{C}$ " generated 2 times within 24 hours.
---	---

Forecast of Cause : <ol style="list-style-type: none"> 1. Foreign matter on heat sink, heat sink dirty 2. Foreign matter on heat exchanger, excessive ambient temperature rise 3. Heatsink temp. thermistor defective




3 TROUBLESHOOTING WITH NO ERROR CODE

Troubleshooting 24

Outdoor unit - No Power

Forecast of Cause:

1. Power Supply failure
2. External cause
3. Electrical Components defective



Troubleshooting 25

No Operation (Power is ON)

Forecast of Cause:

1. Setting/ Connection failure
2. External cause
3. Electrical Component defective

Check Point 1 : Check hydraulic unit and outdoor unit installation condition

- Are these hydraulic unit and outdoor unit suitable model numbers to connect?
- >> If there is some abnormal condition, correct it by referring to Installation manual and Data & Technical Manual.

↓
OK

Turn off Power and check/ correct followings.

- Is there loose or removed communication line of hydraulic unit and outdoor unit?

↓
OK

Check Point 2 : Check external cause on units (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.
(Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.

>> If the symptom does not change by above check 1, 2 replace Main PCB of outdoor unit.

Troubleshooting 26

No Cooling / No Heating

Forecast of Cause:

1. Hydraulic Unit error
2. Outdoor Unit error
3. Effect by Surrounding environment
4. Connection Pipe / Connection Wire failure
5. Refrigeration cycle failure

Check Point 1 : Check Outdoor Unit Operation

- Check if Outdoor Unit is operating
- Check any objects that obstruct the air flow route.
- Check clogged Heat Exchanger.
- Is the Valve open?



Check Point 2 : Check Site Condition

- Is capacity of Hydraulic unit fitted to Room size?
- Any windows open? Or direct sunlight ?




Check Point 3 : Check Hydraulic unit/ Outdoor unit Installation Condition

- Check connection pipe (specified pipe length & Pipe diameter?)
- Check any loose or removed communication line.
- >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**





Check Point 4 : Check Refrigeration cycle

- Check if Strainer is clogged (Refer to the figure at right).
- Measure Gas Pressure and if there is a leakage, correct it.
- >> **When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- Check EEV (PARTS INFORMATION 3)
- Check Compressor (PARTS INFORMATION 1,2)



Attention

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference like shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.



Troubleshooting 27

Abnormal Noise (Outdoor)

Forecast of Cause :

1. Abnormal installation
2. Fan failure
3. Compressor failure

Diagnosis method when Abnormal Noise is occurred

- Is Main Unit installed in stable condition?
- Is Fan Guard installed normally?



- Is Fan broken or deformed?
- Is the screw of Fan loose?
- Is there any object which obstruct the Fan rotation?



- Check if vibration noise by loose bolt or contact noise of piping is happening.




- Is Compressor locked?
>> Check Compressor (PARTS INFORMATION 1,2)

4 SERVICE PARTS INFORMATION

SERVICE PARTS INFORMATION 1

Compressor

Diagnosis method of Compressor (If Outdoor Unit LED displays Error, refer to Troubleshooting)




SERVICE PARTS INFORMATION 2

Inverter Compressor

Check Point 1 : Check Connection


- Check terminal connection of Compressor (loose or incorrect wiring)



Check Point 2 : Check Winding Resistance

- Check winding resistance of each terminal

► **If the resistance value is 0Ω or infinite, replace Compressor.**



Check Point 3 : Replace Inverter PCB

► **If the symptom does not change with above Check 1, 2, replace Inverter PCB.**

Check Point 4 : Replace Main PCB


► **If the symptom does not change with above Check 1~3, replace Main PCB.**

SERVICE PARTS INFORMATION 3

Outdoor unit Electronic Expansion Valve
(EEV)

Check Point 1 : Check Connections


- Check connection of connector
(Loose connector or open cable)



Check Point 2 : Check Coil of EEV

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value
White - Red	$46 \Omega \pm 4 \Omega$ at 20°C
Yellow - Red	
Orange - Red	
Blue - Red	



► **If Resistance value is abnormal, replace EEV.**

Check Point 3 : Check Noise at start up

- Turn on Power and check operation noise.
- **If an abnormal noise does not show, replace Main PCB.**

Check Point 4 : Check Voltage from Main PCB.


- Remove Connector and check Voltage (DC12V)
- **If it does not appear, replace Main PCB.**



Check Point 5 : Check Opening and Closing Operation of Valve


When Valve is closed,
it has a temp. difference between Inlet and Outlet.

CLOSE
Example : Hot Gas





If it is open,
it has no temp. difference between Inlet and Outlet.

OPEN
Example : Hot Gas



Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in ① ,
but if there is a difference as shown in ② , there is a possibility of inside clogged. In this case, replace Strainer.



SERVICE PARTS INFORMATION 4

Outdoor unit fan motor

Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

Check Point 2 : Check resistance of Outdoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 k Ω), replace Outdoor fan motor and Main PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Earth terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown)	Feed back (FG)




SERVICE PARTS INFORMATION 5

Thermistor

Check Point : Check Thermistor resistance value

❑ Remove connector and check Thermistor resistance value.

Temperature [°C]	Resistance Value [kΩ]			
	Thermistor A	Thermistor B	Thermistor C	Thermistor D
-30	1013.1	95.6	224.3	94.3
-20	531.6	50.3	115.2	49.6
-10	292.9	27.8	62.3	27.4
0	168.6	16.1	35.2	15.8
10	100.9	9.6	20.7	9.5
20	62.5	6.0	12.6	5.9
30	40.0	3.8	8.0	3.8
40	26.3	2.5	5.2	2.5
50	17.8	1.7	3.5	1.7
60	12.3	1.2	2.4	1.2
70	8.7	0.8	---	0.8
80	6.3	0.6	---	0.6
90	4.6	---	---	0.4
100	3.4	---	---	0.3
110	2.6	---	---	0.2
120	2.0	---	---	0.2
130	---	---	---	0.1
140	---	---	---	0.1
150	---	---	---	0.1
Applicable Thermistors	Discharge temp. TH Compressor temp. TH Ex. valve temp. TH	Heat exchanger. TH	Outdoor temp. TH	Heatsink temp. TH





4. FIELD WORKING


1. Disassembly Process of Outdoor Unit

7.1 WOYA100KLT and WOHA100KLT

7.1.1 Appearance





7.1.2 SERVICE PANEL removal



Remove the mounting screws

Remove the service panel by sliding downward

7.1.3 TOP PANEL removal




Remove the mounting screws and the top panel

7.1.4 MAIN PCB removal




Remove the connectors and the wires




Remove the main PCB


7.1.5 INVERTER PCB removal




Remove the mounting screws
Remove the binder (don't cut)
Remove the fan motor connector and the pressure switch connector




Change the direction of holder (step 1)



Change the direction of holder (step 2)




Change the direction of holder (step 3)



connector x 3


connector (black) x 1

Remove the connector 4 places



locking spacer x 6


screw




remove the wire from the filter

Remove the connectors and the wires
Remove the inverter PCB


7.1.6 FRONT PANEL removal



Remove the front pipe cover



Remove the mounting screws




Remove the front panel

7.1.7 FAN MOTOR removal




Remove the fan nut and the propeller fan



Remove the fan motor lead wire




**Remove the fan motor lead wire
Loose the clamp**



**Remove the mounting screws
Cut the binders**


7.1.8 RIGHT PANEL removal



Remove the mounting screws
Remove the rear pipe cover


Remove the mounting screws
Remove the right panel by sliding upward

7.1.9 THERMISTOR removal




Remove the thermistor

Remove the thermistor
(outdoor temp.)



Remove the E.E.V. thermistor

7.1.10 SOLENOID COIL (4-WAY VALVE) remove



Remove the mounting screw
Remove the solenoid coil

7.1.11 E.E.V. COIL remove




Remove the E.E.V. coil by hand

7.1.12 PRESSURE SWITCH remove




Remove the connectors

7.1.13 PCB HOLDER removal



Remove the mounting screws
Remove the covers



Lift up the PCB holder



Remove the binder at the PCB holder
(Don't cut)


7.1.14 COMPRESSOR removal

Precautions for exchange of compressor.



Do not allow moisture or debris to get inside refrigerant pipes during work.

Procedure for compressor removal.

1. Turn off the power.
2. Remove the TOP PANEL, FRONT PANEL and RIGHT PANEL ASSY.
3. Collect the refrigerant from the 3-way valve (gas) and 3-way valve (liquid).
4. Start the following work after completely collecting the refrigerant.
 - Do not reuse the refrigerant that has been collected.



Remove the sound insulation unit (top)



Remove the sound insulation unit (body)



**Cut the binder 2 places
Remove the insulation**




Remove the thermistor (discharge)




Remove the thermistor (comp. temp.)



Remove the terminal cover



**Remove the connectors
[R(U):red, T(W):black, S(V):white]**



Cut the discharge pipe in this range




Cut the suction pipe in this range

Caution

Keep their shape better.

There is a possibility of catching fire to oil when removing by the welding without cutting it.



Remove the special nut 3 places
Remove the compressor

Procedure for compressor installation

Reverse procedure to removing the compressor

Precautions for installation of compressor.

1. When brazing, do not apply the flame to the terminal.
2. When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

Precautions for exchange of refrigerant-cycle-parts

- (1) During exchange the following parts shall be protected by wet rag and not make the allowable temperature or more.
- (2) Remove the heat insulation when there is the heat insulation near the welding place.
Move and cool it when its detaching is difficult.
- (3) Cool the parts when there are parts where heat might be transmitted besides the replacement part.
- (4) Interrupt the flame with the fire-retardant board when the flame seems to hit the following parts directly.
- (5) Do not allow moisture or debris to get inside refrigerant pipes during work.
- (6) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

Part name	Allowble temperature	Precautions in work
4-WAY VALVE	120 °C	Remove the coil before brazing. And install the coil after brazing.
EXPANSION VALVE	120 °C	Remove the coil before brazing. And install the coil after brazing.
CHECK JOINT	120 °C	
PRESSURE SWITCH	100 °C	Tighten the flare part gripping it. (Tightening torque:12 1.5N m) Do the static electricity measures.
3-WAY VALVE (GAS) 3-WAY VALVE(LIQUID)	120 °C	