FUJITSU







OPERATING INSTRUCTIONS



Air to Water Heat Pump Split single service & Split integrated DHW type

Output: Contraction Structure

Your installation

Outdoor unit
Hydraulic unit
Settings
Radiators

Carrying out the installation

Distance

Regular checks	. 19
Checking the outdoor unit	. 19
Hot water tank*	. 19



This document was written in French and translated.

	4
Underfloor heating system	. 4
Fan coils / dynamic radiators with an integrated control system	. 4
Domestic Hot Water (DHW)*	. 4

6
nformation display
Details
Operation of the DHW system*
Selecting cooling mode*
Pilot wire* (if kit regulation extension AVS 55) 18
Telephone modem* (if Regulation extension kit AVS 55)
Configuring room control unit* (option) 18

19

3

► Symbols and definitions



Warning. Risk of serious injury to the person and / or risk of damage to the machine. Observe the warning.



Important information that must always be kept in mind.





Warning : Electricity hazard
Warning : Slightly flammable refrigerant.
Read the installation manual
Read the Operating Manual
Read the instructions

* according configuration / option

Please comply with the following instructions in order to avoid any risk of injury or inappropriate use of the appliance.

Commissioning

Do not switch the appliance ON until every filling operation has been performed

Do not attempt to install this appliance yourself. This heat pump must be installed by qualified personnel holding a certificate of competence.

The installation must always be properly earthed and fitted with a safety circuit breaker.

Do not change the power supply.

The appliances are not fireproof and therefore MUST NOT be installed in an explosive environment.

How to Use

This appliance can be used by children from 8 years old and by persons with reduced physical, sensory or mental capabilities or without experience or knowledge, provided that they are properly supervised or if they have been given instructions on how to use the appliance safely and the risks involved have been understood. Children must not play with the appliance. Cleaning and maintenance by the user must not be carried out by children without supervision.

This device is not intended for use by persons (including children) whose physical, sensory or mental capabilities are reduced, or persons without experience or knowledge, unless they have benefited from the intermediary of a person responsible for their safety, surveillance or prior instructions concerning the use of the device. Children should be supervised to ensure that they do not play with the appliance.

Do not let children insert foreign objects into the propeller protection grate or climb on the outdoor unit. The fins of the air heat exchanger are extremely thin and can cause cuts.

Nothing should obstruct the air circulation through the evaporator and out from the fan.

The outdoor unit must only be installed outside. If a shelter is required, it must have broad openings on all 4 sides and respect the installation clearances (see your installation engineer).

Do not climb on the outdoor unit.

Caution: copper pipes that carry refrigerating fluid may be hot and cause burns.

The room in which the unit is operating must be correctly ventilated in order to avoid any shortage of oxygen in the event of a refrigerant gas leak.

If your installation location already meets safety standards, do not carry out any modifications (ventilation, exhaust evacuation, openings, etc.) without the advice of your installation engineer.

Do not place any heat source under the remote control.

To avoid the risk of suffocation, keep plastic bags or plastic film of packaging materials away from young children.

Maintenance

Do not try to repair the appliance yourself.

If a power cable is damaged, it must be replaced by a qualified person to avoid any danger.

This appliance does not contain any components which can be repaired by the user. Removing either of the covers can expose you to dangerous electrical voltages.

Switching off the current is not sufficient to protect you from any external electrical shocks (condensers).

Do not open the outdoor unit or the hydraulic unit while they are in operation.

If you hear unusual noises, smell smoke or other odours coming from the appliance, turn off the power and contact your installation engineer.

Before starting any cleaning, turn off the power to the appliance.

Do not use aggressive cleaning liquids or solvents to clean the body work.

Do not use a pressure hose to clean the outdoor unit. You risk damaging the air exchanger and causing water ingress in the electrical circuits.

Your installation

Outdoor unit

The outdoor unit, as its name suggests, is placed outside your dwelling, and extracts energy from the outside air.

This unit was installed by your installer in a location where it is able to operate with best performance.

Nothing should obstruct the air circulation through the evaporator and out from the fan.

The water contained in the air may condense and flow out of the outdoor unit. The outdoor unit can generate a large volume of water called condensate.

In cold weather, this water freezes on contact with the exchanger and must be regularly removed using the defrosting cycles. The defrosting cycle is managed automatically by the control system and can produce steam emissions which are completely normal.

► Hydraulic unit

The hydraulic unit is located in your boiler room, cellar, garage..., and transfers energy to the heating and domestic hot water circuits*.

The hydraulic unit contains the appliance's control system which manages the room temperature and the production of domestic hot water*.

The hydraulic unit is fitted with an electrical backup* or boiler connection* which intervenes to provide additional heat during the coldest periods.

Settings

Your installer has carefully adjusted your installation. Do not change the settings without their consent. If in doubt, do not hesitate to contact them.

Your heating system is controlled by adjustment in relation to the outdoor temperature (temperature control).

The outdoor sensor monitors the outdoor temperature.

The installation of a room thermostat (option) makes it possible to improve the operation of the control system (influence of the ambient temperature is taken into account).

Radiators

In order to ensure operation of the control system, the room containing the thermostat must not also contain a thermostatic valve. If this is the case, it must be opened as far as possible.

Underfloor heating system

A new underfloor heating system must initially be heated slowly to avoid any problems involving cracking. Check with your installer that this initial heating procedure has indeed been performed before freely using your heating system.

An underfloor heating system's significant inertia prevents sudden room temperature differences. However, this inertia implies a reaction time of around several hours (approx 6 hours).

Any changes to the setting must be made slowly and leave the installation sufficient time to react. Any exaggerated or abrupt adjustments to the settings always result in significant temperature fluctuations during the day.

Similarly if your dwelling has an underfloor heating system, do not reduce it or switch it off if you will be absent for only short periods. The reheating period is always quite long (approx 6 hours).

Fan coils / dynamic radiators with an integrated control system

Do not use a room sensor in the area in question.

Domestic Hot Water (DHW)*

When hot water is required, the heat pump adapts its priority to meet the request.

No heating is produced during the preparation of domestic hot water.

The heat pump produces the domestic hot water (DHW), which is then additionally heated, if required, by the electrical backup.

To ensure a DHW setpoint over 45° C, the electrical backup heating or boiler (boiler connection kit)* must be left on.

The electrical backup allows the correct operation of the anti-legionella cycles.



fig. 1 - Overview of complete installation configuration

Carrying out the installation

▶ User interface, central ambient unit (option) and ambient sensor (option)





Central ambient unit (option)



Ambient sensor (option)

Ref.	Functions	- Definition of the functions
1	Selecting the DHW operation* $\frac{\cancel{R}}{\cancel{R}}$ Marche $\frac{\cancel{R}}{\cancel{R}}$ Arrêt	 Start: Production of DHW in function of the timer programme. Stop: Production of the DHW stopped with antifreeze function of the domestic water active. Manual start button: Press the DHW button for 3 s (switches from "reduced" to "comfort" until the DHW timer programme is switched again).
2	Digital display	 Check the operation, read the current temperature of the heating operation, or a possible fault. View the settings.
3	"ESC" output	- Exit the menu.
4	Navigation and setting	- Setting the comfort temperature value. - Menu selection - Setting the parameters.
5	Selecting the heating operation	 - O Service heating according to the heating programme (automatic summer/winter switching). - O Permanent comfort temperature. - O Permanent reduced temperature. - O "Stand-by" operation with antifreeze protection (provided that the electrical power supply of the heat pump is not interrupted).
6	Displaying information	 Miscellaneous information (see "Information display", page 7). A Reading the error codes. Information on maintenance, special operation.
7	Validation "OK"	 Enter the selected menu. Validate the parameter settings. Validate the comfort temperature value setting.
8	Selection of the refresh mode*	- Service cooling according to the heating programme (automatic summer/winter switching).
9	Reset (Press and relief)	- Reset the parameters and cancel the error messages. Do not use during normal operation
10	Setting button	- Setting the comfort temperature value.
11	Presence button	- Comfort / reduced switching.

* according configuration / option



Icons	Definitions
1 1 3	- Heating mode active with reference to the heating circuit.
*	- Heating in comfort mode.
D	- Heating in reduced mode.
\bigcirc	- Heating in "standby" mode (antifreeze).
*	- Refresh mode active *.
	- Holiday function activated.
X	- Process in progress.
Ø	- Compressor operation.
$\mathbf{\underline{\Diamond}}$	- Burner operation *.
\bigwedge_{\bullet}	- Default message.
de la companya	- Maintenance, special operation
INFO	- Information level activated.
PROG	- Programming activated.
ECO	- ECO function activated (Heating stopped temporarily)
1828 ¢ 2 0,5 (temperature ambiante	- Time / Parameter number / Setpoint value.
temperature ambiente	- Ambient temperature / Setpoint value.
	- Setpoint information / Parameter information.



fig. 2 - Closing the display

* according configuration / option

Appliance start up

ĺ

The installation and 1st start up of the appliance must be done by a qualified installer. That person will also give you instructions on starting and running the appliance.

- Ensure that the installation is fully filled with water and has been correctly bled and that there is a sufficient pressure of 1.5 to 2 bars on the manometer (ref. 2, fig. 3).
- · Close the installation's main circuit breaker.

In winter, so that the compressor can be preheated, close the installation's main circuit breaker (outdoor unit's power supply) some hours before pressing the on/off button.

Quick start-up

Once your installer has started your installation for the first time:

• Engage the Start/Stop switch.

During the regulator initialisation phase, the display shows all the symbols and then "Data, update" and then "State heat pump".

- Select the "AUTO" heating mode (fig. 4).
- Select the DHW mode (fig. 4).
- Adjust the date and time if necessary (fig. 5).



- 1. User interface
- 2. Manometer (installation hydraulic pressure)
- 3. Start/stop switch

fig. 3 - Start-up



fig. 4 - Selecting the heating mode AUTO and Select the DHW mode



fig. 5 - Setting the time and the date

Setting the time



Structure of the "End user" control menu



Parametering the setting

▼ General

- Only the parameters accessible to levels: End user
- ... are described in this document.
- The parameters accessible at level:
 - Commissioning
 - Engineer

... are described in the document reserved for these professional specialists.

Â

Do not make any modifications to these parameters without advice from these professional specialists. Incorrect use of any kind may result in serious malfunctioning.

▼ Setting parameters

With the screen on basic display. - Press **OK**.

Once in "End user" level.

- Scroll the menu list.
- Choose the desired menu.
- Scroll the function lines.
- Choose the desired line.
- Adjust the parameter.
- Check the setting by pressing OK.
- To return the menu, press **ESC**.

If no setting is made for 8 minutes, the screen returns automatically to the basic display.



▶ List of "End user" settings

Ligne	Fonction	Plage de réglage ou affichage	Incrément de réglage	Réglage de base		
Time of day	Time of day and date					
1	Hours / Minutes	00:00 23:59	1			
2	Day / Month	01.01 31.12	1			
3	Year	1900 2099	1			
Operator Section						
20	Language	English, Français, Italiano, Nederlands		English		

Ligne	Fonction	Plage de réglage ou affichage	Incrément de réglage	Réglage de base
Time prog	ram heating / cooling, circuit 1			
500	Pre-selection (Day / Week)	Mon-Sun, Mon-Fri, Sat-Sun, Monday, Tuesday,		Mon-Sun
501	1st phase On (start)	00:00:	10 min	6:00
502	1st phase Off (end)	00:00:	10 min	22:00
503	2nd phase On (start)	00:00:	10 min	:
504	2nd phase Off (end)	00:00:	10 min	;
505	3rd phase On (start)	00:00:	10 min	;
506	3rd phase Off (end)	00:00:	10 min	;
516	Default values, Circuit 1	No, Yes		No

Yes + OK: The default values memorised in the regulator replace and cancel the customised heating programs. Your customised settings are therefore lost.

Time program heating / cooling, circuit 2

	Only with the 2nd circuit kit option.			
520	Pre-selection (Day / Week)	Mon-Sun, Mon-Fri, Sat-Sun, Monday, Tuesday, …		Mon-Sun
521	1st phase On (start)	00:00:	10 min	6:00
522	1st phase Off (end)	00:00:	10 min	22:00
523	2nd phase On (start)	00:00:	10 min	;
524	2nd phase Off (end)	00:00:	10 min	;
525	3rd phase On (start)	00:00:	10 min	;
526	3rd phase Off (end)	00:00:	10 min	;
536	Default values, Circuit 2	No, Yes		No
	Veg. LOV: The default values memorized in the regulator replace and eared the sustainized besting programs			

Yes + OK: The default values memorised in the regulator replace and cancel the customised heating programs. Your customised settings are therefore lost.

Time program 4 / DHW

	If the installation is fitted with the DHW kit.			
560	Pre-selection (Day / Week)	Mon-Sun, Mon-Fri, Sat-Sun, Monday, Tuesday, …		Mon-Sun
561	1st phase On (start)	00:00:	10 min	00:00
562	1st phase Off (end)	00:00:	10 min	05:00
563	2nd phase On (start)	00:00:	10 min	14:30
564	2nd phase Off (end)	00:00:	10 min	17:00
565	3rd phase On (start)	00:00:	10 min	;
566	3rd phase Off (end)	00:00:	10 min	;
576	Default values	No, Yes		No

Yes + OK: The default values memorised in the regulator replace and cancel the customised heating programs. Your customised settings are therefore lost.

Holidays, heating circuit 1 (For the Holiday program is active, the heating mode should be on AUTO).

641	Preselection	Period 1 to 8		Period 1
642	Period Start (Day / Month)	01.01 31.12	1	
643	Period End (Day / Month)	01.01 31.12	1	
648	Operating level	Frost protection, Reduced		Frost protection

Ligne	Fonction	Plage de réglage ou affichage	Incrément de réglage	Réglage de base
Holidays,	heating circuit 2 (For the Holiday program is active	e, the heating mode should be on AUT	O).	
	If the installation consists of 2 heating circuits (Only with the 2nd circuit kit option).		
651	Preselection	Period 1 to 8		Period 1
652	Period Start (Day / Month)	01.01 31.12	1	
653	Period End (Day / Month)	01.01 31.12	1	
658	Operating level	Frost protection, Reduced		Frost protection
Heating ad	djustment, circuit 1			
710	Comfort setpoint	Reduced setpoint Comfort setpoint maximum	0.5 °C	20 °C
712	Reduced setpoint	Frost protection setpoint Comfort setpoint	0.5 °C	19 °C
714	Frost protection setpoint	4 °C Reduced setpoint	0.5 °C	8 °C
Cooling ci	ircuit 1 (Only with the cooling kit option)			
901	Operating mode	Protection, Automatic, Reduced, Comfort		Protection
902	Comfort cooling setpoint	17 40 °C	0.5 °C	24 °C
903	Reduced setpoint	5 40°C		26 °C
Heating ad	djustment, Circuit 2			
	Only with the 2nd circuit kit option (If the install	ation consists of 2 heating circuits).		
1010	Comfort setpoint	Reduced setpoint Comfort setpoint maximum	0.5 °C	20 °C
1012	Reduced setpoint	Frost protection setpoint Comfort setpoint	0.5 °C	19 °C
1014	Frost protection setpoint	4 °C Reduced setpoint	0.5 °C	8 °C
Cooling circuit 2 (Only with the cooling kit option)				
1201	Operating mode	Protection, Automatic, Reduced, Comfort		Protection
1202	Comfort cooling setpoint	17 40 °C	0.5 °C	24 °C
1203	Reduced setpoint	5 40°C		26 °C
Domestic	hot water			
	If the installation is fitted with the DHW kit.			
1600	Operating mode	Off, On, Eco		On
1610	Nominal setpoint	Reduced setpoint (line 1612) 65 °C	1	55 °C
	The backup electrical system is required to rea	ch this level.		
1612	Reduced setting	8 °C Nominal setting (line 1610)	1	40 °C
Swimming	g pool (Only with swimming pool kit option)			
2055	Setpoint solar heating	8 80 °C		26 °C
2056	Setpoint source heating	8 35 °C		22 °C

Ligne	Fonction	Plage de réglage ou affichage	Incrément de réglage	Réglage de base
Energy meter	r			
3095> 3110	: Not used			
3113	Energy brought in		Kwh	
	Cumulation of total consumed electrical energy Electrical energy consumed = Electrical energy ab electrical backup and / or DHW electrical backup (if	sorbed by outdoor unit + electric e installed).	energy absorbed b	by the heating
3121> 3123	: Not used			
3124	Energy brought in heating 1 (N - 1)		Kwh	
3125	Energy brought in DHW 1		Kwh	
3126	Energy brought in cooling 1		Kwh	
3128> 3130	: Not used			
3131	Energy brought in heating 2 (N - 2)		Kwh	
3132	Energy brought in DHW 2		Kwh	
3133	Energy brought in cooling 2		Kwh	
3135> 3137	: Not used			
3138	Energy brought in heating 3 (N - 3)		Kwh	
3139	Energy brought in DHW 3		Kwh	
3140	Energy brought in cooling 3		Kwh	
3142> 3144	: Not used			
3145	Energy brought in heating 4 (N - 4)		Kwh	
3146	Energy brought in DHW 4		Kwh	
3147	Energy brought in cooling 4		Kwh	
3149> 3151	: Not used			
3152	Energy brought in heating 5 (N - 5)		Kwh	
3153	Energy brought in DHW 5		Kwh	
3154	Energy brought in cooling 5		Kwh	
3156> 3158	: Not used			
3159	Energy brought in heating 6 (N - 6)		Kwh	
3160	Energy brought in DHW 6		Kwh	
3161	Energy brought in cooling 6		Kwh	
3163> 3165	: Not used			
3166	Energy brought in heating 7 (N - 7)		Kwh	
3167	Energy brought in DHW 7		Kwh	
3168	Energy brought in cooling 7		Kwh	
3170> 3172 : Not used				
3173	Energy brought in heating 8 (N - 8)		Kwh	
3174	Energy brought in DHW 8		Kwh	
3175	Energy brought in cooling 8		Kwh	
3177> 3179	: Not used			

Air to Water Heat Pump / OPERATING INSTRUCTIONS / 2122 - EN

Ligne	Fonction	Plage de réglage ou affichage	Incrément de réglage	Réglage de base
3180	Energy brought in heating 9 (N - 9)		Kwh	
3181	Energy brought in DHW 9		Kwh	
3182	Energy brought in cooling 9		Kwh	
3184> 3186	: Not used			
3187	Energy brought in heating 10 (N - 10)		Kwh	
3188	Energy brought in DHW 10		Kwh	
3189	Energy brought in cooling 10		Kwh	
390> 3267	: Not used			
Error				
6710	Reset Defaut relais	No, Yes		No
6711	Reset HP	No, Yes		No
Maintenance	/ special regime			
7141	Emergency operation	Off, On		Off
	Off: Heat pump functions normally (with boosters if On: Heat pump uses the electric boost system or th Use the "On" position only in Assist mode or Test m	necessary). le boiler connection. ode: may result in high power bills.		
Generator dia	agnosis			
8410	Return temp HP	0 140 °C		
	Setpoint (flow) HP			
8412	Flow temp HP	0 140 °C		
	Setpoint (flow) HP			
8413	Compressor modulation	0 100%		
Diagnostics	consumers			
8700	Outdoor temperature	-50 50 °C		
8701	Outdoor temp min Reset ? (no, yes)	-50 50 °C		50 °C
8702	Outdoor temp max Reset ? (no, yes)	-50 50 °C		-50 °C
8740	Room temperature 1	0 50 °C		
	Room setting 1			20 °C
8743	Flow temperature 1	0 140 °C		
	Flow temperature setpoint 1			
8756	Cooling flow temperature 1	0 140 °C		
	Cooling flow temperature setpoint 1			
8830	DHW (domestic hot water) temperature	0 140 °C		
	DHW temperature setpoint			50 °C

Information display

Various data can be displayed by pressing the info button $\overset{i}{\bigcirc}$.

Depending on the type of unit, configuration and operating state, some of the info lines listed below may not appear.



fig. 10 - Information key

- Possible error messages: The display shows the "Bell" symbol $\hat{\rightarrow}$.

Consult your heating technician.

- Service messages ; Special mode messages: The display shows the "Key" symbol *&* .

Consult your heating technician.

- Various data (see below).

Designation	Line	
Floor drying current setpoint .	-	
Current drying day.	-	
Terminated drying days.	-	
State heat pump.	8006	
State supplementary source.	8022	
State DHW.	8003	
State swimming pool.	8011	
State heating circuit 1.	8000	
State heating circuit 2.	8001	
State cooling circuit 1.	8004	
Outdoor temperature.	8700	
Room temperature 1.	0740	
Room setpoint 1.	8740	
Flow temperature 1.	0740	
Flow temperature setpoint1.	0/43	
Room temperature 2.	8770	
Room setpoint 2.		
Flow temperature 2.	8773	
Flow temperature setpoint 2.		
DHW (domestic hot water) temperature.	8830	
Heat pump return temperature.	8410	
Setpoint (return) HP.		
Heat pump flow temperature.	8412	
Setpoint (flow) HP.		
Swimming pool temperature.	8900	
Swimming pool temperature setpoint.		
Minimum remaining stop time for compressor 1.	-	
Minimum remaining running time for compressor 1.	-	

Details

If the electrical power supply has been cut off while the heat pump is operating (electrical power failure or unprogrammed pressing of the on/off switch on the hydraulic unit) the display will show error 370 when the appliance restarts. Do not be concerned, the communication between the outdoor and hydraulic unit will re-establish itself in a few moments.

Operation of the DHW system*

The key enables you to switch the DHW (domestic hot water) mode on and off. The selection is shown by a bar, which appears under the corresponding symbol.

Manual activation: Hold down the DHW key for 3 seconds (Switch from "reduced" to "nominal" until the next time the DHW timer switches over).

To ensure a DHW setting over 45°C, the electrical backup heating or the boiler must be left on.

In order to optimise operation of the DHW, it is possible to:

- Program the timer settings (parameters 560 to 576),

- Adjust the comfort temperature set point (parameter 1610),

- Adjust the reduced temperature set point (parameter **1612**). Press the info key $\overset{i}{\bigcirc}$ to obtain the details on the DHW (temperature setting operation).



fig. 8 - Select the DHW mode

Selecting cooling mode*

If the installation is fitted with the cooling kit. The key activates and deactivates cooling mode.



fig. 9 - Selecting cooling mode

▶ Pilot wire* (if AVS 55 kit)

It's possible to order up to 15 electric heaters via output "pilot wire".

The "pilot wire" handles only the hourly operation of electric heaters (comfort mode / reduced mode commutation and Frost protection mode).

The comfort temperature setting should be done directly on the electric heater(s). The "pilot wire" does not handle the temperature of the electric heaters. Refer to the manual supplied with the electric heater(s).

Put the electric heaters on "PROG" mode or "AUTO" mode for piloting by the regulation board.

The difference between the comfort temperature and the reduced temperature is from 3.5°C.

Frost protection temperature is set directly on the electric heaters. Refer to the manual supplied with the electric heater(s).

In the absence of signal, electric heaters operating in comfort mode.

► Telephone modem* (if AVS 55 kit)

It is possible to command the switching of the heating mode to the "freeze" protection mode / reduced (and vise versa) on the heat pump using a modem contact.

The telephone command switches the current heat pump settings to "freeze" protection mode / reduced (and vise versa). In accordance with the setting, any temperature requests from the heating circuits and the DHW are ignored or activated.

The "freeze" protection mode / reduced must not be selected on the heat pump and/or the remote control. See with your installer.

Configuring room control unit* (option)

In the event that the room control unit (see page 6), is used, on start-up, after initialising for around 3 minutes, the language needs setting:

- Press OK.
- Choose menu "Operator section".
- Choose language "Language" English.



fig. 11 - Selecting the frost protection

D Maintenance

In order to ensure that your appliance operates correctly for many years, the maintenance operations described below are required at the start of each heating season. They are generally carried out as part of a maintenance contract.

Regular checks

- Check the water pressure in the heating circuit regularly (refer to the installer's recommended pressure between 1 and 2 bar)
- If a filling operation and a pressure increase are required, check what type of fluid was used initially (when in doubt, contact your installer).
- If frequent refills are required it is absolutely essential that you check for any leaks.

i

The frequent addition of water risks scaling the exchanger and affects its performance and lifespan.

Checking the outdoor unit

Remove any dust from the exchanger, if necessary, while making sure not to damage the blades. Check that there is nothing blocking the air flow.

▼ Checking the refrigeration circuit

Consult your heating technician.

Domestic hot water tank*

Maintenance on the tank must be carried out annually (frequency may vary according to water hardness).

Consult your heating technician.

* according configuration / option

End-of-life of the appliance

The appliances must be dismantled and recycled by a specialised service. The appliances must not, under any circumstances, be thrown out with household waste, bulky waste or at a tip.

At the end of its service life, please contact your installer or local representative to proceed with its dismantling and recycling.



This unit is identified by this symbol. It means that all electrical and electronic products must not be included in household waste. A specific recycling system for this type of product has been set up in European Union countries (*), Norway, Iceland and Liechtenstein. Do not try to dismantle this product yourself. It may have damaging effects on your health or on the environment. Reprocessing of the refrigerant, lubricant and other parts may be performed by a qualified installer in compliance with the local and national legislation in force. This unit must be recycled by a specialised service and in no case may it be thrown away with household waste, rubble or in a landfill. Please contact your installer or local representative for more .

* Depending on the national regulations of each member state.

Date of installation :



Fritz-Vomfelde-Strasse 26-32 40547 Düsseldorf - Germany