

**SPLIT TYPE  
ROOM AIR CONDITIONER  
WALL MOUNTED<sup>type</sup>  
INVERTER**

# SERVICE INSTRUCTION

<b>Models</b>	<b>Indoor unit</b>	<b>Outdoor unit</b>
	AS*G09LZCA	AO*G09LZCAN
	AS*G12LZCA	AO*G12LZCAN
	AS*G14LZCA	AO*G14LZCAN
	RSG09LZCA	ROG09LZCAN
	RSG12LZCA	ROG12LZCAN
	RSG14LZCA	ROG14LZCAN

*Refrigerant*

**R410A**

# CONTENTS

## 1. DESCRIPTION OF EACH CONTROL OPERATION

1. COOLING OPERATION.....	01-01
2. HEATING OPERATION.....	01-02
3. DRY OPERATION.....	01-02
4. AUTO CHANGEOVER OPERATION.....	01-03
5. INDOOR FAN CONTROL.....	01-04
6. OUTDOOR FAN CONTROL.....	01-06
7. LOUVER CONTROL.....	01-07
8. COMPRESSOR CONTROL.....	01-08
9. TIMER OPERATION CONTROL.....	01-09
10. ELECTRONIC EXPANSION VALVE CONTROL.....	01-12
11. TEST OPERATION CONTROL.....	01-12
12. PREVENT TO RESTART FOR 3 MINUTES ( 3 MINUTES ST ).....	01-12
13. FOUR-WAY VALVE EXTENSION SELECT.....	01-12
14. AUTO RESTART.....	01-13
15. MANUAL AUTO OPERATION ( INDOOR UNIT BODY OPERATION ).....	01-13
16. FORCED COOLING OPERATION.....	01-13
17. COMPRESSOR PREHEATING.....	01-14
18. 10°C HEAT OPERATION.....	01-14
19. ECONOMY OPERATION.....	01-14
20. HUMAN SENSOR CONTROL.....	01-14
21. OUTDOOR UNIT LOW NOISE OPERATION.....	01-15
22. POWERFUL OPERATION.....	01-15
23. BASE HEATER OPERATION.....	01-15
24. DEFROST OPERATION CONTROL.....	01-16
25. OFF DEFROST OPERATION CONTROL.....	01-18
26. VARIOUS PROTECTIONS.....	01-19

## **2. TROUBLE SHOOTING**

2-1 ERROR DISPLAY.....	02-01
2-1-1 INDOOR UNIT AND WIRED REMOTE CONTROLLER DISPLAY.....	02-01
2-1-2 WIRED REMOTE CONTROLLER DISPLAY ( OPTION ).....	02-02
2-2 TROUBLE SHOOTING WITH ERROR CODE.....	02-03
2-3 TROUBLE SHOOTING WITH NO ERROR CODE.....	02-24
2-4 SERVICE PARTS INFORMATION.....	02-29

# ***WALL MOUNTED type INVERTER***

1 . DESCRIPTION OF EACH  
CONTROL OPERATION

# 1. COOLING OPERATION

A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.


- \* If the room temperature is 2°C higher than a set temperature, the compressor operation frequency will attain to maximum performance.
- \* If the room temperature is some degrees lower than a set temperature, the compressor will be stopped.
- \* When the room temperature is between +2°C to -2.5°C of the setting temperature, the compressor frequency is controlled within the range shown in Table1. However, the maximum frequency is limited in the range shown in Fig.1 based on the indoor fan mode and the outdoor temperature.

( Table 1 : Compressor frequency range )

Model	Minimum frequency	Maximum frequency I	Maximum frequency II
09LZCAN 12LZCAN	10rps	80rps	63rps
14LZCAN	12rps	91rps	63rps

When the compressor operates for 30 minutes continuously at over the maximum frequency II , the maximum frequency is changed from the maximum frequency I to the maximum frequency II .

( Fig. 1 : Outdoor temperature zone )



( Table 2 : Limit of maximum speed based on outdoor temperature )

Model	Outdoor temp. zone	Indoor fan mode			
		Hi	Me	Lo	Quiet
09LZCAN 12LZCAN	A zone	80rps	51rps	43rps	26rps
	B zone	80rps	51rps	43rps	26rps
	C zone	80rps	51rps	43rps	26rps
	D zone	47rps	35rps	29rps	20rps
	E zone	47rps	35rps	29rps	20rps
	F zone	47rps	35rps	29rps	20rps
14LZCAN	A zone	91rps	44rps	34rps	24rps
	B zone	91rps	44rps	34rps	24rps
	C zone	72rps	44rps	34rps	24rps
	D zone	52rps	30rps	21rps	18rps
	E zone	63rps	34rps	27rps	19rps
	F zone	63rps	34rps	27rps	19rps

## 2. HEATING OPERATION

A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.

- \* If the room temperature is lower by 3°C than a set temperature, the compressor operation frequency will attain to maximum performance.
- \* If the room temperature is some degrees higher than a set temperature, the compressor will be stopped.
- \* When the room temperature is between +2.5°C to -3°C of the setting temperature, the compressor frequency is controlled within the range shown in Table 3. However, the maximum frequency is limited shown in Table 4 based on the fan mode.

( Table 3 : Compressor frequency range )

Model	Minimum frequency	Maximum frequency
09LZCAN 12LZCAN	10rps	119rps
14LZCAN	16rps	130rps

## 3. DRY OPERATION


The compressor frequency shall change according to the temperature, set temperature, and room temperature variation which the room temperature sensor of the indoor unit body has detected as shown in the Table 4 .

However, after the compressor is driven, the indoor unit shall run at operation frequency of 40rps (09LZCAN) , 40rps (12LZCAN), 40rps (14LZCAN) for 80 seconds.

( Table 4 : Compressor frequency in Dry mode )

Model		Operating frequency	Model		Operating frequency
09LZCAN 12LZCAN	X zone	26rps	14LZCAN	X zone	24rps
	J zone	18rps		J zone	16rps
	Y zone	0rps		Y zone	0rps


( Fig.2 : Compressor control based on room temperature )



## 4. AUTO CHANGEOVER OPERATION

When the air conditioner is set to the AUTO mode by remote control, operation starts in the optimum mode from among the Heating, Cooling, Dry and Monitoring modes.  
During operation, the optimum mode is automatically switched in accordance with temperature changes.  
The temperature can be set between 18°C and 30°C in 1°C steps.

( Fig. 3 : Operation flow chart )



## 5. INDOOR FAN CONTROL

### 1. Fan speed

( Table 5 : Indoor fan speed )

Operation mode	Air flow mode	Speed (rpm)		
		09LZCA	12LZCA	14LZCA
Heating	Powerful	1320	1320	1370
	Hi	1100	1100	1210
	Me+	1040	1040	1140
	Me	940	940	1040
	Lo	820	820	880
	Quiet	600	600	740
	Cool air prevention	600	600	600
	S-Lo	540	540	540
Cooling/ Fan	Powerful	1320	1320	1370
	Hi	1100	1100	1210
	Me	940	940	1040
	Lo	820	820	880
	Quiet	600	600	680
Dry		X zone: 600 J zone: 600	X zone: 600 J zone: 600	X zone: 680 J zone: 640

### 2. FAN OPERATION


The airflow can be switched in 5 steps such as Auto, Quiet, Lo, Me, Hi, while the indoor fan only runs. When fan mode is set at [Auto], it operates on [Me] fan Speed.

### 3. COOLING OPERATION

Switch the airflow [Auto], and the indoor fan motor will run according to a room temperature, as shown in Fig. 4 .

On the other hand, if switched in [Hi] ~ [Quiet], the indoor motor will run at a constant airflow of [Cool] operation modes Quiet, Lo, Me, Hi, as shown in Table 5 .

( Fig. 4 : Airflow change - over ( Cooling : Auto ) )



TR : Room temperature  
Ts : Setting temperature

### 4. DRY OPERATION

Refer to the Table 5 .


During the dry mode operation, the fan speed setting can not be changed.



## 5. HEATING OPERATION

Switch the airflow [Auto], and the indoor fan motor will run according to a room temperature, as shown in Fig. 5. On the other hand, if switched in [Hi] ~ [Quiet], the indoor motor will run at a constant airflow of [Heat] operation modes Quiet, Lo, Me, High, as shown in Table 5.


( Fig. 5 : Airflow change - over ( Heating : Auto ) )



## 6. COOL AIR PREVENTION CONTROL (Heating mode)

The maximum value of the indoor fan speed is set as shown in Fig. 6 based on the detected temperature by the indoor heat-exchanger sensor on heating mode.

( Fig. 6 : Cool air prevention control )




## 7. MOISTURE RETURN PREVENTION CONTROL (Cooling mode & Dry mode)

Switch the airflow [Auto] at cooling mode, and the indoor fan motor will run as shown in Fig. 7.

## 8. INDOOR UNIT FAN CONTROL FOR ENERGY SAVING (Cooling mode)

Switch the airflow at cooling mode, and the indoor fan motor will run as shown in Fig. 7. It depends on the Function setting No.49 "Indoor unit fan control for energy saving."

( Fig. 7 : Indoor fan control )



( Table 6 : Indoor fan speed )

Model	Dry			Cooling
	X zone	J zone	Y zone	
09LZCA 12LZCA	600rpm	600rpm	0 ⇔ 540rpm	600rpm
14LZCA	680rpm	640rpm	0 ⇔ 540rpm	680rpm

## 6. OUTDOOR FAN CONTROL

### 1. Outdoor Fan Motor

The Table 7 shows the type of the outdoor fan motor.  
The control method is different between AC motor and DC motor.

( Table 7 : Type of Motor )

Model	AC Motor	DC Motor
09LZCAN 12LZCAN 14LZCAN		○


### 2. Fan Speed

( Table 8 : Outdoor fan speed )

Model	Zone ※	(rpm)		
		Cooling	Heating	Dry
09LZCAN	Y	1050/ 870/ 720/ 590/ 530	1100/ 870/ 780/ 720/ 590/ 480	530
	Z	870/ 300		
	F	300/ 250		
	G	250/ 200		
12LZCAN	Y	1050/ 870/ 720/ 590/ 530	1100/ 870/ 780/ 720/ 590/ 480	530
	Z	870/ 530/ 300		
	F	300/ 250		
	G	250/ 200		
14LZCAN	Y	1050/ 870/ 720/ 530	1100/ 1000/ 780/ 720/ 590/ 480	530
	Z	870/ 530/ 300		
	F	300		
	G	250/ 200		

※ Refer to Fig. 8

( Fig. 8 : Outside air temperature zone selection )



- \* The outdoor fan speed mentioned above depends on the compressor frequency.  
(When the compressor frequency increases, the outdoor fan speed also changes to the higher speed. When the compressor frequency decreases, the outdoor fan speed also changes to the lower speed.)
- \* After the defrost control is operated on the heating mode, the fan speed keeps at the higher speed as Table 9 without relating to the compressor frequency.

( Table 9 : Outdoor fan speed after the defrost )

Model	Fan speed
09LZCAN 12LZCAN 14LZCAN	1100rpm

# 7. LOUVER CONTROL


## 1. VERTICAL LOUVER CONTROL

(Function Range)

Each time the button is pressed, the air direction range will change as follows:

① ↔ ② ↔ ③ ↔ ④ ↔ ⑤ ↔ ⑥ ↔ ⑦ ↔ ⑧

( Fig. 9 : Vertical air direction range )



The Remote Controller's display does not change.

- Use the air direction adjustments within the ranges shown above.
- The vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.

Cooling / Dry mode : Horizontal flow ①

Heating mode : Downward flow ⑦

- After beginning of Auto/ Heat mode operated and automatic defrosting operation time, the airflow will be horizontal ① . However, the Airflow direction cannot be adjusted at beginning Auto operation mode.


## 2. HORIZONTAL LOUVER CONTROL

(Function Range)

Each time the button is pressed, the air direction range will change as follows.

⑤ ↔ ④ ↔ ① ↔ ② ↔ ③

( Fig. 10 : Horizontal air direction range )



## 3. SWING OPERATION

### To select Vertical Airflow Swing Operation

When the swing signal is received from the remote controller, the vertical louver starts to swing.

( Table 10 : Vertical swinging range)

	Range
Cooling / Dry mode Fan mode (①~⑤)	① ↔ ⑤
Heating mode Fan mode (⑥~⑧)	⑤ ↔ ⑧

- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.

### To select Horizontal Airflow Swing Operation

When the swing signal is received from the remote controller, the horizontal louver starts to swing.

( Table 11 : Horizontal swinging range)

	Range
Cooling/ Dry/ Heating/ Fan mode	① ↔ ⑤

- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.

## 8. COMPRESSOR CONTROL

### 1. OPERATION FREQUENCY RANGE

The operation frequency of the compressor is different based on the operation mode as shown in the Table 12 .


( Table 12 : Compressor frequency range )

Model	Cooling		Heating		Dry	
	Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
09LZCAN 12LZCAN	10rps	80rps	10rps	119rps	18rps	26rps
14LZCAN	12rps	91rps	16rps	130rps	16rps	24rps

### 2. OPERATION FREQUENCY CONTROL AT NORMAL START UP

The compressor frequency soon after the start-up is controlled as shown in the Fig.11 .

( Fig. 11 : Compressor control at start-up )



(Frequency)

Model	Frequency I	Frequency II	Frequency III	Frequency IV	Frequency V	Frequency VI
09LZCAN 12LZCAN	40rps	57rps	72rps	80rps	101rps	110rps
14LZCAN	40rps	59rps	72rps	80rps	101rps	110rps

(Time)

Model	Time ①	Time ②	Time ③	Time ④	Time ⑤	Time ⑥
09LZCAN 12LZCAN 14LZCAN	80sec	110sec	140sec	200sec	350sec	410sec

### 3. LIMITATION OF COMPRESSOR FREQUENCY BY OUTDOOR TEMPERATURE

The minimum compressor frequency is limited by outdoor temperature as shown in the Table 13 .

( Table 13 : Limitation of compressor frequency )

[ Cooling/ Dry ]

Model	10°C		14°C		40°C	
	Under	Over	Under	Over	Under	Over
09LZCAN 12LZCAN	35rps	18rps	10rps	23rps		

Model	0°C		10°C		40°C	
	Under	Over	Under	Over	Under	Over
14LZCAN	24rps	18rps	12rps	24rps		

[ Heating ]

Model	- 5°C		1°C		7°C		18°C	
	Under	Over	Under	Over	Under	Over	Under	Over
09LZCAN 12LZCAN	35rps	29rps	18rps	10rps	16rps			

Model	- 5°C		1°C		7°C	
	Under	Over	Under	Over	Under	Over
14LZCAN	24rps	24rps	18rps	16rps		

# 9. TIMER OPERATION CONTROL

## 9-1 WIRELESS REMOTE CONTROLLER


The Table 14 shows the available timer setting based on the product model.

( Table 14 : Timer setting )


Model	ON TIMER / OFF TIMER	PROGRAM TIMER	SLEEP TIMER	WEEKLY TIMER
09LZCA 12LZCA 14LZCA	○	○	○	○

### 1. ON TIMER / OFF TIMER

- OFF timer : When the clock reaches the set time, the air conditioner will be turned off.




- ON timer : When the clock reaches the set time, the air conditioner will be turned on.



### 2. PROGRAM TIMER

- The program timer allows the OFF timer and ON timer to be used in combination one time.




- Operation will start from the timer setting (either OFF timer or ON timer) whichever is closest to the clock's current timer setting.  
The order of operations is indicated by the arrow in the remote control unit's display.
- SLEEP timer operation cannot be combined with ON timer operation.

### 3. SLEEP TIMER

If the sleep is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time ON.


#### In the cooling operation mode

When the sleep timer is set, the setting temperature is increased 1°C  
It increases the setting temperature another 1°C after 1 hour.  
After that, the setting temperature is not changed and the operation is stopped at the time of timer setting.




#### In the heating operation mode

When the sleep timer is set, the setting temperature is decreased 1°C  
It decreases the setting temperature another 1°C every 30 minutes.  
Upon lowering 4°C, the setting temperature is not changed and the operation stops at the time of timer setting.



### 4. WEEKLY TIMER

This timer function can set operation times of the each day of the week. All days can be set together, the weekly timer can be used to repeat the timer setting for all of the days.



## 9-2 WIRED REMOTE CONTROLLER ( OPTION )

The Table 15 shows the available timer setting based on the product model.

( Table 15 : Timer setting )

Model	ON TIMER / OFF TIMER	WEEKLY TIMER	TEMPERATURE SET BACK TIMER
09LZCA 12LZCA 14LZCA	○	○	○


### 1. ON TIMER / OFF TIMER

Same to 9-1 1.ON TIMER / OFF TIMER and shown in those.

### 2. WEEKLY TIMER

This timer function can set operation times of the each day of the week.


All days can be set together, the weekly timer can be used to repeat the timer setting for all of the days.



### 3. TEMPERATURE SET BACK TIMER

This timer function can change setting temperature of setting operation times of the each day of the week.

This can be together with other timer setting.



## 10. ELECTRONIC EXPANSION VALVE CONTROL

The most proper opening of the electronic expansion valve is calculated and controlled under the present operating condition based on the Table 16 .

The compressor frequency, the detected temperature by the discharge temperature sensor, the indoor heat exchanger sensor, the outdoor heat exchanger sensor, and the outdoor temperature sensor.

( Table 16 : The pulse range of the electronic expansion valve control )

Model	Operation mode	Pulse range
09LZCAN 12LZCAN 14LZCAN	Cooling / Dry mode	Between 32 to 480 pulses.
	Heating mode	

- \* The expansion valve is set at 480 pulses 110seconds after the compressor had stopped.
- \* Initialization will start after 24 hours pass from the last initialization, and the compressor stops
- \* At the time of supplying the power to the outdoor unit, the initialization of the electronic expansion valve is operated (528 pulses are input to the closing direction).

## 11. TEST OPERATION CONTROL

### [ Operation method ]

The outdoor unit, may not operate, depending on the room temperature.

In this case, keep on pressing the MANUAL AUTO button of the indoor unit for more than 10 seconds.

The Operation lamp and Timer lamp will begin to flash simultaneously during cooling test run.

Then, heating test run will begin in about 3 minutes when HEAT is selected by the remote control operation.

(When the air conditioner is running by pressing the test run button, the Operation lamp and Timer lamp will simultaneously flash slowly.)

### [ Release ]

Perform the test operation for 60 minutes.

Pressing the MANUAL AUTO button of the indoor unit for more than 3 seconds.

### [ Using the Wired remote control (Option) ]

If the Operation lamp is on, press the START/STOP button to turn it off.

Press the MODE and the FAN buttons at the same time for more than two seconds to start the test operation.

The operation lamp will light up and "o1" will be displayed on the set temperature display.

### [ Release ]

Perform the test operation for 60 minutes.

Pressing the START/STOP button will stop the test operation.

## 12. PREVENT TO RESTART FOR 3 MINUTES ( 3 MINUTES ST )

The compressor won't enter operation status for 2 minutes and 20 seconds after the compressor is stopped, even if any operation is given.

## 13. FOUR-WAY VALVE EXTENSION SELECT

At the time when the air conditioner is switched from the cooling mode to heating mode, the compressor is stopped, and the four-way valve is switched in 2 minutes and 20 seconds later after the compressor stopped.



## 14. AUTO RESTART

When the power was interrupted by a power failure, etc. during operation, the operation contents at that time are memorized and when power is recovered, operation is automatically started with the memorized operation contents.

When the power is interrupted and recovered during timer operation, since the timer operation time is shifted by the time the power was interrupted, an alarm is given by blinking (7 sec ON/2 sec OFF) the indoor unit body timer lamp.

[ Operation contents memorized when the power is interrupted ]


- Operation mode
- Set temperature
- Set air flow
- Timer mode and set time (set by wireless remote controller)
- Set air flow Direction
- Swing
- ECONOMY operation
- 10°C HEAT operation
- Outdoor low noise operation
- Human sensor

## 15. MANUAL AUTO OPERATION ( INDOOR UNIT BODY OPERATION )

When the remote control is lost or battery power dissipated, this function will work without the remote control. When MANUAL AUTO button is set more than 3seconds and less than 10seconds, MANUAL AUTO OPERATION will be started as shown in Table 17 . To stop operation, press the MANUAL AUTO button for 3seconds.

( Table 17 : Manual auto operation )

	Manual auto operation
OPERATION MODE	Auto changeover
FAN CONT. MODE	Auto
TIMER MODE	Continuous (No timer setting available)
SETTING TEMP.	24°C
SETTING LOUVER	Standard
SWING	OFF
ECONOMY	OFF



## 16. FORCED COOLING OPERATION ( TEST OPERATION )

When FORCED COOLING OPERATION is set, the operation is controlled as shown in Table 18 .

( Table 18 : Forced cooling operation )

	Forced cooling operation
OPERATION MODE	Cooling
FAN CONT. MODE	Hi
TIMER MODE	-
SETTING TEMP.	Room Temp is not controlled
SETTING LOUVER	Horizontal (It is changed follow as setting of remote controller)
SWING	OFF
ECONOMY	-

- Forced cooling operation is started when press MANUAL AUTO button for 10 seconds or more.
- During the forced cooling operation, it operates regardless of room temperature sensor.
- Operation LED and timer LED blink at the same time during the forced cooling operation.  
They blink for 1 second ON and 1 second OFF on both operation LED and timer LED (same as test operation).
- Forced cooling operation is released after 60 minutes of starting operation or pressing MANUAL AUTO button for 3 seconds.

## 17. COMPRESSOR PREHEATING

When the outdoor heat exchanger temperature is lower than 5°C and the all operation has been stopped for 30 minutes, power is applied to the compressor and the compressor is heated. (By heating the compressor, warm air is quickly discharged when operation is started.) When operation was started, and when the outdoor heat exchanger temperature rises to 7°C or greater, preheating is ended.

## 18. 10°C HEAT OPERATION

The 10°C HEAT operation performs as below when pressing 10°C. HEAT button or Weekly timer setting on the remote controller.

( Table 19 : 10°C heat operation )

Mode	Heating
Setting temperature	10°C
Fan mode	Auto
LED display	Economy
Defrost operation	Operate as normal

## 19. ECONOMY OPERATION

The ECONOMY operation functions by pressing ECONOMY button on the remote controller. At the maximum output, ECONOMY Operation is approximately 70% of normal air conditioner operation for cooling and heating.

The ECONOMY operation is almost the same operation as below settings.

( Table 20 : Economy operation )

Mode	Cooling/ Dry	Heating
Target temperature	Setting temp.+1°C	Setting temp.-1°C

## 20. HUMAN SENSOR CONTROL

The HUMAN SENSOR functions by pressing SENSOR button on the remote controller.

When the sensor detects that there is no one in the room for 20 minutes or more, it automatically changes the operation as below settings.


When someone comes back into the room, the human sensor will detect this, and automatically revert to the original settings.

( Table 21 : Human sensor control )


Mode	Cooling/ Dry	Heating
Target temperature	Setting temp.+2°C	Setting temp.-4°C

( Application range )

Vertical angle 90°(Side view)



Horizontal angle 100°(Top view)



※ The sensor unit should detect when the human body (estimate: 150cmX30cm) or the object which has more than 4°C temp. difference from the background and are crossed with 1.0m/s speed in front of the sensor unit.

## 21. OUTDOOR UNIT LOW NOISE OPERATION

The OUTDOOR UNIT LOW NOISE Operation functions by pressing OUTDOOR UNIT LOW NOISE button on the remote controller.

This operation stops the PFC control, and changes the Current release operation/release value.

OUTDOOR UNIT LOW NOISE Operation mode can be used during cooling, dry ,heating and automatic operation. It can not be used in Fan mode.

( Table 22 : Outdoor unit low noise operation )

	Control / Release
Current release operation/release value	3.5A / 3.0A

## 22. POWERFUL OPERATION

The POWERFUL OPERATION functions by pressing POWERFUL button on the remote controller.

The indoor unit & outdoor unit will operate at maximum power as shown in Table 23 .

( Table 23 : Powerful operation )

	Powerful operation
COMPRESSOR FREQUENCY	Maximum
FAN CONT. MODE	Powerful
SETTING LOUVER	Cooling/ Dry : 4, Heating : 7

Release Condition is as follows.

[Cooling / Dry]

- Room temperature  $\leq$  Setting temperature -1.5°C or Operation time has passed 20 minutes.


[Heating]

- Room temperature  $\geq$  Setting temperature +1.5°C or Operation time has passed 20 minutes.

## 23. BASE HEATER OPERATION

The base heater is operated as shown in Fig. 12 .

( Fig.12 : Base heater control )



- \* When the compressor stops, Base heater is OFF.
- \* When the outdoor fan motor stops, Base heater is OFF.
- \* In the cooling mode, Base heater is OFF.
- \* After defrost, it will turn OFF the heater (Comp Accumulated operation time) after 15 minutes.

## 24. DEFROST OPERATION CONTROL

### 1. CONDITION OF STARTING THE DEFROST OPERATION

The defrost operation starts as shown in the following Table 24 .

( Table 24 : Condition of starting Defrost Operation )

Normal defrost	Compressor integrating operation time	
	Less than 25 minutes (09/12LZCAN) Less than 40 minutes (14LZCAN)	More than 25 minutes (09/ 12LZCAN) More than 40 minutes (14LZCAN)
	Does not operate	Outdoor heat exchanger temp. $\leq -17^{\circ}\text{C}$ (at outside air temp. $\geq -10^{\circ}\text{C}$ ) ----- Outdoor heat exchanger temp. $\leq$ Outside air temp. $-7^{\circ}\text{C}$ or Outdoor heat exchanger temp. $\leq -25^{\circ}\text{C}$ (at $-20^{\circ}\text{C} < \text{Outdoor air temp.} < -10^{\circ}\text{C}$ ) ----- Outdoor heat exchanger temp. $\leq$ Outside air temp. $-7^{\circ}\text{C}$ or Outdoor heat exchanger temp. $\leq -30^{\circ}\text{C}$ (at outside air temp. $< -20^{\circ}\text{C}$ )

Integrating defrost	Compressor integrating operation time		
	More than 240 minutes (For continuous operation)	More than 213 minutes (For continuous operation)	Less than 10 minutes* ( For intermittent operation )
	Outdoor heat exchanger temperature below $-3^{\circ}\text{C}$	Outdoor heat exchanger temperature below $-5^{\circ}\text{C}$	OFF count of the compressor 40 times

\*If the compressor continuous operation time is less than 10 minutes,  
the OFF number of the compressor is counted.

If any defrost operated, the compressor OFF count is cleared.

### 2. CONDITION OF THE DEFROST OPERATION COMPLETION


Defrost operation is released when the conditions become as shown in Table 25 .

( Table 25 : Defrost release condition )

Release Condition
Outdoor heat exchanger temperature sensor value is higher than $16^{\circ}\text{C}$ or Compressor operation time has passed 15 minutes.

### 3. Defrost Flow Chart

The defrosting shall proceed by the integrating operation time, outdoor temperature and outdoor heat exchanger temperature as follows.



## 25. OFF DEFROST OPERATION CONTROL

When operation stops in the [Heating operation] mode, if frost is adhered to the outdoor unit heat exchanger, the defrost operation will proceed automatically. In this time, if indoor unit operation lamp flashes slowly (7 sec ON / 2 sec OFF), the outdoor unit will allow the heat exchanger to defrost, and then stop.

### 1. OFF DEFROST OPERATION CONDITION


In heating operation, the outdoor heat exchanger temperature is less than - 4°C, compressor continuous operation more than 10 minutes, and compressor operation integrating time lasts for more than 30 minutes.

### 2. OFF DEFROST END CONDITION

( Table 26 : OFF defrost release condition )

Release Condition
Outdoor heat exchanger temperature sensor value is higher than 16°C or Compressor operation time has passed 15 minutes.

### OFF Defrost Flow Chart



## 26. VARIOUS PROTECTIONS

### 1. DISCHARGE GAS TEMPERATURE OVERRISE PREVENION CONTROL

The discharge gas thermosensor (discharge thermistor : Outdoor side) will detect discharge gas temperature.

When the discharge temperature becomes higher than Temperature I, the compressor frequency is decreased 20rps, and it continues to decrease the frequency for 20rps every 120 seconds until the temperature becomes lower than Temperature I .

When the discharge temperature becomes lower than Temperature II, the protection control of the compressor frequency will be released.

When the discharge temperature becomes higher than Temperature III, the compressor is stopped and the indoor unit LED starts blinking.

( Table 27 : Discharge temperature over rise prevention control / Release temperature )

Temperature I	Temperature II	Temperature III
104°C	101°C	110°C

### 2. CURRENT RELEASE CONTROL

The compressor frequency is controlled so that the outdoor unit input current does not exceed the current limit value that was set up with the outdoor temperature.

The compressor frequency returns to the designated frequency of the indoor unit at the time when the frequency becomes lower than the release value.

( Table 28 : Current release operation value / Release value )

#### [ Heating ]

09 / 12LZCAN	
OT (Control / Release)	
17°C	$\frac{7.0A}{9.0A} / \frac{6.5A}{8.5A}$
12°C	$\frac{10.0A}{10.0A} / \frac{9.5A}{9.5A}$
5°C	$\frac{10.0A}{10.0A} / \frac{9.5A}{9.5A}$

OT : Outdoor Temperature

#### [ Heating ]

14LZCAN	
OT (Control / Release)	
17°C	$\frac{7.0A}{9.0A} / \frac{6.5A}{8.5A}$
12°C	$\frac{11.0A}{11.0A} / \frac{10.5A}{10.5A}$
5°C	$\frac{13.0A}{13.0A} / \frac{12.5A}{12.5A}$

OT : Outdoor Temperature

#### [ Cooling ]

09 / 12LZCAN	
OT (Control / Release)	
46°C	$\frac{4.5A}{6.0A} / \frac{4.0A}{5.5A}$
40°C	$\frac{8.5A}{8.5A} / \frac{8.0A}{8.0A}$

OT : Outdoor Temperature

#### [ Cooling ]

14LZCAN	
OT (Control / Release)	
46°C	$\frac{4.5A}{6.0A} / \frac{4.0A}{5.5A}$
40°C	$\frac{9.0A}{9.0A} / \frac{8.5A}{8.5A}$

OT : Outdoor Temperature

# ***WALL MOUNTED type INVERTER***

## 2 . TROUBLE SHOOTING



## 2-1 ERROR DISPLAY

### 2-1-1 INDOOR UNIT AND WIRED REMOTE CONTROLLER DISPLAY

Please refer the flashing pattern as follows.

Indoor Unit : 09/12/14LZCA


The OPERATION, TIMER and ECONOMY lamps operate as follows according to the error contents.

Error Contents	Indoor Unit Display			Wired Remote Controller Display	Trouble shooting
	OPERATION [ I ] (Green)	TIMER [ ⌚ ] (Orange)	ECONOMY [ ⌚ ] (Green)		
Serial Communication Error	1 times	1 times	Continuous	11	1
Wired Remote Controller Communication Error	1 times	2 times	Continuous	12	2
Indoor Unit Model Information Error EEPROM Access Abnormal	3 times	2 times	Continuous	32	3
Manual Auto Switch Error	3 times	5 times	Continuous	35	4
Indoor Room Thermistor Error	4 times	1 times	Continuous	41	5
Indoor Heat Ex.(Pipe) Thermistor Error	4 times	2 times	Continuous	42	6
Indoor Unit Fan Motor Error	5 times	1 times	Continuous	51	7
Outdoor Unit Main PCB Error	6 times	2 times	Continuous	62	8
PFC Circuit Error (9 / 12LZCAN) Active Filter Error (14LZCAN)	6 times	4 times	Continuous	64	9
IPM Error	6 times	5 times	Continuous	65	10
Discharge Thermistor Error	7 times	1 times	Continuous	71	11
Heat Ex. (Pipe) Thermistor Error	7 times	3 times	Continuous	73	12
Outdoor Thermistor Error	7 times	4 times	Continuous	74	13
Current Sensor Error	8 times	4 times	Continuous	84	14
Over Current Error	9 times	4 times	Continuous	94	15
Compressor Control Error	9 times	5 times	Continuous	95	16
Outdoor Unit Fan Motor Error	9 times	7 times	Continuous	97	17
4 Way Valve Error	9 times	9 times	Continuous	99	18
Discharge Temp. Error	10 times	1 times	Continuous	A1	19

## 2-1-2 WIRED REMOTE CONTROLLER DISPLAY ( OPTION )

### 1. SELF - DIAGNOSIS

When " Er " in Temperature Display is displayed, inspection of the air conditioning system is necessary. Please consult authorized service personnel.





ex. Self-diagnosis check

### 2. ERROR CODE HISTORY DISPLAY


Up to 16 memorized error codes may be displayed for the indoor unit connected to the remote controller.

1. Stop the air conditioner operation.

2. Press the SET TEMPERATURE buttons  $\nabla$ ,  $\blacktriangle$  simultaneously for 3 seconds or more to start the self-diagnosis.



3. Press the SET TEMPERATURE button to select the error history number.



$\left[ \begin{array}{cccccccc} 0 & \leftrightarrow & 1 & \leftrightarrow & 2 & \leftrightarrow & 3 & \leftrightarrow & 4 & \leftrightarrow & 5 & \leftrightarrow & 6 & \leftrightarrow & 7 \\ F & \leftrightarrow & E & \leftrightarrow & d & \leftrightarrow & c & \leftrightarrow & b & \leftrightarrow & A & \leftrightarrow & 9 & \leftrightarrow & 8 \end{array} \right]$

4. Press the SET TEMPERATURE buttons  $\nabla$ ,  $\blacktriangle$  simultaneously for 3 seconds or more or there is no key input for 60 seconds to stop the display.

## 2-2 TROUBLE SHOOTING WITH ERROR CODE

**Trouble shooting 1-1**  
**OUTDOOR UNIT Error Method:**  
**Serial Communication Error**  
**(Serial Reverse Transfer Error)**

**Indicate or Display:**

Outdoor Unit : No indication  
 Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 1 time Flash  
 Economy lamp: Continuous flash.  
 ERROR CODE : [E : 11]

**Detective Actuators:**

Outdoor unit Main PCB  
 Outdoor unit fan motor

**Detective details:**

When the indoor unit cannot receive the serial signal from Outdoor unit more than 2minutes after power ON, or the indoor unit cannot receive the serial signal more than 15seconds during normal operation.

**Forecast of Cause:**

1. Connection failure
2. External cause
3. Main PCB failure
4. Outdoor unit fan motor failure

Check Point 1-1 : Reset the power and operate

- Does Error indication show again?

YES

Check Point 2 : Check Connection

- Check any loose or removed connection line of Indoor unit and Outdoor unit.
- >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**

OK

Check Point 3 : Check the voltage of power supply


- Check the voltage of power supply
- >> **Check if AC207V (AC230V -10%) - 253V (AC230V +10%) appears at Outdoor Unit Terminal L - N.**



OK

Check Point 4 : Check Serial Signal (Reverse Transfer Signal)


- Check Serial Signal (Reverse Transfer Signal)
- >> **Check if Indicated value swings between AC90V and AC270V at Outdoor Unit Terminal 1 - 3.**
- >> **If it is abnormal, Check Outdoor unit fan motor. (PARTS INFORMATION 5)**
- >> **If Outdoor fan motor is abnormal, replace Outdoor unit fan motor and Main PCB.**
- >> **If Outdoor fan motor is normal, replace Main PCB.**



<p><b>Trouble shooting 1-2</b>  <b>INDOOR UNIT Error Method:</b>  <b>Serial Communication Error</b>  <b>(Serial Forward Transfer Error)</b></p>	<p><b>Indicate or Display:</b>  Outdoor Unit : No indication  Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 1 time Flash  Economy lamp: Continuous flash.  <b>ERROR CODE : [E : 11]</b></p>
---	---

<p><b>Detective Actuators:</b>  Indoor unit Controller PCB  Indoor unit Fan motor</p>	<p><b>Detective details:</b>  When the outdoor unit cannot receive the serial signal from Indoor unit more than 10seconds.</p>
---	--

**Forecast of Cause:**  
1. Connection failure    2. External cause    3. Controller PCB failure    4. Indoor unit fan motor failure




<b>Trouble shooting 2</b> <b>INDOOR UNIT Error Method:</b> <b>Wired Remote Controller</b> <b>Communication Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 12]</b>
---	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Wired remote control	<b>Detective details:</b> When the indoor unit cannot receive the signal from Wired Remote Control more than 1minute during normal operation.
---	--

<b>Forecast of Cause:</b> 1. Terminal connection abnormal    2. Wired remote control failure    3. Controller PCB failure
--

<b>Check Point 1 : Check the connection of terminal</b>
<u>After turning off the power, check &amp; correct the followings.</u> • Check the connection of terminal between remote control and Indoor unit, and check if there is a disconnection of the cable.




<b>Check Point 2 : Check Remote Control and Controller PCB</b>	
• Check Voltage at CN2 (terminal 1-3) of UTY-TWBXF (Communication kit). (Power supply to Remote Control) >> If it is DC 5V, Remote Control is failure. (Controller PCB is normal)                      >> Replace Remote Control >> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again) >> Replace Controller PCB ▶ <b><u>Upon correcting the removed connector or miss-wiring, reset the power.</u></b>	

<p><b>Trouble shooting 3</b>  <b>INDOOR UNIT Error Method:</b>  <b>Indoor Unit Model Information Error</b>  <b>EEPROM Access Abnormal</b></p>	<p><b>Indicate or Display:</b>  Outdoor Unit : No indication  Indoor Unit : Operation lamp: 3 time Flash, Timer lamp: 2 time Flash  Economy lamp: Continuous flash.  <b>ERROR CODE : [E : 32]</b></p>
---	---

<p><b>Detective Actuators:</b>  Indoor unit Controller PCB</p>	<p><b>Detective details:</b>  When power is on and there is some below case.  1. When model information of EEPROM is incorrect.  2. When the access to EEPROM failed.</p>
--	---

<p><b>Forecast of Cause:</b>  1. External cause    2. Defective connection of electric components    3. Controller PCB failure</p>
--




**Note : EEPROM**  
EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.

<b>Trouble shooting 4</b> <b>INDOOR UNIT Error Method:</b> <b>Manual Auto Switch Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 3 time Flash, Timer lamp: 5 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 35]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Indicator PCB Manual auto switch	<b>Detective details:</b> When the Manual Auto Switch becomes ON for consecutive 60 or more seconds.
--	---

**Forecast of Cause :**  
1. Manual auto switch failure    2. Controller PCB and Indicator PCB failure

<b>Check Point 1 : Check the Manual auto switch</b> <ul style="list-style-type: none"> <li>• Check if Manual auto switch is kept pressed.</li> <li>• Check ON/OFF switching operation by using a meter.</li> </ul> <b>&gt;&gt;If Manual Auto Switch is disabled (on/off switching), replace it.</b>	
--	--



<b>Check Point 2 : Replace Controller PCB</b>
<b>▶ If Check Point 1 do not improve the symptom, change Controller PCB and Indicator PCB.</b>

<b>Trouble shooting 5</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Room Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 4 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 41]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Room temperature thermistor	<b>Detective details:</b> When Room Temperature Thermistor open or short-circuit is detected.
--	--

Forecast of Cause :  
1. Connector connection failure 2. Thermistor failure 3. Controller PCB failure


**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**



Thermistor Characteristics (Approx. value)


Temperature (°C)	-10°C	-5°C	0°C	5°C	10°C	15°C	20°C	25°C
Resistance Value (kΩ)	58.2	44.0	33.6	25.9	20.2	15.8	12.5	10.0

Temperature (°C)	30°C	35°C	40°C	45°C
Resistance Value (kΩ)	8.0	6.5	5.3	4.4


**► If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**



Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)

THERMISTOR (PIPE) 	<table border="1" style="border-collapse: collapse;"> <tr> <td style="text-align: center;">BLACK</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> <td rowspan="4" style="vertical-align: middle; padding-left: 10px;">CN4</td> </tr> <tr> <td style="text-align: center;">BLACK</td> <td style="text-align: center;">2</td> <td style="text-align: center;">2</td> </tr> <tr> <td style="text-align: center;">BLACK</td> <td style="text-align: center;">3</td> <td style="text-align: center;">3</td> </tr> <tr> <td style="text-align: center;">BLACK</td> <td style="text-align: center;">4</td> <td style="text-align: center;">4</td> </tr> </table>	BLACK	1	1	CN4	BLACK	2	2	BLACK	3	3	BLACK	4	4
BLACK	1	1	CN4											
BLACK	2	2												
BLACK	3	3												
BLACK	4	4												

**► If the voltage does not appear, replace Controller PCB.**



<b>Trouble shooting 6</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Heat Ex.(Pipe)</b> <b>Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 4 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 42]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Heat Ex. temperature thermistor	<b>Detective details:</b> When Heat Ex. Temperature Thermistor open or short-circuit is detected.
--	--

**Forecast of Cause :**  
1. Connector connection failure    2. Thermistor failure    3. Controller PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Approx. value)

Temperature (°C)	-10°C	-5°C	0°C	5°C	10°C	20°C
Resistance Value (kΩ)	312.3	233.2	176.0	134.2	103.3	62.9

Temperature (°C)	30°C	40°C	50°C	60°C	63°C
Resistance Value (kΩ)	39.6	25.6	17.1	11.6	10.4

► **If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**

Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)

► **If the voltage does not appear, replace Controller PCB.**

<b>Trouble shooting 7</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Unit Fan Motor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 5 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 51]</b>
---	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Indoor unit Fan motor	<b>Detective details:</b> When the condition that actual frequency of Indoor Fan is below 1/3 of target frequency is continued more than 56 seconds.
--	---

<b>Forecast of Cause:</b> 1. Fan rotation failure    2. Fan motor winding open    3. Motor protection by surrounding temperature rise 4. Control PCB failure    5. Indoor unit fan motor failure
--

<b>Check Point 1 : Check rotation of Fan</b>
<ul style="list-style-type: none"> <li>· Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)</li> <li><b>&gt;&gt;If Fan or Bearing is abnormal, replace it.</b></li> </ul>

↓ **OK**

<b>Check Point 2 : Check ambient temp. around motor</b>
<ul style="list-style-type: none"> <li>· Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)</li> <li><b>&gt;&gt;Upon the temperature coming down, restart operation.</b></li> </ul>

↓ **OK**

<b>Check Point 3 : Check Indoor unit fan motor</b>
<ul style="list-style-type: none"> <li>· Check Indoor unit fan motor. (PARTS INFORMATION 4)</li> <li><b>&gt;&gt;If Indoor unit fan motor is abnormal, replace Indoor unit fan motor.</b></li> </ul>


↓ **OK**

<b>Check Point 4 : Replace Controller PCB</b>
<ul style="list-style-type: none"> <li><b>▶ If Check Point 1- 3 do not improve the symptom, replace Controller PCB.</b></li> </ul>

<b>Trouble shooting 8</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Main PCB Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 62]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> Access to EEPROM failed due to some cause after outdoor unit started.
--	--

Forecast of Cause:  
1. External cause (Noise, temporary open, voltage drop) 2. Main PCB failure



**For 09 / 12 LZCAN**

<p><b>Trouble shooting 9-1</b>  <b><u>OUTDOOR UNIT Error Method:</u></b>  <b>PFC Circuit Error</b></p>	<p><b><u>Indicate or Display:</u></b>  <b>Outdoor Unit : No indication</b>  <b>Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 4 time Flash</b>  <b>Economy lamp: Continuous flash.</b>  <b>ERROR CODE : [E : 64]</b></p>
--	---

<p><b><u>Detective Actuators:</u></b>          Outdoor unit Main PCB</p>	<p><b><u>Detective details:</u></b>          When inverter output DC voltage is higher than 415V for over 3 seconds, the compressor stops.          If the same operation is repeated 5 times, the compressor stops permanently.</p>
--	--

<p><b><u>Forecast of Cause :</u></b>          1. External cause    2. Connector connection failure    3. Main PCB failure</p>
---

<p><b>Check Point 1 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)</b></p>
<ul style="list-style-type: none"> <li>• Instant drop : Check if there is a large load electric apparatus in the same circuit.</li> <li>• Momentary power failure : Check if there is a defective contact or leak current in the power supply circuit.</li> <li>• Noise : Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)              Check the complete insulation of grounding.</li> </ul>



<p><b>Check Point 2 : Check connection of Connector</b></p>
<ul style="list-style-type: none"> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> <p><b>&gt;&gt;Upon correcting the removed connector or miss-wiring, reset the power.</b></p>



<p><b>Check Point 3 : Replace Main PCB</b></p>
<p><b>► <u>If Check Point 1, 2 do not improve the symptom, change Main PCB.</u></b></p>

**For 14LZCAN**

<p><b>Trouble shooting 9-2</b>  <b><u>OUTDOOR UNIT Error Method:</u></b>  <b>Active Filter Error</b></p>	<p><b><u>Indicate or Display:</u></b>                  Outdoor Unit : No indication                  Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 4 time Flash                  Economy lamp: Continuous flash.  <b>ERROR CODE : [E : 64]</b></p>
--	--

<p><b><u>Detective Actuators:</u></b>                  Outdoor unit Main PCB                  Active filter module</p>	<p><b><u>Detective details:</u></b>                  When inverter input DC voltage is higher than 425V or lower than 80V.                  When a momentary power cut off occurred on low voltage</p>
--	--

<p><b><u>Forecast of Cause :</u></b>                  1. External cause   2. Connector connection failure   3. Main PCB failure   4. Active filter module failure</p>
---

<p><b>Check Point 1 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)</b></p> <ul style="list-style-type: none"> <li>• Instant drop : Check if there is a large load electric apparatus in the same circuit.</li> <li>• Momentary power failure : Check if there is a defective contact or leak current in the power supply circuit.</li> <li>• Noise : Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave) Check the complete insulation of grounding.</li> </ul>
--



<p><b>Check Point 2 : Check connection of Connector</b></p> <ul style="list-style-type: none"> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> <p><b>&gt;&gt;Upon correcting the removed connector or miss-wiring, reset the power.</b></p>
---



<p><b>Check Point 3 : Check Active filter module</b></p> <ul style="list-style-type: none"> <li>• Check Active filter module. <b>(PARTS INFORMATION 6)</b></li> </ul> <p><b>&gt;&gt;If Active filter module is abnormal, replace it.</b></p>
--



<p><b>Check Point 4 : Replace Main PCB</b></p> <p><b>▶ If Check Point 1 - 3 do not improve the symptom, change Main PCB.</b></p>
--

<b>Trouble shooting 10</b> <b>OUTDOOR UNIT Error Method:</b> <b>IPM Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : No indication</b> <b>Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 5 time Flash</b> <b>Economy lamp: Continuous flash.</b> <b>ERROR CODE : [E : 65]</b>
---	---

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor unit Transistor PCB (14LZCAN) Compressor	<b>Detective details:</b> ① When more than normal operating current to IPM in Main PCB flows, the compressor stops. ② After the compressor restarts, if the same operation is repeated within 40sec, the compressor stops again. ③ If ① and ② repeats 5 times, the compressor stops permanently.
---	---

<b>Forecast of Cause :</b> 1. Defective connection of electric components 2. Outdoor Fan Operation failure 3. Outdoor Heat Exchanger clogged 4. Compressor failure 5. Main PCB failure 6. Transistor PCB failure (For 14LZCAN )
---

<b>Check Point 1 : Check connections of Outdoor Unit Electrical Components</b> <ul style="list-style-type: none"> <li>• Check if the terminal connection is loose.</li> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> <b>&gt;&gt; Upon correcting the removed connector or miss-wiring, reset the power.</b>
---



<b>Check Point 2 : Check Outdoor Fan, Heat Exchanger</b> <ul style="list-style-type: none"> <li>• Is there anything obstructing the air distribution circuit?</li> <li>• Is there any clogging of Outdoor Heat Exchanger?</li> <li>• Is the Fan rotating by hand when operation is off ?</li> </ul> <b>&gt;&gt; If the Fan Motor is locked, replace it.</b>
--



<b>Check Point 3 : Check Outdoor Fan</b> <ul style="list-style-type: none"> <li>• Check Outdoor Fan Motor. (Refer to Trouble shooting 17)</li> </ul> <b>&gt;&gt; If the Fan Motor is failure, replace it.</b>
--



<b>Check Point 4 : Check Compressor</b> <ul style="list-style-type: none"> <li>• Check Compressor. (PARTS INFORMATION 2)</li> </ul>
--



<b>Check Point 5 : Check Transistor PCB (For 14LZCAN )</b> <ul style="list-style-type: none"> <li>• Check Transistor PCB. (PARTS INFORMATION 7)</li> </ul>
---



<b>Check Point 6 : Replace Main PCB</b> <b>► If Check Point 1~ 5 do not improve the symptom, change Main PCB.</b>
--

<b>Trouble shooting 11</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 71]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Discharge pipe temperature thermistor	<b>Detective details:</b> When Discharge pipe temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
---	--

**Forecast of Cause :**  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value** Ω

Thermistor Characteristics (Approx. value)

Temperature (°C)	-10°C	-5°C	0°C	5°C	10°C	20°C	30°C	40°C	50°C
Resistance Value (kΩ)	292.9	221.1	168.6	129.8	100.9	62.5	40.0	26.3	17.8

Temperature (°C)	60°C	70°C	80°C	90°C	100°C	110°C	120°C
Resistance Value (kΩ)	12.3	8.7	6.3	4.6	3.4	2.6	2.0

► **If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Main PCB (DC5.0V)** DC

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

**09 / 12 LZCAN**

THERMISTOR (PIPE)	BLACK	1	1	CN71
	BLACK	2	2	
	BROWN	3	3	
	BROWN	4	4	
THERMISTOR (DISCHARGE)				
THERMISTOR (OUTDOOR)	BLACK	1	1	CN70
	BLACK	2	2	
	BLACK	3	3	

**14 LZCAN**

THERMISTOR (PIPE)	BLACK	1	1	CN61
	BLACK	2	2	
	BLACK	3	3	
	BLACK	4	4	
THERMISTOR (DISCHARGE)				
THERMISTOR (OUTDOOR)	BLACK	1	1	CN62
	BLACK	2	2	
	BLACK	3	3	

► **If the voltage does not appear, replace Main PCB.**

02-15

<b>Trouble shooting 12</b> <b>OUTDOOR UNIT Error Method:</b> <b>Heat Ex.(Pipe) Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 3 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 73]</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Heat exchanger thermistor	<b>Detective details:</b> When Heat exchanger temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
---	--

Forecast of Cause :  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Approx. value)

Temperature (°C)	-10°C	-5°C	0°C	5°C	10°C	20°C	30°C	40°C	50°C
Resistance Value (kΩ)	27.8	21.0	16.1	12.4	9.6	6.0	3.8	2.5	1.7

Temperature (°C)	60°C	70°C	80°C
Resistance Value (kΩ)	1.2	0.8	0.6

**► If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Main PCB (DC5.0V)**

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

**09 / 12 LZCAN**

THERMISTOR (PIPE)	BLACK	1	1	CN71
	BLACK	2	2	
	BROWN	3	3	
	BROWN	4	4	
THERMISTOR (DISCHARGE)				
THERMISTOR (OUTDOOR)	BLACK	1	1	CN70
	BLACK	2	2	
	BLACK	3	3	

**14LZCAN**

THERMISTOR (PIPE)	BLACK	1	1	CN61
	BLACK	2	2	
	BLACK	3	3	
	BLACK	4	4	
THERMISTOR (DISCHARGE)				
THERMISTOR (OUTDOOR)	BLACK	1	1	CN62
	BLACK	2	2	
	BLACK	3	3	

**► If the voltage does not appear, replace Main PCB.**

02-16



<b>Trouble shooting 13</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 74]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor thermistor	<b>Detective details:</b> When Outdoor temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
--	---

Forecast of Cause :  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure


**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>> Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**



Thermistor Characteristics (Approx. value)

Temperature (°C)	-20°C	-15°C	-10°C	-5°C	0°C	5°C	10°C	20°C	30°C
Resistance Value (kΩ)	115.2	84.2	62.3	46.6	35.2	26.9	20.7	12.6	8.0

Temperature (°C)	35°C	40°C	45°C	50°C	55°C
Resistance Value (kΩ)	6.4	5.2	4.2	3.5	2.8

► **If Thermistor is either open or shorted, replace it and reset the power.**




**Check Point 3 : Check voltage of Main PCB (DC5.0V)**




Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

**09/12 LZCAN**



**14 LZCAN**




► **If the voltage does not appear, replace Main PCB.**

<b>Trouble shooting 14</b> <b>OUTDOOR UNIT Error Method:</b> <b>Current Sensor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 8 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 84]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> When Input Current Sensor has detected 0A, while Inverter Compressor is operating at higher than 56rps, after 1minute upon starting the Compressor. (Except during the defrost operation)
--	--

<b>Forecast of Cause :</b> 1. Defective connection of electric components    2. External cause    3. Main PCB failure
--



<b>Trouble shooting 15</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Trip Detection</b>	<b><u>Indicate or Display:</u></b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 94]</b>
---	---

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB Compressor	<b><u>Detective details:</u></b> ▪ <b>"Protection stop</b> by overcurrent generation after inverter compressor start processing completed" generated consecutively 10 times. * The number of generations is reset if the start-up of the compressor succeeds.
---	---

<b><u>Forecast of Cause :</u></b> <ol style="list-style-type: none"> <li>1. Outdoor unit fan operation defective, foreign matter on hear exchanger, excessive rise of ambient temperature</li> <li>2. Main PCB failure</li> <li>3. Compressor failure (lock, winding short)</li> </ol>
--

<b>Check Point 1 : Check the outdoor unit fan operation, heat exchanger, ambient temperature</b>
<ul style="list-style-type: none"> <li>• No obstructions in air passages?</li> <li>• Heat exchange fins clogged</li> <li>• Outdoor unit fan motor check</li> <li>• Ambient temperature not raised by the effect of other heat sources?</li> <li>• Discharged air not sucked in?</li> </ul>



<b>Check Point 2 : Replace Main PCB</b>
<b>▶ <u>If Check Point 1 do not improve the symptom, change Main PCB.</u></b>



<b>Check Point 3 : Replace Compressor</b>
<b>▶ <u>If Check Point 2 do not improve the symptom, change Compressor.</u></b>

<b>Trouble shooting 16</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor Motor Control Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 5 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 95]</b>
--	--

<b>Detective Actuators:</b>  Outdoor unit Main PCB Compressor	<b>Detective details:</b>  ① If the detected rotor location is out of phase with actual rotor location more than 90°, the compressor stops. After the compressor restarts, if the same operation is repeated ② within 40sec, the compressor stops again. ③ If ① and ② repeats 5 times, the compressor stops permanently.
--	---

<b>Forecast of Cause :</b> 1. Defective connection of electric components    2. Main PCB failure    3. Compressor failure
--

Check Point 1 : Check Noise from Compressor

• Turn on Power and check operation noise.

▶ **If an abnormal noise show, replace Compressor.**



Check Point 2 : Check connection of around the Compressor components

For Compressor Terminal, Main PCB

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

(Refer to PARTS INFORMATION 2)

>>**Upon correcting the removed connector or miss-wiring, reset the power.**



Check Point 3 : Replace Main PCB

▶ **If Check Point 1,2 do not improve the symptom, change Main PCB.**



Check Point 4 : Replace Compressor

▶ **If Check Point 3 do not improve the symptom, change Compressor.**

<b>Trouble shooting 17</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Fan Motor Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : No indication</b> <b>Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 7 time Flash</b> <b>Economy lamp: Continuous flash.</b> <b>ERROR CODE : [E : 97]</b>
---	--

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB Outdoor unit Fan motor	<b><u>Detective details:</u></b> ① When outdoor fan rotation speed is less than 100rpm in 20 seconds after fan motor starts, fan motor stops. ② After fan motor restarts, if the same operation within 60sec is repeated 3 times in a row, compressor and fan motor stops. ③ If ① and ② repeats 5 times in a row, compressor and fan motor stops permanently.
---	--

<b><u>Forecast of Cause:</u></b> 1. Fan rotation failure   2. Motor protection by surrounding temperature rise   3. Main PCB failure 4. Outdoor unit fan motor
--

<b>Check Point 1 : Check rotation of Fan</b>
• Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor) <b>&gt;&gt;If Fan or Bearing is abnormal, replace it.</b>



<b>Check Point 2 : Check ambient temp. around motor</b>
• Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat) <b>&gt;&gt;Upon the temperature coming down, restart operation.</b>



<b>Check Point 3 : Check Outdoor unit fan motor</b>
• Check Outdoor unit fan motor. (PARTS INFORMATION 5) <b>&gt;&gt;If Outdoor unit fan motor is abnormal, replace Outdoor unit fan motor.</b>



<b>Check Point 4 : Check Output Voltage of Main PCB</b>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">DC</div> 						
• Check outdoor unit circuit diagram and the voltage. (Measure at Main PCB side connector)							
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Read wire</th> <th>DC voltage</th> </tr> </thead> <tbody> <tr> <td>Red - Black (Vm)</td> <td>240 - 400V</td> </tr> <tr> <td>White - Black (Vcc)</td> <td>13.5 - 16.5V</td> </tr> </tbody> </table>	Read wire	DC voltage	Red - Black (Vm)	240 - 400V	White - Black (Vcc)	13.5 - 16.5V
Read wire	DC voltage						
Red - Black (Vm)	240 - 400V						
White - Black (Vcc)	13.5 - 16.5V						
<b>▶ If the voltage is not correct, replace Main PCB.</b>							

<b>Trouble shooting 18</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>4-Way Valve Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : No indication</b> <b>Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 9 time Flash</b> <b>Economy lamp: Continuous flash.</b> <b>ERROR CODE : [E : 99]</b>
--	--

<b><u>Detective Actuators:</u></b> Indoor unit Controller PCB Heat Ex. temperature thermistor Room temperature thermistor 4-way valve Main PCB	<b><u>Detective details:</u></b> When the indoor heat exchanger temperature is compared with the room temperature, and either following condition is detected continuously two times, the compressor stops. <ul style="list-style-type: none"> <li>• Cooling or Dry operation              [Indoor heat exchanger temp.] - [Room temp.] &gt; 10°C</li> <li>• Heating operation              [Indoor heat exchanger temp.] - [room temp.] &lt; - 10°C</li> </ul> If the same operation is repeated 5 times, the compressor stops permanently.
---	---

**Forecast of Cause :**

1. Connector connection failure   2. Thermistor failure   3. Coil failure   4. 4-way valve failure  
 5. Main PCB failure   6. Controller PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>> Upon correcting the removed connector or mis-wiring, reset the power.**



**Check Point 2 : Check each thermistor**

- Isn't it fallen off the holder?
- Is there a cable pinched?

**>> Check characteristics of thermistor (Refer to Trouble shooting 5, 6),**  
**If defective, replace the thermistor**



**Check Point 3 : Check the solenoid coil and 4-way valve**

[ Solenoid coil ]

- Remove CN30 (For 9/12LZCAN) and CN500 (For 14LZCAN) from PCB and check the resistance value of coil. Resistance value is 1.88kΩ ~ 2.29kΩ at 20°C.

**>> If it is Open or abnormal resistance value, replace Solenoid Coil.**

[ 4-way valve ]

- Check each piping temperature, and the location of the valve by the temperature difference.

**>> If the value location is not proper, replace 4-way valve.**



**Check Point 4 : Check the voltage of 4-way valve**

- Check the voltage CN30 (For 09/12LZCAN) or CN500 (For 14LZCAN) of Main PCB.

**Check if AC207V (AC230V -10%) - 253V (AC230V +10%) appears at CN 30 or CN500 of Main PCB.**

[ Heating operation ]

**>> If it is not voltage, Replace Main PCB.**

[ Cooling operation ]

**>> If it is voltage, Replace Main PCB.**




**Check Point 5 : Replace Controller PCB**

**▶ If Check Point 1- 4 do not improve the symptom, replace Controller PCB.**

<b>Trouble shooting 19</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temperature Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 10 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : A1]</b>
---	---

<b>Detective Actuators:</b> Outdoor unit Main PCB Discharge temperature thermistor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "discharge temperature <math>\geq 110^{\circ}\text{C}</math> during compressor operation"" generated 2 times within 24 hours.</li> </ul>
--	--

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation failure, foreign matter on heat exchanger 4. Discharge temperature thermistor failure 5. Insufficient refrigerant 6. Main PCB failure
----------------------------	---



## 2-3 TROUBLE SHOOTING WITH NO ERROR CODE

### Trouble shooting 20

Indoor Unit - No Power

#### Forecast of Cause:

1. Power supply failure
2. External cause
3. Electrical components defective

#### Check Point 1 : Check Installation Condition

- Isn't the breaker down?
- Check loose or removed connection cable.
- >> **If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**



#### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.



#### Check Point 3 : Check Electrical Components



- Check the voltage of power supply.
- >> **Check if AC187 - 253V appears at Outdoor Unit Terminal L - N.**



- Check Fuse in Main PCB.
- >> **If Fuse is open, check if the wiring between Terminal and Main PCB is loose, and replace Fuse.**
- Check Varistor in Main PCB.
- >> **If Varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace Varistor. Upon checking the normal power supply, replace Varistor.**



## Trouble shooting 21

Outdoor Unit - No Power

### Forecast of Cause:

1. Power supply failure
2. External cause
3. Electrical Components defective

#### Check Point 1 : Check Installation Condition

- Isn't the breaker down?
  - Check loose or removed connection cable.
- >>If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**

↓  
**OK**

#### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.  
(Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.

↓  
**OK**

#### Check Point 3 : Check Electrical Components



- Check the voltage of power supply.
- >> Check if AC187 - 253V appears at Outdoor Unit Terminal L - N.**

↓  
**YES**

- Check Fuse in Main PCB.  
**>> If Fuse is open, check if the wiring between Terminal and Main PCB is loose, and replace Fuse.**
- Check Varistor in Main PCB.  
**>> If Varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace Varistor. Upon checking the normal power supply, replace Varistor.**

↓  
**OK**

▶ **If the symptom does not change by above Check 3, replace Main PCB.**

## Trouble shooting 22

No Operation (Power is ON)

### Forecast of Cause:

1. Setting/ Connection failure
2. External cause
3. Electrical component defective

### Check Point 1 : Check indoor and outdoor installation condition

- Indoor Unit - Check incorrect wiring between Indoor Unit - Remote Control.  
Or, check if there is an open cable connection.
- Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?  
**>> If there is some abnormal condition, correct it by referring to Installation manual and Data & Technical Manual.**

OK

Turn off Power and check/ correct followings.

- Is there loose or removed communication line of Indoor Unit and Outdoor Unit?

OK


### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.  
(Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.

OK

### Check Point 3 : Check Electrical Components at Indoor and Outdoor

- Check Voltage at CN2 (terminal 1-3) of UTY-TWBXF1(Communication kit).  
(Power supply to Remote Control)  
**>> If it is DC 5V, Remote Control is failure. (Controller PCB is normal) >> Replace Remote Control**  
**>> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again)**  
**>> Check Indoor unit fan motor. (PARTS INFORMATION 4)**  
**If it is normal, replace Controller PCB.**  
**If it is abnormal, replace Indoor unit fan motor and Controller PCB.**  
**>> If the symptom does not change by above Check 1, 2, 3, replace Main PCB of Outdoor unit.**



## Trouble shooting 23

No Cooling / No Heating

### Forecast of Cause:

1. Indoor Unit error
2. Outdoor Unit error
3. Effect by surrounding environment
4. Connection pipe / Connection wire failure
5. Refrigeration cycle failure

#### Check Point 1 : Check Indoor unit

- Does Indoor unit Fan run on High fan?
- Is Air filter dirty?
- Is Heat exchanger clogged?
- Check if Energy save function is operated.



#### Check Point 2 : Check Outdoor unit operation

- Check if Outdoor unit is operating
- Check any objects that obstruct the air flow route.
- Check clogged Heat Exchanger.
- Is the Valve open?



#### Check Point 3 : Check Site condition

- Is capacity of Indoor unit fitted to room size?
- Any windows open? or direct sunlight ?




#### Check Point 4 : Check Indoor / Outdoor installation condition

- Check connection pipe (specified pipe length & Pipe diameter?)
- Check any loose or removed communication line.
- >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**





#### Check Point 5 : Check Refrigeration cycle

- Check if Strainer is clogged (Refer to the figure at right).
- Measure Gas Pressure and if there is a leakage, correct it.
- >> **When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- Check EEV (PARTS INFORMATION 3)
- Check Compressor (PARTS INFORMATION 1,2)
- Check Heater Unit (PARTS INFORMATION 8)




### Attention

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference like shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.




**Trouble shooting 24**  
Abnormal Noise

Forecast of Cause :  
1. Abnormal installation (Indoor/ Outdoor)  
2. Fan failure (Indoor/ Outdoor)  
3. Compressor failure (Outdoor)



**Trouble shooting 25**  
Water Leaking

Forecast of Cause:  
1. Erroneous installation 2. Drain hose failure




## 2-4 SERVICE PARTS INFORMATION

### SERVICE PARTS INFORMATION 1

#### Compressor

Diagnosis method of Compressor ( If Outdoor Unit LED displays Error, refer to Trouble shooting )




## SERVICE PARTS INFORMATION 2

### Compressor



#### Check Point 1 : Check Connection

- Check terminal connection of Compressor (loose or incorrect wiring)



#### Check Point 2 : Check Winding Resistance

- Check winding resistance of each terminal  
▶ **If the resistance value is 0Ω or infinite, replace Compressor.**



- **09 / 12 LZCAN**  
Resistance Value :  
1.4Ω at 25°C
- **14 LZCAN**  
Resistance Value :  
0.7Ω at 25°C

#### Check Point 3 : Replace Main PCB


- ▶ **If the symptom does not change with above Check 1, 2, replace Main PCB.**

### SERVICE PARTS INFORMATION 3

Outdoor unit Electronic Expansion Valve (EEV)

#### Check Point 1 : Check Connections

- Check connection of connector (CN40 or CN700) (Loose connector or open cable)



#### Check Point 2 : Check Coil of EEV

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value
White - Red	$46 \Omega \pm 4 \Omega$ at 20°C
Yellow - Red	
Orange - Red	
Blue - Red	

► **If Resistance value is abnormal, replace EEV.**

#### Check Point 3 : Check Voltage from Main PCB.

- Remove Connector and check Voltage (DC12V)
- **If it does not appear, replace Main PCB.**



#### Check Point 4 : Check Noise at start up


- Turn on Power and check operation noise.
- **If an abnormal noise does not show, replace Main PCB.**

#### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed, it has a temp. difference between Inlet and Outlet.

**CLOSE**  
Example : Hot Gas


Pipe (In)  
Hi TEMP.



If it is open, it has no temp. difference between Inlet and Outlet.



**OPEN**  
Example : Hot Gas

Pipe (In)  
Hi TEMP.



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference as shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.



#### **SERVICE PARTS INFORMATION 4**

Indoor unit fan motor

##### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)

**>>If Fan or Bearing is abnormal, replace it.**

##### Check Point 2 : Check resistance of Indoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)

**>>If they are short-circuited (below 300 kΩ), replace Indoor fan motor and Controller PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Blue)	Feed back (FG)
2 (Yellow)	Speed command (Vsp)
3 (White)	Control voltage (Vcc)
4 (Black)	Earth terminal (GND)
5	No function
6 (Red)	DC voltage (Vm)

---

#### **SERVICE PARTS INFORMATION 5**

Outdoor unit fan motor

##### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)

**>>If Fan or Bearing is abnormal, replace it.**

##### Check Point 2 : Check resistance of Outdoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)

**>>If they are short-circuited (below 300 kΩ), replace Outdoor fan motor and Main PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Earth terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown)	Feed back (FG)



**For 14LZCAN**

**SERVICE PARTS INFORMATION 6**

Active filter module

**Check Point 1 : Check Open or Short-circuit and Diode (D1)**

· Remove connector, check the open or short-circuit and the diode in the module

Check the open or short-circuit

Table.1 Each type standard value

Terminal		Resistance value	
		Type A	Type B
multimeter (+)	multimeter (-)	SACT32010 [ HITACHI ] LACT33020 [ HITACHI ]	PM-604 [ FGEL ] PM-703 [ FGEL ]
		PM-601 [ FGEL ] <u>LOT No. - 1302931395</u>	PM-601 [ FGEL ] <u>LOT No. 1302931396 -</u>
+ (+IN)*	- (-IN)*	360kΩ ± 20%	360kΩ ± 20%
- (-IN)*	N1 (N)*	0 Ω	0 Ω
※ P	+ (+IN)*	720kΩ ± 20%	900kΩ ± 20%
L1	L2	1.01MΩ / 0.76MΩ (Ref. value 1) (Ref. value 2)	1.01MΩ / 0.76MΩ (Ref. value 1) (Ref. value 2)
P	N1 (N)*	360kΩ ± 20%	540kΩ ± 20%
L1 , L2	Control Box	∞ Ω	∞ Ω
※ L2	N1 (N)*	1.65MΩ / 1.14MΩ (Ref. value 1) (Ref. value 2)	1.65MΩ / 1.14MΩ (Ref. value 1) (Ref. value 2)

\* ( ) is FGEL terminal name.

Table.2 Standard value is changed by the tool specification  
(Type A and B are the same value)

Terminal		Resistance value
multimeter (+)	multimeter (-)	
※ L2	P	1.32MΩ / 0.66MΩ (Ref. value 1) (Ref. value 2)
※ P	L2	1.01MΩ / 0.76MΩ (Ref. value 1) (Ref. value 2)



※ By kind of multimeter , the value may change significantly.

Ref. value 1  
Specifications for Multimeter  
Manufacturer : FLUKE  
Model name : FLUKE11  
Power source : DC9V.

Ref. value 2  
Specifications for Multimeter  
Manufacturer : SANWA  
Model name : PM3  
Power source : DC3V.

► **If it is abnormal,replace ACTIVE FILTER MODULE**

**LOT No. of PM-601 [ FGEL ] type**



**Check Point 2 : Check the Output DC voltage (between P and N)**

· Check the Output DC voltage (between P and N) of compressor stopping and operating.

>> If the output voltage of compressor operating is less than the output voltage of compressor stopping, Active Filter Module is defective. >> **Replace Active Filter Module**


**For 14LZCAN**

**SERVICE PARTS INFORMATION 7**


IPM

(Mounted on Transistor PCB)

**Check Point 1 : Check the Transistor of PCB ( for Resistance )**




- ① Disconnect the connection wires between the Transistor PCB - Capacitor PCB and Transistor PCB - Inverter Compressor.
- ② Set the tester to the "Resistance" mode, and measure the resistance between the following terminals.  
 TM301 (P) - TM305(U) / TM304(V) / TM303(W)  
 TM302 (N) - TM305(U) / TM304(V) / TM303(W)
- ③ Judge the result of ② as follows:



Terminal		Resistance value
Tester(+)	Tester(-)	
P	U	Over 2kΩ (Including ∞Ω)
P	V	
P	W	
U	P	Over 20kΩ (Including ∞Ω)
V	P	
W	P	
N	U	
N	V	Over 2kΩ (Including ∞Ω)
N	W	
U	N	
V	N	Over 2kΩ (Including ∞Ω)
W	N	

**Check Point 2 : Check the Transistor of PCB ( for Diode )**



- ④ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.
- ⑤ Judge the result of ④ as follows:

Terminal		Tester display
Tester(+)	Tester(-)	
P	U	∞
P	V	
P	W	
U	P	0.3V ~ 0.7V
V	P	
W	P	
N	U	
N	V	∞
N	W	
U	N	
V	N	∞
W	N	


## SERVICE PARTS INFORMATION 8

### Heater Unit


#### Check Point 1 : Check Connections

- Check connection of connector  
( Loose connector or open cable )

##### 09 / 12 LZCAN



##### 14LZCAN



#### Check Point 2 : Check electrical components

- Check Check Fuses.  
 >> **If Fuse is open, check connection, and replace Fuse.**

#### Check Point 3 : Check Heater wire.

- Remove connector, check resistance of Heater wire.

Read wire	Resistance value
Black - White	321 ~ 368 Ω at 25°C

- ▶ **If Resistance value is abnormal, replace Heater Unit.**

### 3. ANTIFREEZING CONTROL (Cooling and Dry mode)

The compressor frequency is decrease on cooling & dry mode when the indoor heat exchanger temperature sensor detects the temperature lower than Temperature I .  
Then, the anti-freezing control is released when it becomes higher than Temperature II .

( Table 29 : Anti-freezing protection operation / Release temperature)

Outdoor temperature	Temperature I	Temperature II
Over than 10°C *1 or 12°C *2	4°C	7°C
Less than 10°C *1 or 12°C *2		13°C

\*1. When the temperature drops.

\*2. When the temperature rises.

### 4. COOLING PRESSURE OVERRISE PROTECTION

When the outdoor unit heat exchange sensor temperature rises to 67°C or greater, the compressor and the outdoor fan motor are stopped and trouble display is performed.

### 5. HIGH TEMPERATURE RELEASE CONTROL (Heating mode)

On heating mode, the compressor frequency is controlled as following based on the detection value of the indoor heat exchanger temperature sensor.

[ Control System ]

