

REFRIGERANT R32
INVERTER

AIR CONDITIONER

3-unit multi-split type

DESIGN & TECHNICAL MANUAL

INDOOR



AUXG07KVLA
AUXG09KVLA
AUXG12KVLA
AUXG14KVLA
AUXG18KVLA

ARXG07KSLAP
ARXG09KSLAP
ARXG12KSLAP
ARXG14KSLAP
ARXG18KSLAP

ARXG07KLLAP
ARXG09KLLAP
ARXG12KLLAP
ARXG14KLLAP
ARXG18KLLAP

ASYG07KGTB
ASYG09KGTB
ASYG12KGTB
ASYG14KGTB

ASYG18KMTB



ASYG07KMCC
ASYG09KMCC
ASYG12KMCC
ASYG14KMCC

ASYG07KETA
ASYG09KETA
ASYG12KETA
ASYG14KETA

ASYG07KETA-B
ASYG09KETA-B
ASYG12KETA-B
ASYG14KETA-B

ABYG18KRTA

AGYG09KVCA
AGYG12KVCA
AGYG14KVCA

OUTDOOR



AOYG18KBTB3
AOYG24KBTB3

FUJITSU GENERAL LIMITED

Notices:

- Product specifications and design are subject to change without notice for future improvement.
- For further details, please check with our authorized dealer.

Trademarks

FGLair™ is trademark of Fujitsu General Limited in the United States, other countries or both.

Google Play™ is trademark of Google Inc.

App Store® is a service mark of Apple Inc., registered in the U.S. and other countries.

CONTENTS

Part 1. INDOOR UNIT	1
1. Model lineup	2
1-1. Indoor unit connection patterns	3
2. Specifications	5
2-1. Compact cassette type	5
2-2. Mini duct type	7
2-3. Slim duct type	9
2-4. Wall mounted type	11
2-5. Ceiling type	15
2-6. Floor type	16
3. Dimensions	17
3-1. Compact cassette type	17
3-2. Mini duct type	19
3-3. Slim duct type	22
3-4. Wall mounted type	25
3-5. Ceiling type	33
3-6. Floor type	35
4. Wiring diagrams	37
4-1. Compact cassette type	37
4-2. Mini duct type and Slim duct type	38
4-3. Wall mounted type	39
4-4. Ceiling type	43
4-5. Floor type	44
5. Air velocity and temperature distributions	45
5-1. Compact cassette type	45
5-2. Mini duct type	52
5-3. Slim duct type	62
5-4. Wall mounted type	72
5-5. Ceiling type	75
5-6. Floor type	76
6. Fan performance	77
6-1. Mini duct type	77
6-2. Slim duct type	87
7. Airflow	97
7-1. Compact cassette type	97
7-2. Mini duct type	98
7-3. Slim duct type	99
7-4. Wall mounted type	100
7-5. Ceiling type	103
7-6. Floor type	104
8. Noise level curve	105

CONTENTS (continued)

8-1. Compact cassette type	105
8-2. Mini duct type.....	108
8-3. Slim duct type	111
8-4. Wall mounted type	114
8-5. Ceiling type	119
8-6. Floor type.....	120
8-7. Sound level check point	122
9. Electrical characteristics	125
10. Safety devices	126
11. External input and output.....	128
11-1.Compact cassette, Mini duct, and Slim duct types	128
11-2.Wall mounted type (Models: ASYG07KGTB, ASYG09KGTB, ASYG12KGTB, ASYG14KGTB, ASYG07KETA, ASYG09KETA, ASYG12KETA, ASYG14KETA, ASYG07KETA-B, ASYG09KETA-B, ASYG12KETA-B, and ASYG14KETA-B).....	134
11-3.Wall mounted type (Models: ASYG18KMTB, ASYG07KMCC, ASYG09KMCC, ASYG12KMCC, and ASYG14KMCC)	144
11-4.Ceiling type	149
11-5.Floor type	160
12. Group connection	169
13. Remote controller	171
13-1.Wireless remote controller (AR-REW4E, AR-REM4E, and AR-REB1E).....	171
13-2.Wireless remote controller (AR-REW2E)	175
13-3.Wireless remote controller (AR-REM7E).....	177
13-4.Wireless remote controller (UTY-LNTY: Optional part)	179
13-5.IR receiver kit with Wireless remote controller (UTY-LBTYM: Optional part)	181
13-6.Wired remote controller (UTY-RNNYM: Optional part).	184
13-7.Wired remote controller (UTY-RLRY: Optional part)	188
13-8.Wired remote controller (UTY-RVNYM: Optional part).....	191
13-9.Wired remote controller (UTY-RNRYZ*: Optional part).....	199
13-10.Simple remote controller (UTY-RSNYM: Optional part)	202
13-11.Simple remote controller (UTY-RSRY and UTY-RHRY: Optional parts).....	206
14. Function settings	209
14-1.Compact cassette, Mini duct, Slim duct types indoor unit (setting by DIP switch).....	209
14-2.Indoor unit (setting by wireless remote controller).....	211
14-3.Indoor unit (setting by wired remote controller)	228
14-4.Indoor unit (setting by simple remote controller)	239
14-5.Function details	246
14-6.Wired remote controller (UTY-RNNYM)	254
14-7.Wired remote controller (UTY-RVNYM)	256
14-8.Wired remote controller (UTY-RLRY)	257
14-9.Wired remote controller (UTY-RNRYZ*)	257
14-10.Simple remote controller (UTY-RSNYM).....	258
15. Accessories	259

CONTENTS (continued)

15-1.Compact cassette type	259
15-2.Mini duct type	260
15-3.Slim duct type	262
15-4.Wall mounted type	263
15-5.Ceiling type	266
15-6.Floor type	267
16. Optional parts	268
16-1.Controllers	268
16-2.Cassette grille	270
16-3.Others	271
17. Indoor unit installation precautions	275
17-1.Places where prohibited for use	275
17-2.Points to remember when installing	275

CONTENTS (continued)

Part 2. OUTDOOR UNIT (3 UNITS TYPE)	279
1. Specifications.....	280
2. Dimensions.....	282
2-1. Models: AOYG18KBTA3 and AOYG24KBTA3	282
3. Installation space	283
3-1. Models: AOYG18KBTA3 and AOYG24KBTA3	283
4. Refrigerant circuit	286
4-1. Models: AOYG18KBTA3 and AOYG24KBTA3	286
5. Wiring diagram	287
5-1. Models: AOYG18KBTA3 and AOYG24KBTA3	287
6. Capacity table.....	288
6-1. Combinations	288
6-2. Cooling capacity.....	292
6-3. Heating capacity	315
7. Capacity compensation rate for pipe length and height difference.....	338
7-1. Models: AOYG18KBTA3 and AOYG24KBTA3	338
8. Additional charge calculation	341
8-1. Model: AOYG18KBTA3	341
8-2. Model: AOYG24KBTA3	341
9. Airflow	342
9-1. Model: AOYG18KBTA3	342
9-2. Model: AOYG24KBTA3	342
10. Operation noise (sound pressure).....	343
10-1.Noise level curve.....	343
10-2.Sound level check point	344
11. Electrical characteristics	345
12. Safety devices	346
13. Function settings	347
13-1.Setting methods	347
13-2.Outdoor unit low noise operation function (option)	350
13-3.Changing the current limit function.....	350
14. Check and test.....	351
14-1.Check run	351
14-2.Test run.....	357
14-3.Error code	358
14-4.Pump down	361
15. Accessories	363
15-1.Model: AOYG18KBTA3	363
15-2.Model: AOYG24KBTA3	363

CONTENTS (continued)

16. Outdoor unit installation precautions	364
16-1.Places where prohibited for use	364
16-2.Points to remember when installing	364

Part 1. INDOOR UNIT

COMPACT CASSETTE TYPE: WALL MOUNTED TYPE:

AUXG07KVLA	ASYG07KGTB
AUXG09KVLA	ASYG09KGTB
AUXG12KVLA	ASYG12KGTB
AUXG14KVLA	ASYG14KGTB
AUXG18KVLA	ASYG18KMTB

SLIM DUCT TYPE:

ARXG07KLLAP	ASYG07KMCC
ARXG09KLLAP	ASYG09KMCC
ARXG12KLLAP	ASYG12KMCC
ARXG14KLLAP	ASYG14KMCC
ARXG18KLLAP	ASYG07KETA

MINI DUCT TYPE:

ARXG07KSLAP	ASYG09KETA
ARXG09KSLAP	ASYG12KETA
ARXG12KSLAP	ASYG14KETA
ARXG14KSLAP	ASYG07KETA-B
ARXG18KSLAP	ASYG09KETA-B

CEILING TYPE:

ABYG18KRTA

FLOOR TYPE:

AGYG09KVCA
AGYG12KVCA
AGYG14KVCA

1. Model lineup

Indoor unit			
	 	 	
AUXG07KVLA AUXG09KVLA AUXG12KVLA AUXG14KVLA AUXG18KVLA	ARXG07KSLAP ARXG09KSLAP ARXG12KSLAP ARXG14KSLAP ARXG18KSLAP	ARXG07KLLAP ARXG09KLLAP ARXG12KLLAP ARXG14KLLAP ARXG18KLLAP	ASYG07KGTB ASYG09KGTB ASYG12KGTB ASYG14KGTB
			
ASYG18KMTB	ASYG07KMCC ASYG09KMCC ASYG12KMCC ASYG14KMCC	ASYG07KETA ASYG09KETA ASYG12KETA ASYG14KETA	ASYG07KETA-B ASYG09KETA-B ASYG12KETA-B ASYG14KETA-B
			
ABYG18KRTA	AGYG09KVCA AGYG12KVCA AGYG14KVCA		

Outdoor unit
 AOYG18KBTA3 AOYG24KBTA3

1-1. Indoor unit connection patterns

■ 3-unit multi-split type

AOYG18KBTA3				
Combination no.	Unit 1	Unit 2	Unit 3	Total
1	7	7	—	14
2	7	9	—	16
3	7	12	—	19
4	7	14	—	21
5	9	9	—	18
6	9	12	—	21
7	9	14	—	23
8	12	12	—	24
9	12	14	—	26
10	14	14	—	28
11	7	7	7	21
12	7	7	9	23
13	7	7	12	26
14	7	7	14	28
15	7	9	9	25
16	7	9	12	28
17	7	9	14	30
18	9	9	9	27
19	9	9	12	30

Numbers in column Unit 1, 2, 3, and Total indicate the indoor unit capacities as follows:

7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h

AOYG24KBTA3

Combination no.	Unit 1	Unit 2	Unit 3	Total
1	7	7	—	14
2	7	9	—	16
3	7	12	—	19
4	7	14	—	21
5	7	18	—	25
6	9	9	—	18
7	9	12	—	21
8	9	14	—	23
9	9	18	—	27
10	12	12	—	24
11	12	14	—	26
12	12	18	—	30
13	14	14	—	28
13	14	18	—	32
14	7	7	7	21
15	7	7	9	23
16	7	7	12	26
17	7	7	14	28
18	7	7	18	32
19	7	9	9	25
20	7	9	12	28
21	7	9	14	30
22	7	9	18	34
23	7	12	12	31
25	7	12	14	33
26	7	14	14	35
27	9	9	9	27
28	9	9	12	30
29	9	9	14	32
30	9	9	18	36
31	9	12	12	33
32	9	12	14	35
33	12	12	12	36

Numbers in column Unit 1, 2, 3, and Total indicate the indoor unit capacities as follows:

7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h

2. Specifications

2-1. Compact cassette type

Model name				AUXG07KVLA	AUXG09KVLA	AUXG12KVLA	AUXG14KVLA									
Power supply				1Ø 230 V ~50 Hz												
Available voltage range				198—264 V												
Capacity		kW class		2.0	2.5	3.5	4.0									
Input power		W		18		23	28									
Running current		A		0.15		0.19	0.22									
Fan	Airflow rate	Cooling	HIGH	m³/h	540	610	680									
			MED		490	530	580									
			LOW		440	470	490									
			QUIET		390	410	410									
		Heating	HIGH		540	610	790									
			MED		490	530	680									
			LOW		440	470	580									
			QUIET		390	410	450									
Type × Q'ty				Turbo fan × 1												
Motor output				W	54											
Sound pressure level *	Cooling	HIGH		dB (A)	33	37	38									
			MED		31	34	35									
			LOW		29	31	32									
			QUIET		27	28	29									
		Heating	HIGH		34	37	43									
			MED		32	34	38									
			LOW		29	31	34									
			QUIET		27	29	30									
	Sound power level		Cooling	dB (A)	46	49	50									
			Heating		47	49	55									
Heat exchanger type	Dimensions (H × W × D)			mm	Main1: 210 × 1,310 × 13.3 Main2: 210 × 1,250 × 13.3											
	Fin pitch			mm	1.2											
	Rows × Stages				Main1: 1 × 10 Main2: 1 × 10											
	Pipe type				Copper tube											
	Fin type				Aluminum											
	Dimensions (H × W × D)		Net	mm	245 × 570 × 570											
			Gross		265 × 730 × 625											
Weight	Net		kg	15												
	Gross			19												
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)												
		Gas		Ø9.52 (Ø3/8)												
	Method			Flare												
	Material			PVC												
	Tip diameter			Ø25 (I.D.), Ø32 (O.D.)												
Operation range	Cooling			°C	18 to 32											
				%RH	80 or less											
	Heating			°C	16 to 30											
Cassette grille (Grid type: Option)	Model name			UTG-UFYF-W												
	Material			Polystyrene												
	Color			White												
				Approximate color of Munsell 9PB 9.1/0.2												
	Dimensions (H × W × D)	Net	mm	49 × 620 × 620												
		Gross		120 × 765 × 755												
	Weight	Net	kg	2.3												
		Gross		4.5												
NOTES:																
<ul style="list-style-type: none"> • The protective function might work when using it outside the operation range. • *: Sound pressure level: <ul style="list-style-type: none"> – These are the measured values in the manufacturer's anechoic chamber. – Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here. 																

Model name				AUXG18KVLA		
Power supply				1Ø 230 V ~50 Hz		
Available voltage range				198—264 V		
Capacity	kW class			5.0		
Input power	W			39		
Running current	A			0.30		
Fan	Airflow rate	Cooling	HIGH	680		
			MED	580		
			LOW	490		
			QUIET	410		
		Heating	HIGH	790		
			MED	680		
			LOW	580		
			QUIET	450		
Type × Q'ty				Turbo fan × 1		
Motor output				54		
Sound pressure level *	Cooling	dB (A)	HIGH	38		
			MED	35		
			LOW	32		
			QUIET	29		
		Heating	HIGH	43		
			MED	38		
			LOW	34		
			QUIET	30		
Sound power level				50		
Heating				55		
Heat exchanger type	Dimensions (H × W × D)		mm	Main1: 210 × 1,310 × 13.3		
	Fin pitch			Main2: 210 × 1,250 × 13.3		
	Rows × Stages			1.2		
	Pipe type			Copper tube		
	Fin type			Aluminum		
	Dimensions (H × W × D)		mm	245 × 570 × 570		
	Net			265 × 730 × 625		
	Gross					
	Weight		kg	15		
	Net			19		
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)		
		Gas		Ø12.70 (Ø1/2)		
	Method			Flare		
	Drain hose			PVC		
	Material			Ø25 (I.D.), Ø32 (O.D.)		
	Tip diameter		mm			
	Operation range	Cooling		18 to 32 °C		
		%RH		80 or less		
		Heating		16 to 30 °C		
Cassette grille (Grid type: Option)	Model name		UTG-UFYF-W			
	Material		Polystyrene			
	Color		White			
			Approximate color of Munsell 9PB 9.1/0.2			
	Dimensions (H × W × D)		mm	49 × 620 × 620		
	Net			120 × 765 × 755		
	Gross					
	Weight		kg	2.3		
	Net			4.5		
	Gross					

NOTES:

- The protective function might work when using it outside the operation range.
- *: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

2-2. Mini duct type

Model name			ARXG07KSLAP	ARXG09KSLAP	ARXG12KSLAP	ARXG14KSLAP		
Power supply			1Ø 230 V ~50 Hz					
Available voltage range			198—264 V					
Capacity		kW class	2.0	2.5	3.5	4.0		
Input power	Fan	W	33	40	47	72		
			23	23	26	44		
			20	20	22	30		
			18	18	18	18		
			A	0.29	0.33	0.38		
Running current						0.58		
Fan	Airflow rate	Cooling	550	600	650	800		
			440	450	490	640		
			390	400	430	530		
			360	360	360	360		
		Heating	550	600	650	800		
			440	450	490	640		
			390	400	430	530		
			360	360	360	360		
Type × Q'ty			Sirocco fan × 2					
Motor output			W	75				
Recommended static pressure			Pa	0 to 30		0 to 50		
Sound pressure level *	Cooling	dB (A)	HIGH	29	29	31		
			MED	26	26	27		
			LOW	24	24	25		
			QUIET	23	23	23		
	Heating		HIGH	29	29	31		
			MED	26	26	27		
			LOW	24	24	25		
			QUIET	23	23	23		
Sound power level		Cooling	dB (A)	52	54	55		
		Heating		53	56	57		
Heat exchanger type			Dimensions (H × W × D)	mm				
			Fin pitch	mm				
			Rows × Stages	2 × 16				
			Pipe type	Copper tube				
			Fin type	Aluminum				
Enclosure			Material	Steel sheet				
			Color	—				
Dimensions (H × W × D)		Net	mm	198 × 700 × 450				
		Gross		250 × 930 × 580				
Weight		Net	kg	15.5				
		Gross		19.0				
Connection pipe		Size	mm (in)	Ø6.35 (Ø1/4)				
		Gas		Ø9.52 (Ø3/8)				
Method				Flare				
Drain hose			Material	Hard PVC				
			Tip diameter	mm	Ø25 (I.D.), Ø32 (O.D.)			
					18 to 32			
Operation range			Cooling	%RH	80 or less			
			Heating		16 to 30			

NOTES:

- Values mentioned in the table are based on the following conditions:
 - Static pressure: 10 Pa
- The protective function might work when using it outside the operation range.
- *: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

Model name				ARXG18KSLAP			
Power supply				1Ø 230 V ~ 50 Hz			
Available voltage range				198—264 V			
Capacity				5.0			
Input power	Fan		HIGH	W	63		
			MED		38		
			LOW		22		
			QUIET		19		
Running current				A	0.49		
Fan	Airflow rate	Cooling	HIGH	m³/h	940		
			MED		750		
			LOW		540		
			QUIET		480		
		Heating	HIGH		940		
			MED		750		
			LOW		540		
			QUIET		480		
Type x Q'ty				Sirocco fan x 3			
Motor output				W	80		
Recommended static pressure				Pa	0 to 50		
Sound pressure level *		Cooling	HIGH	dB (A)	33		
			MED		29		
			LOW		26		
			QUIET		23		
		Heating	HIGH		33		
			MED		29		
			LOW		26		
			QUIET		23		
Sound power level		Cooling	dB (A)	58			
		Heating	dB (A)	59			
Heat exchanger type	Dimensions (H × W × D)		mm	336 × 690 × 26.6			
	Fin pitch			1.30			
	Rows x Stages		2 × 16				
	Pipe type		Copper tube				
Enclosure		Fin type	Aluminum				
		Material	Steel sheet				
		Color	—				
Dimensions (H × W × D)	Net		mm	198 × 900 × 450			
	Gross			250 × 1,130 × 580			
Weight	Net		kg	18.5			
	Gross			23.0			
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)			
		Gas		Ø12.7 (Ø1/2)			
Method		Flare					
Drain hose		PVC					
Operation range	Tip diameter		mm	Ø25 (I.D.), Ø32 (O.D.)			
	Cooling		°C	18 to 32			
	Heating		%RH	80 or less			
		°C		16 to 30			

NOTES:

- Values mentioned in the table are based on the following conditions:
 - Static pressure: 15 Pa
- The protective function might work when using it outside the operation range.
- *: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

2-3. Slim duct type

Model name				ARXG07KLLAP	ARXG09KLLAP	ARXG12KLLAP	ARXG14KLLAP			
Power supply				1Ø 230 V ~50 Hz						
Available voltage range				198–264 V						
Capacity		kW class	2.0	2.5	3.5	4.0				
Input power		W	33	49	58	76				
Running current		A	0.33	0.30	0.35	0.51				
Fan	Airflow rate	Cooling	HIGH	550	600	650	800			
			MED	490	550	600	700			
			LOW	470	500	550	600			
			QUIET	440	450	480	480			
		Heating	HIGH	550	600	650	800			
			MED	490	550	600	700			
			LOW	470	500	550	600			
			QUIET	440	450	480	480			
Type × Q'ty				Sirocco fan × 2						
Motor output		W	80	81						
Recommended static pressure		Pa		0 to 90						
Sound pressure level *	Cooling	dB (A)	HIGH	28	28	29	32			
			MED	26	27	28	30			
			LOW	25	26	27	28			
			QUIET	24	25	26	26			
		Heating	HIGH	28	28	29	32			
			MED	26	26	28	30			
			LOW	25	25	27	28			
			QUIET	24	24	24	25			
Sound power level		Cooling		57	58	60				
		Heating		57	58	60				
Heat exchanger type	Dimensions (H × W × D)		mm	294 × 500 × 26.6	294 × 500 × 39.9					
	Fin pitch		mm		1.3					
	Rows × Stages			2 × 14	3 × 14					
	Pipe type				Copper tube					
Fin type					Aluminum					
Enclosure	Material				Steel sheet					
	Color				—					
Dimensions (H × W × D)	Net		mm	198 × 700 × 620						
	Gross			276 × 968 × 772						
Weight	Net		kg	16	17					
	Gross			21	22					
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)						
		Gas		Ø9.52 (Ø3/8)						
Method				Flare						
Drain hose	Material			PVC						
	Tip diameter		mm	Ø25 (I.D.), Ø32 (O.D.)						
Operation range	Cooling		°C	18 to 32						
			%RH	80 or less						
Heating			°C	16 to 30						

NOTES:

- Values mentioned in the table are based on the following conditions:
 - Static pressure: 25 Pa
 - The protective function might work when using it outside the operation range.
 - *: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

Model name				ARXG18KLLAP				
Power supply				1Ø 230 V ~50 Hz				
Available voltage range				198—264 V				
Capacity	kW class			5.0				
Input power	W			73				
Running current	A			0.44				
Fan	Airflow rate	Cooling	HIGH	940				
			MED	880				
			LOW	820				
			QUIET	750				
		Heating	HIGH	940				
			MED	880				
			LOW	820				
			QUIET	750				
Type × Q'ty				Sirocco fan × 3				
Motor output				81				
Recommended static pressure				0 to 90				
Sound pressure level *	Cooling	dB (A)	HIGH	32				
			MED	30				
			LOW	29				
			QUIET	27				
	Heating		HIGH	32				
			MED	30				
			LOW	29				
			QUIET	27				
Sound power level				58				
Heat exchanger type				58				
Dimensions (H × W × D)				294 × 700 × 39.9				
Fin pitch				mm				
Rows × Stages				1.3				
Pipe type				3 × 14				
Fin type				Copper tube				
Enclosure				Aluminum				
Material				Steel sheet				
Color				—				
Dimensions (H × W × D)	Net		mm	198 × 900 × 620				
	Gross			276 × 1,168 × 772				
Weight	Net		kg	20				
	Gross			26				
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)				
		Gas		Ø12.70 (Ø1/2)				
Drain hose	Method			Flare				
	Material			PVC				
Tip diameter				Ø25 (I.D.), Ø32 (O.D.)				
Operation range	Cooling		°C	mm				
	Heating		%RH	18 to 32				
				80 or less				
				16 to 30				

NOTES:

- Values mentioned in the table are based on the following conditions:
 - Static pressure: 25 Pa
- The protective function might work when using it outside the operation range.
- *: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

2-4. Wall mounted type

Model name				ASYG07KGTB	ASYG09KGTB	ASYG12KGTB	ASYG14KGTB		
Power supply				1Ø 230 V ~50 Hz					
Available voltage range				198–264 V					
Capacity		kW class	2.0	2.5	3.5	4.0			
Input power		W	23	27	27	33			
Running current		A	0.20	0.24	0.24	0.29			
Fan	Airflow rate	Cooling	HIGH	650	700	700	770		
			MED	540	560	560	600		
			LOW	430	430	430	450		
			QUIET	270	270	270	280		
		Heating	HIGH	720	750	770	800		
			MED	580	610	640	660		
			LOW	460	470	520	520		
			QUIET	330	330	330	340		
Type × Q'ty				Crossflow fan × 1					
Motor output		W	30		49				
Sound pressure level *1	Cooling	HIGH	38	40	40	43			
			33	34	35	36			
			29	29	30	30			
			21	21	21	21			
		Heating	HIGH	41	42	42	44		
			MED	35	36	38	39		
			LOW	31	31	33	33		
			QUIET	22	22	22	24		
Sound power level		dB (A)	54	55	56	57			
			56	57	58	59			
Heat exchanger type	Dimensions (H × W × D)		mm	Main1: 210 × 670 × 26.6 Main2: 112 × 670 × 20.0	Main1: 210 × 670 × 26.6, Main2: 112 × 670 × 20.0 Sub: 84 × 670 × 13.3				
	Fin pitch		mm	Main1: 1.2, Main2: 1.1	Main1: 1.2, Main2: 1.1, Sub: 1.4				
	Rows × Stages		Main1: 2 × 10, Main2: 2 × 7		Main1: 2 × 10, Main2: 2 × 7, Sub: 1 × 4				
	Pipe type		Copper tube						
	Fin type		Aluminum						
Enclosure	Material		Polystyrene						
	Color		White + Pearl white (painted) Approximate color of Munsell N 9.25/						
Dimensions (H × W × D)	Net		mm	270 × 834 × 215					
	Gross			277 × 914 × 332					
Weight	Net		kg	10.0					
	Gross			12.5					
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)					
		Gas		Ø9.52 (Ø3/8)					
	Method			Flare					
Drain hose		Material		PP + HDPE					
		Tip diameter		Ø13.8 (I.D.), Ø15.0 to Ø16.8 (O.D.)					
Operation range	Cooling	°C		18 to 32					
		%RH		80 or less					
		Heating		16 to 30					
Remote controller type				Wireless (Option: Wired, Mobile app*2 [FGLair™])					

NOTES:

- The protective function might work when using it outside the operation range.
- *1: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- *2: Available on Google Play™ store or on App Store®. Optional WLAN adapter is also required. For details, refer to the setting manual.

Model name			ASYG18KMTB		
Power supply			1Ø 230 V ~50 Hz		
Available voltage range			198—264 V		
Capacity	kW class		5.0		
Input power	W		37.5		
Running current	A		0.35		
Fan	Airflow rate	Cooling	HIGH	980	
			MED	810	
			LOW	640	
			QUIET	510	
		Heating	HIGH	1,020	
			MED	850	
			LOW	640	
			QUIET	510	
	Type × Q'ty		Crossflow fan × 1		
Sound pressure level *1	Motor output	W		59	
		Cooling	HIGH	45	
			MED	40	
			LOW	35	
		Heating	QUIET	29	
			HIGH	46	
			MED	40	
			LOW	35	
			QUIET	29	
Sound power level	Cooling	dB (A)		60	
	Heating			61	
Heat exchanger type	Dimensions (H × W × D)		mm	Main1: 210 × 798 × 26.6 Main2: 135 × 798 × 20.0 Sub1: 84 × 798 × 13.3 Sub2: 84 × 798 × 13.3	
	Fin pitch		mm	Main1: 1.2, Main2: 1.1 Sub1: 1.4, Sub2: 1.4	
	Rows × Stages			Main1: 2 × 10 Main2: 2 × 8 Sub1: 1 × 4 Sub2: 1 × 4	
	Pipe type			Copper tube	
	Fin type			Aluminum	
	Material			Polystyrene	
	Color			White Approximate color of Munsell N 9.25/	
	Net	mm		280 × 980 × 240	
	Gross			322 × 1,078 × 346	
Weight	Net	kg		12.5	
	Gross			18	
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)	
		Gas		12.7 (Ø1/2)	
	Method			Flare	
Drain hose	Material			PP + HDPE	
	Tip diameter	mm		Ø13.8 (I.D.), Ø15.8 to Ø16.7 (O.D.)	
Operation range	Cooling	°C		18 to 32	
		%RH		80 or less	
	Heating	°C		16 to 30	
Remote controller type			Wireless (Option: Wired, Mobile app*2 [FGLair™])		

NOTES:

- The protective function might work when using it outside the operation range.
- *1: Sound pressure level:
— These are the measured values in the manufacturer's anechoic chamber.
— Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- *2: Available on Google Play™ store or on App Store®. Optional WLAN adapter is also required. For details, refer to the setting manual.

Model name			ASYG07KMCC	ASYG09KMCC	ASYG12KMCC	ASYG14KMCC				
Power supply			1Ø 230 V ~50 Hz							
Available voltage range			198—264 V							
Capacity	kW class	2.0	2.5	3.5	4.0					
Input power	W	23	27	27	33					
Running current	A	0.20	0.24	0.24	0.30					
Fan	Airflow rate	HIGH	650	700	700	770				
		MED	540	560	560	600				
		LOW	430	430	430	450				
		QUIET	320	320	320	310				
		HIGH	720	750	780	820				
	Heating	MED	580	610	640	660				
		LOW	460	470	520	520				
		QUIET	330	330	330	340				
Type × Q'ty	Crossflow fan × 1									
Motor output	W	27								
Sound pressure level *1	Cooling	HIGH	38	40	40	43				
		MED	33	34	35	36				
		LOW	29	29	30	30				
		QUIET	21	21	21	21				
		HIGH	41	42	42	44				
	Heating	MED	35	36	38	39				
		LOW	31	31	33	33				
		QUIET	22	22	22	24				
	dB (A)									
Heat exchanger type	Dimensions (H × W × D)		mm	Main1: 210 × 670 × 26.6 Main2: 112 × 670 × 20						
	Fin pitch			Man1: 1.2, Main2: 1.1						
	Rows × Stages		Main1: 2 × 10, Main2: 2 × 7			Main1: 2 × 10, Main2: 2 × 7, Sub: 1 × 4				
	Pipe type		Copper tube							
	Fin type		Aluminum							
	Material		Polystyrene							
	Color		White + Pearl white (painted) Approximate color of Munsell N 9.25/							
	Dimensions (H × W × D)	Net	mm	270 × 834 × 222			Main1: 210 × 670 × 26.6 Main2: 112 × 670 × 20 Sub: 84 × 670 × 13.3			
		Gross		277 × 914 × 332						
Weight	Net	kg	10.0							
	Gross		12.5							
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)			13.0			
		Gas		Ø9.52 (Ø3/8)						
Method			Flare							
Drain hose			PP + HDPE							
Tip diameter			Ø13.8 (I.D.), Ø15.0 to Ø16.8 (O.D.)							
Operation range	Cooling		°C	18 to 32						
				80 or less						
	Heating		°C	16 to 30						
Remote controller type			Wireless (Wired, Mobile app*2 [FGLair™] [option])							

NOTES:

- The protective function might work when using it outside the operation range.
- *1: Sound pressure level:
 - These are the measured values in the manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- *2: Available on Google Play™ store or on App Store®. Optional WLAN adapter is also required. For details, refer to the setting manual.

Model name			ASYG07KETA ASYG07KETA-B	ASYG09KETA ASYG09KETA-B	ASYG12KETA ASYG12KETA-B	ASYG14KETA ASYG14KETA-B	
Power supply			1Ø 230 V ~50 Hz				
Available voltage range			198–264 V				
Capacity			kW class	2.0	2.5	3.5	
Input power			W	23	27	33	
Running current			A	0.20	0.24	0.30	
Fan	Airflow rate	Cooling	m³/h	650	700	770	
				540	560	600	
				430	430	450	
		QUIET		270	270	280	
		Heating		720	750	800	
				580	610	660	
				460	470	520	
		QUIET		330	330	340	
Type × Q'ty			Crossflow fan × 1				
Motor output			W	30		49	
Sound pressure level *1	Cooling	HIGH	dB (A)	38	40	43	
		MED		33	34	36	
		LOW		29	29	30	
		QUIET		21	21	21	
		Heating		41	42	44	
				35	36	39	
				31	31	33	
		QUIET		22	22	24	
Sound power level			dB (A)	54	55	57	
Heating				56	57	59	
Heat exchanger type	Dimensions (H × W × D)		mm	Main1: 210 × 670 × 26.6 Main2: 112 × 670 × 20.0		Main1: 210 × 670 × 26.6 Main2: 112 × 670 × 20.0 Sub: 84 × 670 × 13.3	
	Fin pitch		mm	Main1: 1.2, Main2: 1.1		Main1: 1.2, Main2: 1.1 Sub: 1.4	
	Rows × Stages			Main1: 2 × 10, Main2: 2 × 7		Main1: 2 × 10 Main2: 2 × 7 Sub: 1 × 4	
	Pipe type			Copper tube			
	Fin type			Aluminum			
	Material			Polystyrene			
Enclosure	Color			KETA; White + Pearl white (painted) Approximate color of Munsell N 9.25/			
				KETA-B; Dark Gray + Silver (painted) Approximate color of Munsell 0.5P 3.5/0.2			
Dimensions (H × W × D)	Net		mm	295 × 950 × 230			
	Gross			284 × 1,027 × 357			
Weight	Net		kg	11.0		11.5	
	Gross			14.5		15.0	
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)			
		Gas		Ø9.52 (Ø3/8)			
Method				Flare			
Drain hose				PP + HDPE			
Material				Ø13.8 (I.D.), Ø15.0 to Ø16.8 (O.D.)			
Operation range	Cooling	Tip diameter	mm	18 to 32			
		%RH		80 or less			
		°C		16 to 30			
Remote controller type				Wireless (Option: Wired, Mobile app*2 [FGLair™])			

NOTES:

- The protective function might work when using it outside the operation range.
- *1: Sound pressure level:
– These are the measured values in the manufacturer's anechoic chamber.
– Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- *2: Available on Google Play™ store or on App Store®. Optional WLAN adapter is also required. For details, refer to the setting manual.

2-5. Ceiling type

Model name				ABYG18KRTA			
Power supply				1Ø 230 V ~50 Hz			
Available voltage range				198—264 V			
Capacity		kW class		5.0			
Input power		W		37			
Running current		A		0.21			
Fan	Airflow rate	Cooling	HIGH	m³/h	840		
			MED		790		
			LOW		710		
			QUIET		650		
		Heating	HIGH		840		
			MED		790		
			LOW		710		
			QUIET		650		
Type × Q'ty				Sirocco × 2			
Motor output				50			
Sound pressure level *		Cooling	HIGH	dB (A)	38		
			MED		36		
			LOW		33		
			QUIET		31		
		Heating	HIGH		38		
			MED		36		
			LOW		33		
			QUIET		31		
Heat exchanger type	Dimensions (H × W × D)		mm	294 × 715 × 39.9			
	Fin pitch		mm	1.30			
	Rows × Stages			3 × 14			
	Pipe type			Copper			
	Fin type			Aluminum			
Enclosure	Material				Steel sheet		
	Color				White Approximate color of Munsell N9.25/		
Dimensions (H × W × D)	Net		mm	235 × 1,080 × 705			
	Gross			330 × 1,165 × 825			
Weight	Net		kg	24			
	Gross			33			
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)			
		Gas		Ø12.70 (Ø1/2)			
Drain hose	Method				Flare		
	Material				PVC		
	Tip diameter		mm	Ø25 (I.D.), Ø32 (O.D.)			
Operation range		Cooling	°C	18 to 32			
			%RH	80 or less			
		Heating	°C	16 to 30			
Remote controller type				Wired remote controller, Wireless remote controller, Mobile app*3 (FGLair™)			

NOTES:

- Specifications are based on the following conditions:
 - Cooling: Indoor temperature of 27 °CDB/19 °CWB, and outdoor temperature of 35 °CDB/24 °CWB.
 - Heating: Indoor temperature of 20 °CDB/15 °CWB, and outdoor temperature of 7 °CDB/6 °CWB.
 - Pipe length: 5 m, Height difference: 0 m. (Between outdoor unit and indoor unit.)
 - Protective function might work when using it outside the operation range.
 - *: Sound pressure level:
 - Measured values in manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.

2-6. Floor type

Model name				AGYG09KVCA	AGYG12KVCA	AGYG14KVCA			
Power supply				230 V ~ 50 Hz					
Available voltage range				198–264 V					
Capacity				2.5	3.5	4.0			
Input power				W	16	20			
Running current				A	0.15	0.18			
Fan	Airflow rate	Cooling	HIGH	m³/h	530	600			
			MED		440	490			
			LOW		360	380			
			QUIET		270	270			
		Heating	HIGH		530	600			
			MED		460	510			
			LOW		380	410			
			QUIET		270	270			
Type × Q'ty				Cross flow fan × 2					
Motor output				W	16 × 2				
Sound pressure level *	Cooling	HIGH	dB (A)	39	42	44			
				34	36	38			
				28	30	31			
				22	22	22			
		Heating		39	42	44			
				35	38	39			
				30	32	33			
				22	22	22			
Sound power level		Cooling	dB (A)	52	55	56			
		Heating		52	55	56			
Heat exchanger type	Dimensions (H × W × D)		mm	378 × 550 × 26.6					
	Fin pitch			1.2					
	Rows × Stages		2 × 18						
	Pipe type		Copper tube						
	Fin type		Aluminum						
Enclosure		Material	Polystyrene						
		Color	White						
Dimensions (H × W × D)		Net	mm	600 × 740 × 200					
		Gross		700 × 820 × 310					
Weight		Net	kg	14					
		Gross		18					
Connection pipe	Size	Liquid	mm (in)	Ø6.35 (Ø1/4)					
		Gas		Ø9.52 (Ø3/8)					
	Method		Flare						
Drain hose		Material	PP + LLDPE						
		Tip diameter	mm	Ø13.8 (I.D.), Ø15.8 to Ø16.7 (O.D.)					
Operation range	Cooling	°C	18 to 32						
		%RH	80 or less						
	Heating	°C	30 or less						
Remote controller type				Wireless (Wired, Simple mobile app [option])					

NOTES:

- Specifications are based on the following conditions:
 - Cooling: Indoor temperature of 27 °CDB/19 °CWB, and outdoor temperature of 35 °CDB/24 °CWB.
 - Heating: Indoor temperature of 20 °CDB/15 °CWB, and outdoor temperature of 7 °CDB/6 °CWB.
 - Pipe length: 5 m, Height difference: 0 m. (Between outdoor unit and indoor unit.)
- Protective function might work when using it outside the operation range.
- *: Sound pressure level:
 - Measured values in manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.


3. Dimensions

3-1. Compact cassette type




■ Models: AUXG07KVLA, AUXG09KVLA, AUXG12KVLA, AUXG14KVLA, and AUXG18KVLA

Unit: mm

Grid type grille



View A



A

View B

C


View C

a: Ceiling openings

Cassette grille (Option [Grid type])	mm	580 to 610
--------------------------------------	----	------------

● Installation space requirement


Unit: mm

**Maximum height from floor to ceiling (Unit: mm)**

	07 and 09 models	12 or larger models
Standard		2,700
High ceiling	—	3,000

3-way direction setting:

Unit: mm









NOTES:

- To set “3-direction”, optional Air outlet shutter plate (UTR-YDZB) must be installed, and the “outlet-direction” need to be switched to “3-way” by remote controller.
- *When installing the indoor unit, be careful about the maintenance space.
- In 3-way outlet mode, changing of ceiling height setting by function setting 20 is prohibited. (Ceiling height setting [function setting 20] is allowed to be changed only in 4-way outlet mode.)

3-2. Mini duct type


■ Models: ARXG07KSLAP, ARXG09KSLAP, ARXG12KSLAP, and ARXG14KSLAP

Unit: mm




■ Model: ARXG18KSLAP


Unit: mm




Rear view




View A




Top view



Side view



Front view




Bottom view

● Installation space requirement


Provide sufficient installation space for product safety.

Unit: mm




*: 400 or more when drain from drain pipe

- When intaking air from back:



- When intaking air from bottom:




● Maintenance space requirement

For future maintenance and service access, provide sufficient maintenance space.

NOTE: Do not place any wiring or illumination in the maintenance space, as they will impede service.

Unit: mm




Top view

3-3. Slim duct type


■ Models: ARXG07KLLAP, ARXG09KLLAP, ARXG12KLLAP, and ARXG14KLLAP

Unit: mm





■ Model: ARXG18KLLAP

Unit: mm




Rear view




Top view


Drain port



Side view



Front view




Bottom view

● Installation space requirement

Provide sufficient installation space for product safety.


In ceiling-concealed installations:



● Maintenance space requirement

For future maintenance and service access, provide sufficient maintenance space.


NOTE: Do not place any wiring or illumination in the maintenance space, as they will impede service.



3-4. Wall mounted type

■ Models: ASYG07KGTB, ASYG09KGTB, ASYG12KGTB, and ASYG14KGTB



Unit: mm



● Installation space requirement




Provide sufficient installation space for product safety.

Unit: mm



■ Model: ASYG18KMTB



Unit: mm



● Installation space requirement


Provide sufficient installation space for product safety.

Unit: mm



■ Models: ASYG07KMCC, ASYG09KMCC, ASYG12KMCC, and
ASYG14KMCC



Unit: mm



● Installation space requirement


Provide sufficient installation space for product safety.

Unit: mm



■ Models: ASYG07KETA, ASYG09KETA, ASYG12KETA,
ASYG14KETA, ASYG07KETA-B, ASYG09KETA-B,
ASYG12KETA-B, and ASYG14KETA-B



Unit: mm



● Installation space requirement

Provide sufficient installation space for product safety.


Unit: mm




3-5. Ceiling type

■ Model: ABYG18KRTA


Unit: mm



Top view




Rear view



■ Installation space requirement

Unit: mm




Required ceiling height varies according to the ceiling mode setting of function setting No. 20.

Ceiling height (m)		
Ceiling mode	Standard	High ceiling
18 model	2.7	3.5

3-6. Floor type

■ Models: AGYG09KVCA, AGYG12KVCA, and AGYG14KVCA


Unit: mm



Front view

Side view

● Installation space



⚠ WARNING

- The appliance shall be installed, operated and stored in a room with a floor area larger than X m².


Amount of refrigerant charge M (kg)	Minimum room area X (m²)
M ≤ 1.22	-
1.22 < M ≤ 1.23	12.99
1.23 < M ≤ 1.50	19.31
1.50 < M ≤ 1.75	26.28
1.75 < M ≤ 2.0	34.33
2.0 < M ≤ 2.5	53.63
2.5 < M ≤ 3.0	77.23
3.0 < M ≤ 3.5	105.12
3.5 < M ≤ 4.0	137.29

(IEC 60335-2-40)

4. Wiring diagrams


4-1. Compact cassette type

■ Models: AUXG07KVLA, AUXG09KVLA, AUXG12KVLA, AUXG14KVLA, and AUXG18KVLA




4-2. Mini duct type and Slim duct type

■ Models: ARXG07KSLAP, ARXG09KSLAP, ARXG12KSLAP, ARXG14KSLAP, ARXG18KSLAP, ARXG07KLLAP, ARXG09KLLAP, ARXG12KLLAP, ARXG14KLLAP, and ARXG18KLLAP




4-3. Wall mounted type


■ Models: ASYG07KGTB, ASYG09KGTB, ASYG12KGTB, and ASYG14KGTB




■ Model: ASYG18KMTB



■ Models: ASYG07KMCC, ASYG09KMCC, ASYG12KMCC, and ASYG14KMCC




■ Models: ASYG07KETA, ASYG09KETA, ASYG12KETA,
ASYG14KETA, ASYG07KETA-B, ASYG09KETA-B,
ASYG12KETA-B, and ASYG14KETA-B




4-4. Ceiling type

■ Model: ABYG18KRTA



4-5. Floor type

■ Models: AGYG09KVCA, AGYG12KVCA, and AGYG14KVCA





5. Air velocity and temperature distributions

5-1. Compact cassette type

■ Models: AUXG07KVLA and AUXG09KVLA

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------


Side view
Vertical airflow direction louver: down



- Air temperature distribution

Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------



Side view
Vertical airflow direction louver: down



■ Model: AUXG12KVLA

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------


Side view
Vertical airflow direction louver: down



- Air temperature distribution

Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------



Side view
Vertical airflow direction louver: down



■ Model: AUXG14KVLA

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------


Side view
Vertical airflow direction louver: down



- Air temperature distribution




Measuring conditions NOTE: Reference data	Fan speed HIGH	Operation mode HEAT	Outlet directions 4-way air outlet
---	-------------------	------------------------	---------------------------------------

Side view
Vertical airflow direction louver: down



■ Model: AUXG18KVLA

Measuring conditions	Fan speed	Operation mode	Ceiling mode
	HIGH	FAN	STANDARD






5-2. Mini duct type

■ Model: ARXG07KSLAP

NOTE: This data is measured after installing optional Auto louver grille kit.


- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	FAN




- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT




■ Model: ARXG09KSLAP

NOTE: This data is measured after installing optional Auto louver grille kit.

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center






■ Model: ARXG12KSLAP

NOTE: This data is measured after installing optional Auto louver grille kit.

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center






■ Model: ARXG14KSLAP

NOTE: This data is measured after installing optional Auto louver grille kit.


- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	




- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT




■ Model: ARXG18KSLAP


NOTE: This data is measured after installing optional Auto louver grille kit.

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center



Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Left & Right




Side view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center

- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center






5-3. Slim duct type

■ Model: ARXG07KLLAP

NOTE: This data is measured after installing optional Auto louver grille kit.


- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	FAN




- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT




■ Model: ARXG09KLLAP

NOTE: This data is measured after installing optional Auto louver grille kit.

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center






■ Model: ARXG12KLLAP

NOTE: This data is measured after installing optional Auto louver grille kit.

- Air velocity distribution


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center






■ Model: ARXG14KLLAP

NOTE: This data is measured after installing optional Auto louver grille kit.


- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	




- Air velocity distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT



- Air temperature distribution

Measuring conditions	Fan speed	Operation mode
	HIGH	HEAT




■ Model: ARXG18KLLAP

NOTE: This data is measured installing the Auto louver grille kit (option).


Measuring conditions	Fan speed HIGH	Operation mode FAN
----------------------	-------------------	-----------------------

- Air velocity distribution


Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center



Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Left & Right




Side view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center



Measuring conditions	Fan speed HIGH	Operation mode HEAT
----------------------	-------------------	------------------------


- Air velocity distribution

Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



- Air temperature distribution


Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center




5-4. Wall mounted type

■ Models: **ASYG07KGTB, ASYG09KGTB, ASYG07KMCC, ASYG09KMCC, ASYG12KMCC, ASYG07KETA, ASYG09KETA, ASYG12KETA, ASYG07KETA-B, ASYG09KETA-B, and ASYG12KETA-B**


Measuring conditions	Fan speed	Operation mode
	HIGH	FAN



■ Model: ASYG18KMTB

■ Models: **ASYG12KGTB, ASYG14KGTB, ASYG14KMTB,
ASYG14KMCC, ASYG14KETA, and ASYG14KETA-B**

Measuring conditions	Fan speed HIGH	Operation mode FAN
----------------------	-------------------	-----------------------




5-5. Ceiling type


■ Model: ABYG18KRTA

Measuring conditions	Fan speed	Operation mode
	HIGH	FAN


Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center



Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Left & Right



Side view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center



Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center




5-6. Floor type


■ Models: AGYG09KVCA, AGYG12KVCA, and AGYG14KVCA

Measuring conditions	Fan speed	Operation mode	Fan select
	HIGH	FAN	Upper and lower


Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center




Top view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Left & Right



Side view
Vertical airflow direction louver: Up
Horizontal airflow direction louver: Center




Side view
Vertical airflow direction louver: Down
Horizontal airflow direction louver: Center



6. Fan performance

6-1. Mini duct type

■ Model: ARXG07KSLAP




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling



- Heating




■ Model: ARXG09KSLAP




● Characteristics of air volume and capacity


- Cooling



- Heating



■ Model: ARXG12KSLAP




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity



- Cooling



- Heating



■ Model: ARXG14KSLAP




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling




- Heating



■ Model: ARXG18KSLAP



Available airflow rate range (High level)




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity

- Cooling




- Heating



6-2. Slim duct type

■ Model: ARXG07KLLAP




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling



- Heating



■ Model: ARXG09KLLAP




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling




- Heating



■ Model: ARXG12KLLAP



Available airflow rate range (High level)




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling




- Heating



■ Model: ARXG14KLLAP



Available airflow rate range (High level)




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity


- Cooling




- Heating



■ Model: ARXG18KLLAP



Available airflow rate range (High level)




*1: Available airflow rate range when Auto louver grille (option) is installed.

Fan speed: HIGH


Vertical airflow direction louver: Up

● Characteristics of air volume and capacity

- Cooling



- Heating



7. Airflow

Conversion factor:

- $1 \text{ m}^3/\text{h} = 0.2778 \text{ l/s} = 0.5886 \text{ CFM}$
- $3.6 \text{ m}^3/\text{h} = 1 \text{ l/s}$
- $1.699 \text{ m}^3/\text{h} = 1 \text{ CFM}$

7-1. Compact cassette type

Model	Operation mode	Fan speed	Airflow		
			m^3/h	l/s	CFM
AUXG07KVLA AUXG09KVLA	Cooling	High	540	150	318
		Med	490	136	288
		Low	440	122	259
		Quiet	390	108	230
	Heating	High	540	150	318
		Med	490	136	288
		Low	440	122	259
		Quiet	390	108	230
AUXG12KVLA	Cooling	High	610	169	359
		Med	530	147	312
		Low	470	131	277
		Quiet	410	114	241
	Heating	High	610	169	359
		Med	530	147	312
		Low	470	131	277
		Quiet	410	114	241
AUXG14KVLA	Cooling	High	680	189	400
		Med	580	161	341
		Low	490	136	288
		Quiet	410	114	241
	Heating	High	790	219	465
		Med	680	189	400
		Low	580	161	341
		Quiet	450	125	265
AUXG18KVLA	Cooling	High	680	189	400
		Med	580	161	341
		Low	490	136	288
		Quiet	410	114	241
	Heating	High	790	219	465
		Med	680	189	400
		Low	580	161	341
		Quiet	450	125	265

7-2. Mini duct type

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
ARXG07KSLAP	Cooling	High	550	153	324
		Med	440	122	259
		Low	390	108	230
		Quiet	360	100	212
	Heating	High	550	153	324
		Med	550	122	259
		Low	390	108	230
		Quiet	360	100	212
ARXG09KSLAP	Cooling	High	600	167	353
		Med	450	125	265
		Low	400	111	235
		Quiet	360	100	212
	Heating	High	600	167	353
		Med	450	125	265
		Low	400	111	235
		Quiet	360	100	212
ARXG12KSLAP	Cooling	High	650	181	383
		Med	490	136	288
		Low	430	119	253
		Quiet	360	100	212
	Heating	High	650	181	383
		Med	490	136	288
		Low	430	119	253
		Quiet	360	100	212
ARXG14KSLAP	Cooling	High	800	222	471
		Med	640	178	377
		Low	530	147	312
		Quiet	360	100	212
	Heating	High	800	222	471
		Med	640	178	377
		Low	530	147	312
		Quiet	360	100	212
ARXG18KSLAP	Cooling	High	940	261	553
		Med	750	208	441
		Low	540	150	318
		Quiet	480	133	283
	Heating	High	940	261	553
		Med	750	208	441
		Low	540	150	318
		Quiet	480	133	283

7-3. Slim duct type

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
ARXG07KLLAP	Cooling	High	550	153	324
		Med	490	136	288
		Low	470	131	277
		Quiet	440	122	259
	Heating	High	550	153	324
		Med	490	136	288
		Low	470	131	277
		Quiet	440	122	259
ARXG09KLLAP	Cooling	High	600	167	353
		Med	550	153	324
		Low	500	139	294
		Quiet	450	125	265
	Heating	High	600	167	353
		Med	550	153	324
		Low	500	139	294
		Quiet	450	125	265
ARXG12KLLAP	Cooling	High	650	181	383
		Med	600	167	353
		Low	550	153	324
		Quiet	480	133	283
	Heating	High	650	181	383
		Med	600	167	353
		Low	550	153	324
		Quiet	480	133	283
ARXG14KLLAP	Cooling	High	800	222	471
		Med	700	194	412
		Low	600	167	353
		Quiet	480	133	283
	Heating	High	800	222	471
		Med	700	194	412
		Low	600	167	353
		Quiet	480	133	283
ARXG18KLLAP	Cooling	High	940	261	553
		Med	880	244	518
		Low	820	228	483
		Quiet	750	208	441
	Heating	High	940	261	553
		Med	880	244	518
		Low	820	228	483
		Quiet	750	208	441

7-4. Wall mounted type

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	I/s	CFM
ASYG07KGTB	Cooling	High	650	181	383
		Med	540	150	318
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	720	200	424
		Med	580	161	341
		Low	460	128	271
		Quiet	330	92	194
ASYG09KGTB	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	750	208	441
		Med	610	169	359
		Low	470	131	277
		Quiet	330	92	194
ASYG12KGTB	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	770	214	453
		Med	640	178	377
		Low	520	144	306
		Quiet	330	92	194
ASYG14KGTB	Cooling	High	770	214	453
		Med	600	167	353
		Low	450	125	265
		Quiet	280	78	165
	Heating	High	800	222	471
		Med	660	183	388
		Low	520	144	306
		Quiet	340	94	200
ASYG18KMTB	Cooling	High	980	272	577
		Med	810	225	477
		Low	640	178	377
		Quiet	510	142	300
	Heating	High	1,020	283	600
		Med	850	236	500
		Low	640	178	377
		Quiet	510	142	300
ASYG07KMCC	Cooling	High	650	181	383
		Med	540	150	318
		Low	430	119	253
		Quiet	320	89	188
	Heating	High	720	200	424
		Med	580	161	341
		Low	460	128	271
		Quiet	330	92	194

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
ASYG09KMCC	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	320	89	188
	Heating	High	750	208	441
		Med	610	169	359
		Low	470	131	277
		Quiet	330	92	194
ASYG12KMCC	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	320	89	188
	Heating	High	780	217	459
		Med	640	178	377
		Low	520	144	306
		Quiet	330	92	194
ASYG14KMCC	Cooling	High	770	214	453
		Med	600	167	353
		Low	450	125	265
		Quiet	310	86	182
	Heating	High	820	228	483
		Med	660	183	388
		Low	520	144	306
		Quiet	340	94	200
ASYG07KETA ASYG07KETA-B	Cooling	High	650	181	383
		Med	540	150	318
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	720	200	424
		Med	580	161	341
		Low	460	128	271
		Quiet	330	92	194
ASYG09KETA ASYG09KETA-B	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	750	208	441
		Med	610	169	359
		Low	470	131	277
		Quiet	330	92	194
ASYG12KETA ASYG12KETA-B	Cooling	High	700	194	412
		Med	560	156	330
		Low	430	119	253
		Quiet	270	75	159
	Heating	High	770	214	453
		Med	640	178	377
		Low	520	144	306
		Quiet	330	92	194

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
ASYG14KETA ASYG14KETA-B	Cooling	High	770	214	453
		Med	600	167	353
		Low	450	125	265
		Quiet	280	78	165
	Heating	High	800	222	471
		Med	660	183	388
		Low	520	144	306
		Quiet	340	94	200

7-5. Ceiling type

Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
ABYG18KRTA	Cooling	High	840	233	494
		Med	790	219	465
		Low	710	197	418
		Quiet	650	181	383
	Heating	High	840	233	494
		Med	790	219	465
		Low	710	197	418
		Quiet	650	181	383

7-6. Floor type


Model	Operation mode	Fan speed	Airflow		
			m ³ /h	l/s	CFM
AGYG09KVCA	Cooling	High	530	147	312
		Med	440	111	235
		Low	360	100	212
		Quiet	270	75	159
	Heating	High	530	147	312
		Med	460	128	271
		Low	380	106	224
		Quiet	270	75	159
AGYG12KVCA	Cooling	High	600	167	353
		Med	490	136	288
		Low	380	106	224
		Quiet	270	75	159
	Heating	High	600	167	353
		Med	510	142	300
		Low	410	114	241
		Quiet	270	75	159
AGYG14KVCA	Cooling	High	650	181	383
		Med	520	144	306
		Low	400	131	277
		Quiet	270	75	159
	Heating	High	650	181	383
		Med	540	150	318
		Low	430	119	253
		Quiet	270	75	159

8. Noise level curve


8-1. Compact cassette type

■ Model: AUXG07KVLA

● Cooling




● Heating








■ Model: AUXG09KVLA

● Cooling




● Heating




■ Model: AUXG12KVLA**● Cooling****● Heating****■ Model: AUXG14KVLA****● Cooling****● Heating**

■ Model: AUXG18KVLA

● Cooling




● Heating




8-2. Mini duct type

■ Model: ARXG07KSLAP

● Cooling




● Heating








■ Model: ARXG09KSLAP

● Cooling




● Heating




■ Model: ARXG12KSLAP**● Cooling****● Heating****■ Model: ARXG14KSLAP****● Cooling****● Heating**

■ Model: ARXG18KSLAP

● Cooling




● Heating




8-3. Slim duct type

■ Model: ARXG07KLLAP

● Cooling




● Heating








■ Model: ARXG09KLLAP



● Cooling



● Heating




■ Model: ARXG12KLLAP**● Cooling****● Heating****■ Model: ARXG14KLLAP****● Cooling****● Heating**

■ Model: ARXG18KLLAP**● Cooling****● Heating**


8-4. Wall mounted type

■ Model: ASYG07KGTB

● Cooling




● Heating








■ Model: ASYG09KGTB





● Cooling



● Heating




■ Model: ASYG12KGTB**● Cooling****● Heating****■ Model: ASYG14KGTB****● Cooling****● Heating**


■ Model: ASYG18KMTB**● Cooling****● Heating****■ Models: ASYG07KMCC, ASYG07KETA, and ASYG07KETA-B****● Cooling****● Heating**

■ Models: ASYG09KMCC, ASYG09KETA, and ASYG09KETA-B

● Cooling




● Heating




■ Models: ASYG12KMCC, ASYG12KETA, and ASYG12KETA-B

● Cooling




● Heating




■ Models: ASYG14KMCC, ASYG14KETA, and ASYG14KETA-B

● Cooling




● Heating




8-5. Ceiling type

■ Model: ABYG18KRTA

● Cooling




● Heating




8-6. Floor type

■ Model: AGYG09KVCA

● Cooling




● Heating




■ Model: AGYG12KVCA

● Cooling




● Heating




■ Model: AGYG14KVCA

● Cooling





● Heating




8-7. Sound level check point


■ Compact cassette type




■ Mini duct type



■ Slim duct type




■ Wall mounted type




NOTE: Detailed shape of the actual indoor unit might be slightly different from the one illustrated above.

■ Ceiling type



■ Floor type



9. Electrical characteristics

		Power supply (50 Hz, 230 V)	Indoor rated		Wiring spec. of connection cable (Indoor unit to outdoor unit)	
Type	Model name	MCA	Input power	FLA	Cross-sectional area	Limited wiring length
		(A)	(W)	(A)	(mm ²)	(m)
Compact cassette	AUXG07KVLA	0.19	18	0.15	1.5	26
	AUXG09KVLA	0.19	18	0.15		
	AUXG12KVLA	0.24	23	0.19		
	AUXG14KVLA	0.28	28	0.22		
	AUXG18KVLA	0.38	39	0.30		
Mini duct	ARXG07KSLAP	0.33	33	0.29	1.5	26
	ARXG09KSLAP	0.38	40	0.33		
	ARXG12KSLAP	0.42	47	0.38		
	ARXG14KSLAP	0.67	72	0.58		
	ARXG18KSLAP	0.61	63	0.49		
Slim duct	ARXG07KLLAP	0.41	33	0.33	1.5	26
	ARXG09KLLAP	0.38	49	0.30		
	ARXG12KLLAP	0.44	58	0.35		
	ARXG14KLLAP	0.64	76	0.51		
	ARXG18KLLAP	0.55	73	0.44		
Wall mounted	ASYG07KGTB	0.25	23	0.20	1.5	26
	ASYG09KGTB	0.30	27	0.24		
	ASYG12KGTB	0.30	27	0.24		
	ASYG14KGTB	0.37	33	0.29		
	ASYG18KMTB	0.44	38	0.35		
	ASYG07KMCC	0.25	23	0.20		
	ASYG09KMCC	0.30	27	0.24		
	ASYG12KMCC	0.30	27	0.24		
	ASYG14KMCC	0.38	33	0.30		
	ASYG07KETA	0.25	23	0.20		
	ASYG07KETA-B		23	0.20		
	ASYG09KETA	0.30	27	0.24		
	ASYG09KETA-B		27	0.24		
	ASYG12KETA	0.30	27	0.24		
	ASYG12KETA-B		27	0.24		
	ASYG14KETA	0.38	33	0.30		
	ASYG14KETA-B		33	0.30		
Ceiling	ABYG18KRTA	0.39	37	0.21		
Floor	AGYG09KVCA	0.19	16	0.15		
	AGYG12KVCA	0.23	20	0.18		
	AGYG14KVCA	0.25	23	0.20		

MCA: Minimum Circuit Ampacity = Maximum operating current (Full load)

FLA: Full Load Amperes (Fan motor)

10. Safety devices

Indoor unit type	Model name	PCB* fuse	Fan motor thermal protector	Terminal thermal fuse	Float switch	
Compact cassette	AUXG07KVLA	250 V, 5 A	Activate: $100 \pm 15^\circ\text{C}$ Fan motor stop Reset: $95 \pm 10^\circ\text{C}$ Fan motor restart	—	○	
	AUXG09KVLA					
	AUXG12KVLA					
	AUXG14KVLA					
	AUXG18KVLA					
Mini duct	ARXG07KSLAP	250 V, 5 A	Activate: $135 \pm 15^\circ\text{C}$ Fan motor stop Reset: $105 \pm 15^\circ\text{C}$ Fan motor restart	—	○	
	ARXG09KSLAP					
	ARXG12KSLAP					
	ARXG14KSLAP					
	ARXG18KSLAP					
Slim duct	ARXG07KLLAP	250 V, 5 A	Activate: $135 \pm 15^\circ\text{C}$ Fan motor stop Reset: $115 \pm 15^\circ\text{C}$ Fan motor restart	—	○	
	ARXG09KLLAP					
	ARXG12KLLAP					
	ARXG14KLLAP					
	ARXG18KLLAP					
Wall mounted	ASYG07KGTB	250 V, 3.15 A	Activate: $110 \pm 15^\circ\text{C}$ Fan motor speed down Reset: $110 \pm 15^\circ\text{C}$ Fan motor speed recover	102°C Off	—	
	ASYG09KGTB					
	ASYG12KGTB					
	ASYG14KGTB					
	ASYG18KMTB		Activate: $125 \pm 10^\circ\text{C}$ Fan motor stop Reset: $100 \pm 10^\circ\text{C}$ Fan motor restart	—		
	ASYG07KMCC					
	ASYG09KMCC					
	ASYG12KMCC					
	ASYG14KMCC		Activate: $125 \pm 24^\circ\text{C}$ Fan motor stop Reset: $100 \pm 25^\circ\text{C}$ Fan motor restart	—		
	ASYG07KETA					
	ASYG07KETA-B					
	ASYG09KETA					
	ASYG09KETA-B		Activate: $110 \pm 15^\circ\text{C}$ Fan motor speed down Reset: $110 \pm 15^\circ\text{C}$ Fan motor speed recover	102°C Off		
	ASYG12KETA					
	ASYG12KETA-B					
	ASYG14KETA					
	ASYG14KETA-B					

Indoor unit type	Model name	PCB* fuse	Fan motor thermal protector	Terminal thermal fuse	Float switch
Ceiling	ABYG18KRTA		Activate: $135 \pm 15^\circ\text{C}$ Fan motor stop Reset: $105 \pm 15^\circ\text{C}$ Fan motor restart	108°C Off	—
Floor	AGYG09KVCA	250 V, 3.15 A	Activate: $150 \pm 15^\circ\text{C}$ Fan motor stop Reset: $120 \pm 15^\circ\text{C}$ Fan motor restart	110°C Off	—
	AGYG12KVCA				
	AGYG14KVCA				


*: Printed Circuit Board

11. External input and output


11-1. Compact cassette, Mini duct, and Slim duct types

Exterior of the indoor unit PCB and the component location differ by the type of the indoor unit as follows.

- **Compact cassette type:**



- **Mini duct and Slim duct types:**




External input and output		Connector	Input select	Input signal	External connect kit (Optional parts)
External input	Operation/Stop Forced stop	Terminal	Dry contact	Edge	—
External output	Operation status	CN47	—	—	UTY-XWZXZG
	Error status				
	Indoor unit fan operation status				
	External heater output				

■ External input

With using external input function, some functions on this product can be controlled from an external device.

- "Operation/Stop" mode or "Forced stop" mode can be selected with function setting of indoor unit.
- A twisted pair cable (22AWG) should be used. Maximum length of cable is 150 m.
- The wire connection should be separate from the power cable line.

Indoor unit functions such as Operation/Stop can be done by using indoor unit terminals.



*1: The switch can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.


■ External output

Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 25 m.
- Output voltage: High DC 12 V ± 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to "[Combination of external input and output](#)" on page 130.


● When indicator, etc. are connected directly

Example: Function setting 60 is set to "00"



● When connecting with a device equipped with a power supply

Example: Function setting 60 is set to "00"



■ Combination of external input and output

By combining the function setting of the indoor unit, you can select various combinations of functions.

Combination examples of external input and output are as follows:

Mode	Function setting	External input	External output
		Terminal	CN47
0	60—00	Operation/Stop	
1—8	60—01 to 60—08	(Setting prohibited)	
9	60—09	Operation/Stop	Error status
10	60—10	Operation/Stop	Indoor unit fan operation status
11	60—11	Operation/Stop	External heater output


NOTE: Input of Operation/Stop depends on the setting of function setting 46.

- 00: Operation/Stop mode 1 (R.C. enabled)
- 01: (Setting prohibited)
- 02: Forced stop
- 03: Operation/Stop mode 2 (R.C. disabled)

● Input signal type

- Indoor unit

Input signal type is only "Edge".




■ Details of function

● Control input function

- When function setting is "Operation/Stop" mode 1

Function setting	External input	Input signal	Command
46—00	Terminal	Off → On	Operation
		On → Off	Stop




NOTES:

- The last command has priority.
- The indoor units within the same remote controller group operates in the same mode.

- When function setting is "Forced stop" mode

Function setting	External input	Input signal	Command
46—02	Terminal	Off → On	Forced stop
		On → Off	Normal




NOTES:

- When the forced stop is triggered, indoor unit stops and Operation/Stop operation by the remote controller is restricted.
- When forced stop function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

- When function setting is "Operation/Stop" mode 2

Function setting	External input	Input signal	Command
46—03	Terminal	Off → On	Operation
		On → Off	Stop (R.C. disabled)



NOTE: When "Operation/Stop" mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

● Control output function

Function setting	External output	Output signal	Command
60—00	CN47	Low → High	Operation
		High → Low	Stop


The output is low when the unit is stopped.



● Error status

Function setting	External output	Output signal	Command
60—09	CN47	Low → High	Error
		High → Low	Normal


The output is ON when an error is generated for the indoor unit.



● Indoor unit fan operation status

Function setting	External output	Output signal	Command
60—10	CN47	Low → High	Fan run
		High → Low	Fan stop

Output signal	Condition
On	The indoor unit fan is operating.
Low → High	
Off	The fan is stopped or during cold air prevention.
High → Low	During thermostat off when in dry mode operation.



● External heater output


Function setting	External output	Output signal	Command
60—11	CN47	Low → High	Heater on
		High → Low	Heater off

Output signal	Condition
Low → High	Heater turns on as shown in diagram of heating temperature
Off → On	
High → Low	Heater turns off as shown in diagram of heating temperature <ul style="list-style-type: none"> • Other than Heating mode • Error occurred • Forced thermo off • Fan stop protection
On → Off	

Specifications of the signal output performance are as shown as follows:

Example When set temperature (Ts) is set at 22 °C;


- And room temperature (Tr) increase above 12 °C, signal output is on.
- And Tr increase above 21 °C, signal output is off.
- And Tr decrease below 19 °C, signal output is on.
- And Tr decrease below 10 °C, signal output is off.



The output also turns off in defrost operation.

11-2. Wall mounted type (Models: ASYG07KGTB, ASYG09KGTB, ASYG12KGTB, ASYG14KGTB, ASYG07KETA, ASYG09KETA, ASYG12KETA, ASYG14KETA, ASYG07KETA-B, ASYG09KETA-B, ASYG12KETA-B, and ASYG14KETA-B)

External input and output PCB



PCB	External input	External output	Connector	Input select	Input signal
External input and output (UTY-XCSXZ2)	Operation/Stop	-	CN313/ CN314	Dry contact/ Apply voltage	Edge/Pulse
	Forced stop		CN313		Edge
	Forced thermostat off		CN312	-	
	-	Operation status	CN310	-	
		Error status	CN311	-	
		Indoor unit fan operation status	CN312	-	

NOTE: KETA, KETA-B: External input and output PCB cannot be used with Wireless LAN adapter simultaneously.

■ External input

With using external input function, some functions on this product can be controlled from an external device.

- "Operation/Stop" mode or "Forced stop" mode can be selected with function setting of indoor unit.
- A twisted pair cable should be used. Maximum length of cable is 150 m.
- The wire connection should be separate from the power cable line.

● External input and output PCB


The indoor unit Operation/Stop can be set by using the input connector on the PCB.

• Input select:

Use either one of these types of connectors according to the application. (Both types of connectors cannot be used simultaneously.)

– Dry contact


In case of internal power supply, set the slide switch of SW301 to "NON VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

– Apply voltage

In case of external power supply, set the slide switch of SW301 to "VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.


*2: Make the power supply DC 12 to 24 V, 10 mA or more.

■ External output

Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.


● External input and output PCB

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 25 m.
- Output voltage: High DC 12 V±2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to "Combination of external input and output" on page 137.
- **When indicator or other components are connected directly:**
Example: Function setting 60 is set to "00".



- **When connecting with a device equipped with a power supply:**

Example: Function setting 60 is set to "00".



■ Combination of external input and output

By combining the function setting of the indoor unit and rotary switch setting of the External input and output PCB, you can select various combinations of functions.

Combination examples of external input and output are as follows:

Mode	Function setting	External input and output PCB (Rotary SW)	External input		
			External input and output PCB		
			CN313	CN314	Signal type
0-1	60-00	1	Operation/Stop	Not available	Edge
			Operation	Stop	Pulse
0-2	60-00	2	Forced Thermostat OFF	Not available	Edge
1—8	60-01 to 60-08	3 - 9, A	(Setting prohibited)		
9	60-09	B	Forced Thermostat OFF	Not available	Edge
10	60-10	C	Forced Thermostat OFF	Not available	Edge
11	60-11	D	Forced Thermostat OFF	Not available	Edge

Mode	Function setting	External input and output PCB (Rotary SW)	External output		
			External input and output PCB		
			CN310	CN311	CN312
0-1	60-00	1	Operation/Stop	Error status	Indoor unit fan operation status
0-2	60-00	2	Error status	Indoor unit fan operation status	Not available
1—8	60-01 to 60-08	3 - 9, A	(Setting prohibited)		
9	60-09	B	Operation/Stop	Indoor unit fan operation status	Not available
10	60-10	C	Operation/Stop	Error status	Not available
11	60-11	D	Operation/Stop	Indoor unit fan operation status	Error status

NOTE: Input of Operation/Stop depends on the setting of function setting 46.

00: Operation/Stop mode 1 (R.C. enabled)

01: (Setting prohibited)

02: Forced stop


03: Operation/Stop mode 2 (R.C. disabled)

● Input signal type

External input and output PCB:

The input signal type can be selected.

Signal type (edge or pulse) can be switched by the DIP switch SW302 on the External input and output PCB.




■ Details of function

● Control input function


- When function setting is "Operation/Stop" mode 1
 - In the case of "Edge" input:

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-00	60-00 / 1	External input and output PCB	CN313	Off → On	Operation
				On → Off	Stop



- In the case of "Pulse" input:

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-00	60-00 / 1	External input and output PCB	CN313	Pulse	Operation
				CN314	Stop




NOTES:

- The last command has priority.
- The indoor units within the same remote controller group operate in the same mode.

- When function setting is "Forced stop" mode


- In the case of "Edge" input:

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-02	60-00 / 1	External input and output PCB	CN313	Off → On	Forced stop
				On → Off	Normal



- In the case of "Pulse" input:

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-02	60-00 / 1	External input and output PCB	CN313	Pulse	Forced stop
			CN314	Pulse	Normal




NOTES:

- When the forced stop is triggered, indoor unit stops and Operation/Stop operation by the remote controller is restricted.
- When forced stop function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

- When function setting is "Operation/Stop" mode 2


- In the case of "Edge" input:

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-03	60-00 / 1	External input and output PCB	CN313	Off → On	Operation
				On → Off	Stop (R.C. disabled)



- In the case of "Pulse" input:


Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
46-03	60-00 / 1	External input and output PCB	CN313	Pulse	Operation
			CN314	Pulse	Stop (R.C. disabled)



NOTE: When "Operation/Stop" mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

- Forced thermostat off function

Function setting /	Rotary SW on External input and output PCB	External input		Input signal	Command
60-00 / 2 60-09 / B 60-10 / C	External input and output PCB	CN313	Off → On	Thermostat off	
			On → Off	Normal operation	




NOTE: When the signal is received from another unit on the refrigerant circuit, there may be a delay in thermostat off function at the unit.

● Control output function

- Operation/Stop status

Function setting /	Rotary SW on External input and output PCB	External output		Output signal	Command
60-00 / 1	External input and output PCB		CN310	Off → On	Operation
				On → Off	Stop


The output is low when the unit is stopped.



- Error status

Function setting /	Rotary SW on External input and output PCB	External output		Output signal	Command
60-00 / 1	External input and output PCB		CN311	Off → On	Error
				On → Off	Normal


The output is ON when an error is generated for the indoor unit.



- Indoor unit fan operation status

Function setting /	Rotary SW on External input and output PCB	External output		Output signal	Command
60-00 / 1	External input and output PCB		CN312	Off → On	Fan run
				On → Off	Fan stop

Output signal	Condition
On Low → High	The indoor unit fan is operating.
Off High → Low	The fan is stopped or during cold air prevention. During thermostat off when in dry mode operation.



11-3. Wall mounted type (Models: ASYG18KMTB, ASYG07KMCC, ASYG09KMCC, ASYG12KMCC, and ASYG14KMCC)

With using external input and output functions, this product can be operated inter-connectedly with an external device.

Connector	Input	Output	Remarks
CNA01	Control input	—	See external input/output settings for details.
CNB01	—	Operation status output	
CNB02	—	Error status output	

■ External input

With using external input function, some functions on this product can be controlled from an external device.

- “Operation/Stop” mode can be selected with function setting of indoor unit.
- A twisted pair cable (22AWG) should be used. Maximum length of cable is 150 m.
- The wire connection should be separate from the power cable line.


● Control input (Operation/Stop or Forced stop)

The air conditioner can be remotely operated by means of the following on-site work.

Unit operation is started at the following contents by adding the contact input of a commercial on/off switch to a connector on the external control PCB and turning it on.


Unit operation	Initial setting after power is on	Starting mode other than initial setting
Operation mode	Auto changeover	Mode at previous operation
Set temperature	24 °C	Temperature at previous operation
Airflow mode	AUTO	Mode at previous operation
Air direction (swing)	Standard air direction (swing: off)	Air direction at previous operation

- Circuit diagram example




- Contact capacity: DC 24 V or more, 10 mA or more.
- *: Make the distance from the PCB to the connected unit within 10 m.
- Use non-polar relays and switches.


- When function setting is "Operation/Stop" mode



- When function setting is "Forced stop" mode




- When function setting is "Operation/Stop" mode 2



NOTE: When "Operation/Stop" mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

- Optional part

Part name	Model name	Exterior
External connect kit	UTY-XWZXZ5	External input wire 
Communication kit	UTY-TWBXF2	

* For operating the external function, the wall mounted type requires the communication kit in addition to the wire (UTY-XWZXZ5).


■ External output

With using external output function, operating status of this product can be transmitted to the external device, and also, this product can be inter-connected with the external device.


● Operation status output

Air conditioner operation status signal can be output.


- **Circuit diagram example:**



- *: Make the distance from the PCB to the connected unit within 10 m.
 - Relay spec: Max. DC 24 V, 10 mA to less than 500 mA.



- **Optional part:**


Part name	Model name	Exterior
External connect kit	UTY-XWZXZ5	External output wire 
Communication kit	UTY-TWBXF2	

* For operating the external function, the wall mounted type requires the communication kit in addition to the wire (UTY-XWZXZ5).


● Error status output

Air conditioner error status signal can be output.

- **Circuit diagram example:**



- *: Make the distance from the PCB to the connected unit within 10 m.
- Relay spec: Max. DC 24 V, 10 mA to less than 500 mA.



- **Optional part:**

Part name	Model name	Exterior
External connect kit	UTY-XWZXZ5	External output wire
Communication kit	UTY-TWBXF2	

* For operating the external function, the wall mounted type requires the communication kit in addition to the wire (UTY-XWZXZ5).

11-4. Ceiling type




Fig. Indoor unit PCB




Fig. External input and output PCB

PCB	External input	External output	Connector	Input select	Input signal	External connect kit (Optional parts)
Indoor unit	Operation/Stop Forced stop	—	Terminal CN47	Dry contact	Edge	—
	—	Operation status		—	—	UTY-XWZXZG
	—	Error status		—	—	
	—	Indoor unit fan operation status		—	—	
	—	External heater output		—	—	
External input and output (UTY-XCSX)	Operation/Stop	—	Input 1/ Input 2	Dry contact/ Apply voltage	Edge/ Pulse	—
	Forced thermostat off	—			Edge	
	—	Operation status	Output 1 Output 2 Output 3	—	—	—
	—	Error status			—	
	—	Indoor unit status			—	
	—	External heater output			—	


■ External input

With using external input function, some functions on this product can be controlled from an external device.

- “Operation/Stop” mode can be selected with function setting of indoor unit.
- A twisted pair cable (22AWG) should be used. Maximum length of cable is 150 m.
- The wire connection should be separate from the power cable line.

● Indoor unit

Indoor unit functions such as Operation/Stop can be done by using indoor unit terminals.



*1: The switch can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

● External input and output PCB


The indoor unit Operation/Stop can be set by using the input terminal on the PCB.

● Input select

Use either one of these types of terminals according to the application. (Both types of terminals cannot be used simultaneously.)

- Dry contact


In case of internal power supply, set the slide switch of SW1 to "NON VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

- Apply voltage

In case of external power supply, set the slide switch of SW1 to "VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

*2: Make the power supply DC 12 V to 24 V 10 mA or more.

■ External output


Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.

● Indoor unit

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 25 m.
- Output voltage: High DC 12 V ± 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to Chapter 11-4-3. "Combination of external input and output" on page 152.


● When indicator, etc. are connected directly

Example: Function setting 60 is set to "00"




● When connecting with a device equipped with a power supply

Example: Function setting 60 is set to "00"



● External input and output PCB

- A twisted pair cable (22AWG) should be used.
- Permissible voltage and current: DC 5 V to 30 V / 3 A, AC 30 V to 250 V / 3 A
- For details, refer to Chapter 11-4-3. "Combination of external input and output" on page 152.



■ Combination of external input and output

By combining the function setting of the indoor unit and rotary switch setting of the External input and output PCB, you can select various combinations of functions.

Combination examples of external input and output are as follows:

Mode	Function setting	External input and output PCB (Rotary SW)	External input			
			Indoor unit Input	External input and output PCB		
			Terminal	Input 1	Input 2	Signal type
0-1	60-00	1	Operation/Stop	Operation/Stop	Not available	Edge
				Operation	Stop	Pulse
0-2	60-00	2	Operation/Stop	Forced Thermostat OFF	Not available	Edge
1-8	60-01 to 60-08	3 - 9, A		(Setting prohibited)		
9	60-09	B	Operation/Stop	Forced Thermostat OFF	Not available	Edge
10	60-10	C	Operation/Stop	Forced Thermostat OFF	Not available	Edge
11	60-11	D	Operation/Stop	Forced Thermostat OFF	Not available	Edge

Mode	Function setting	External input and output PCB (Rotary SW)	External output			
			Indoor unit Output	External input and output PCB		
			CN47	Output 1	Output 2	Output 3
0-1	60-00	1	Operation/Stop	Operation/Stop	Error status	Indoor unit fan operation status
0-2	60-00	2	Operation/Stop	Error status	Indoor unit fan operation status	External heater output
1-8	60-01 to 60-08	3 - 9, A		(Setting prohibited)		
9	60-09	B	Error status	Operation/Stop	Indoor unit fan operation status	External heater output
10	60-10	C	Indoor unit fan operation status	Operation/Stop	Error status	External heater output
11	60-11	D	External heater output	Operation/Stop	Indoor unit fan operation status	Error status

NOTE: Input of Operation/Stop depends on the setting of function setting 46.

00: Operation/Stop mode 1 (R.C. enabled)

01: (Setting prohibited)

02: Forced stop

03: Operation/Stop mode 2 (R.C. disabled)

● Input signal type

- Indoor unit


Input signal type is only "Edge".



- External input and output PCB

The input signal type can be selected.

Signal type (edge or pulse) can be switched by the DIP switch 2 (SW2) on the External input and output PCB.




■ Details of function

● Control input function

- When function setting is "Operation/Stop" mode 1
 - In the case of "Pulse" input

Function setting /	Rotary SW of External input and output PCB	External input		Input signal	Command
46-00	60-00 / 1	External input and output PCB	Input 1	Pulse	Operation
			Input 2	Pulse	Stop




NOTES:

- The last command has priority.
- The indoor units within the same remote controller group operate in the same mode.

- When function setting is "Forced stop" mode


- In the case of "Edge" input

Function setting /	Rotary SW of External input and output PCB	External input		Input signal	Command
46-02	-	Input of indoor unit	Terminal	Off → On	Forced stop
	60-00 / 1	External input and output PCB	Input 1	On → Off	Normal
	60-00 / 1	External input and output PCB	Input 1	Off → On	Forced stop
				On → Off	Normal



- In the case of "Pulse" input

Function setting /	Rotary SW of External input and output PCB	External input		Input signal	Command
46-02	60-00 / 1	External input and output PCB	Input 1	Pulse	Forced stop
			Input 2	Pulse	Normal




NOTES:

- When the forced stop is triggered, indoor unit stops and Operation/Stop operation by the remote controller is restricted.
- When forced stop function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.


- When function setting is "Operation/Stop" mode 2
 - In the case of "Edge" input

Function setting /	Rotary SW of External input and output PCB	External input		Input signal	Command
46-03	-	Input of indoor unit	Terminal	Off → On	Operation
				On → Off	Stop (R.C. disabled)
	60-00 / 1	External input and output PCB	Input 1	Off → On	Operation
				On → Off	Stop (R.C. disabled)



- In the case of "Pulse" input

Function setting /	Rotary SW of External input and output PCB	External input		Input signal	Command
46-03	60-00 / 1	External input and output PCB	Input 1	Pulse	Operation
			Input 2	Pulse	Stop (R.C. disabled)




NOTES:

- When "Operation/Stop" mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

● Forced thermostat off function

Function setting /	Rotary SW of External input and output PCB	External input	Input signal	Command
60-00 / 2 60-09 / B 60-10 / C 60-11 / D	External input and output PCB	Input 1	Off → On	Thermostat off
			On → Off	Normal operation




NOTE: When the signal is received from another unit on the refrigerant circuit, there may be a delay in thermostat off function at the unit.

● Control output function

Function setting /	Rotary SW of External input and output PCB	External output	Output signal	Command
60-00 / 1, 2	Output of indoor unit	CN47	Low → High	Operation
			High → Low	Stop
60-00 / 1 60-09 / B 60-10 / C 60-11 / D	External input and output PCB	Output 1	Off → On	Operation
			On → Off	Stop


The output is low when the unit is stopped.



● Error status

Function setting /	Rotary SW of External input and output PCB	External output		Output signal	Command
60-09 / B		Output of indoor unit	CN47	Low → High	Error
				High → Low	Normal
60-00 / 2				Off → On	Error
				On → Off	Normal
60-00 / 1		External input and output PCB	Output 2	Off → On	Error
60-10 / C				On → Off	Normal
60-11 / D				Off → On	Error
				On → Off	Normal


The output is ON when an error is generated for the indoor unit.



● Indoor unit fan operation status

Function setting /	Rotary SW of External input and output PCB	External output		Output signal	Command
60-10 / C		Output of indoor unit	CN47	Low → High	Fan run
				High → Low	Fan stop
60-00 / 2		External input and output PCB	Output 2	Off → On	Fan run
60-09 / B				On → Off	Fan stop
60-11 / D				Off → On	Fan run
60-00 / 1				On → Off	Fan stop

Output signal	Condition
On Low → High	The indoor unit fan is operating.
Off High → Low	The fan is stopped or during cold air prevention. During thermostat off when in dry mode operation.



● External heater output


Function setting /	Rotary SW of External input and output PCB	External output		Output signal	Command
60-11 / D		Output of indoor unit		CN47	Low → High Heater on
					High → Low Heater off
60-00 / 2 60-09 / B 60-10 / C		External input and output PCB		Output 3	Off → On Heater on
					On → Off Heater off

Output signal	Condition
Low → High Off → On	Heater turns on as shown in diagram of heating temperature
High → Low On → Off	Heater turns off as shown in diagram of heating temperature <ul style="list-style-type: none"> • Other than Heating mode • Error occurred • Forced thermo off • Fan stop protection

Specifications of the signal output performance are as shown as follows:


Example: When set temperature (Ts) is set at 22 °C;

- And room temperature (Tr) increase above 12 °C, signal output is on.
- And Tr increase above 21 °C, signal output is off.
- And Tr decrease below 19 °C, signal output is on.
- And Tr decrease below 10 °C, signal output is off.



The output also turns off in defrost operation.

11-5. Floor type



PCB	External input	External output	Connector	Input signal
Indoor unit	Operation/Stop	—	CN14	Edge
	Forced stop			
	Forced thermostat off		CN15	
	—	Operation status	CN20/CN21/ CN22/CN23	—
		Error status		
		Indoor unit fan operation status		
		External heater output		


■ External input

With using external input function, some functions on this product can be controlled from an external device.

- “Operation/Stop” mode can be selected with function setting of indoor unit.
- A twisted pair cable (22AWG) should be used. Maximum length of cable is 150 m.
- The wire connection should be separate from the power cable line.

● Indoor unit

Indoor unit functions such as Operation/Stop can be done by using indoor unit connectors.



*1: The switch can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

■ External output


Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.

● Indoor unit

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 25 m .
- Output voltage: High DC 12 V ± 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to Chapter 11-5-3. "Combination of external input and output" on page 162.


● When indicator or other components are connected directly

Example: Function setting 60 is set to "00"



● When connecting with a device equipped with a power supply

Example: Function setting 60 is set to "00"



■ Combination of external input and output

By combining the function setting of the indoor unit, you can select various combinations of functions.

Combination examples of external input and output are as follows:

Mode	Function setting	External input	
		Indoor unit	
		CN14	CN15
0	60-00	Operation/Stop (Function setting 46-00) or Emergency stop (Function setting 46-01) or Forced stop (Function setting 46-02)	Forced thermostat Off
9	60-09		Forced thermostat Off
10	60-10		Forced thermostat Off
11	60-11		Forced thermostat Off
12	60-12		Forced thermostat Off

Mode	Function setting	External output			
		Indoor unit			
		CN20	CN21	CN22	CN23
0	60-00	Operation/Stop	Error status	Indoor unit fan operation status	External heater output
9	60-09	Error status	Operation/Stop	Indoor unit fan operation status	External heater output
10	60-10	Indoor unit fan operation status	Operation/Stop	Error status	External heater output
11	60-11	External heater output	Operation/Stop	Indoor unit fan operation status	Error status

NOTE: Input of Operation/Stop depends on the setting of function setting 46.

00: Operation/Stop mode 1 (R.C. enabled)

01: (Setting prohibited)


02: Forced stop

03: Operation/Stop mode 2 (R.C. disabled)

● Input signal type

- Indoor unit

Input signal type is only "Edge".




■ Details of function

● Control input function


- When function setting is "Operation/Stop" mode 1
 - In the case of "Edge" input

Mode	Function setting		External input	Input signal	Command
0	46-00	—	Input of indoor unit	CN14	Off → On Operation
		60-00			On → Off Stop
	60-00	—		CN15	Off → On Operation
		—		CN15	On → Off Stop




- When function setting is "Forced stop" mode
 - In the case of "Edge" input

Mode	Function setting		External input	Input signal	Command
0	46-02	—	Input of indoor unit	CN14	Off → On Forced stop
		60-00			On → Off Normal
	60-00	—		CN15	Off → On Forced stop
		—		CN15	On → Off Normal



- When function setting is "Operation/Stop" mode 2
 - In the case of "Edge" input

Mode	Function setting	External input	Input signal	Command	
0	46-03	Input of indoor unit	CN14	Off → On Operation	
				On → Off Stop (R.C. disabled)	
	60-00		CN15	Off → On Operation	
				On → Off Stop (R.C. disabled)	




● Control output function

- Operation/Stop status

Mode	Function setting	External output		Output signal	Command
0	60-00	Output of indoor unit	CN15	Low → High	Operation
0				High → Low	Stop
0	60-00		CN20	Off → On	Operation
0				On → Off	Stop


The output is low when the unit is stopped.



- Error status

Mode	Function setting	External output		Output signal	Command
9	60-09	Output of indoor unit	CN15	Low → High	Error
0				High → Low	Normal
0	60-00		CN21	Off → On	Error
0				On → Off	Normal


The output is ON when an error is generated for the indoor unit.



- Indoor unit fan operation status

Mode	Function setting	External output		Output signal	Command
10	60-10	Output of indoor unit	CN15	Low → High	Fan run
0	60-00		CN22	High → Low	Fan stop
				Off → On	Fan run
				On → Off	Fan stop

Output signal	Condition
On Low → High	The indoor unit fan is operating.
Off High → Low	The fan is stopped or during cold air prevention. During thermostat off when in dry mode operation.



- Set point attainment status


NOTE: This function is valid only when function setting 96 is set to "01" (Primary unit) or "02" (Secondary unit).

When the room temperature does not reach the set point at a room due to the lower cooling performance caused by external factor such as the outdoor temperature change, signal is output to tell the attainment status of set point.

Mode	Function setting	External output		Output signal	Command
12	60-12	Output of indoor unit	CN15	On → Off	Normal
				Off → On	Set point attainment

Output signal	Condition
Off	Reached the set point. ($Tr \leq Tsa + 0.5^\circ C$)
On	Unreached the set point. ($Tr > Tsa + 2.5^\circ C$) However, even if the set point unreached, the signal will not be output for 7 minutes after power is turned on.

When performing the server room control, both of the primary unit and secondary unit output the set point attainment status if any of the unit is outputting alternative operation command.




*: When starting operation or resetting, judges the zone to descending direction.

● External heater output

• Installation configuration of individual connection

External heating device is installed individually. (No use of indoor unit fan)




⚠ WARNING

- Design and install external heater appropriately with considering its protection.
- Inappropriate designing and installation of external heater may cause a fire by emitted heat from the external heater.
- Fujitsu General Ltd. is not responsible for inappropriate designing or installation of external heating device.


- Auxiliary heater control 1

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Fan stop protection


- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting “Thon”.



Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature



Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature



Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

*: When room temperature stays in this zone for a specific time, auxiliary heater is turned on. For details, refer to function number 71.

Example: When set temperature (Ts) is 22°C (Factory setting),

- and room temperature (Tr) increases above 12°C, signal output is on.
- and room temperature (Tr) increases above 21°C, signal output is off.
- and room temperature (Tr) decreases below 19°C, signal output is on.
- and room temperature (Tr) decreases below 10°C, signal output is off.

12. Group connection


NOTE: Group control cannot be used together with Wireless LAN adapter.

Installation procedure for group control system:

A number of indoor units can be operated at the same time using a single remote controller.

NOTE: When different type of indoor units (such as wall mounted type and cassette type, cassette type and duct type, or other combinations) are connected using group control system, some functions may no longer be available.

1. Connect up to 16 indoor units in a system.




A, B, C, D, E: Remote controller cable


Wiring length limitation

$A + B + C + D + E \leq 500 \text{ m}$

Example of wiring method



Example of wiring method



2. Set the R.C. address. (Function setting)


- Addresses will be automatically set when initially starting up this unit. In such a case, do not change the remote controller address for the indoor unit, and keep it at the initial setting of "00".
- Only set addresses manually when using different numbers for addresses.
Set the R.C. address of each indoor unit using the function setting. (Refer to "Remote controller address setting" in "[Contents of function setting](#)" on page 246.)

NOTES:

- Do not use the same setting value.
- Setting is reflected after the power is turned on again.
Also set the R.C. address for the remote controller. For details, refer to the remote controller installation manual.

NOTE: In manual setting, connect up to 15 indoor units in a system.

Example of wiring method




13. Remote controller

13-1. Wireless remote controller (AR-REW4E, AR-REM4E, and AR-REB1E)


■ Overview

- AR-REW4E




NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

- AR-REM4E




NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

• AR-REB1E



NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

■ Specifications

● Controller


Unit: mm



Size (H × W × D)	mm	205 × 61 × 17
Weight	g	124 (without batteries)

● Holder


Unit: mm



Size (H × W × D)	mm	150 × 69.3 × 26.2
Weight	g	27


13-2. Wireless remote controller (AR-REW2E)

■ Overview



NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

■ Specifications

● Controller


Unit: mm



Size (H × W × D)	mm	205 × 61 × 17
Weight	g	125 (without batteries)

● Holder


Unit: mm



Size (H × W × D)	mm	150 × 69.3 × 26.2
Weight	g	27


13-3. Wireless remote controller (AR-REM7E)

■ Overview



NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

■ Specifications

● Controller


Unit: mm



Size (H × W × D)	mm	205 × 61 × 17
Weight	g	124 (without batteries)

● Holder


Unit: mm



Size (H × W × D)	mm	150 × 69.3 × 26.2
Weight	g	27


13-4. Wireless remote controller (UTY-LNTY: Optional part)

■ Overview



NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

■ Specifications

● Controller


Unit: mm



Size (H × W × D)	mm	205 × 61 × 17
Weight	g	124 (without batteries)

● Holder


Unit: mm



Size (H × W × D)	mm	150 × 69.3 × 26.2
Weight	g	27


13-5. IR receiver kit with Wireless remote controller (UTY-LBTYM: Optional part)

■ Overview



NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

Display panel




To facilitate explanation, the accompanying illustration has been drawn to show all possible indicators; in actual operation, however, the display will only show those indicators appropriate to the current operation.

■ Specifications

● Controller


Unit: mm



Size (H × W × D)	mm	205 × 61 × 17
Weight	g	124 (without batteries)

● Holder


Unit: mm



Size (H × W × D)	mm	150 × 69.3 × 26.2
Weight	g	27

● IR receiver


Unit: mm




Size (H × W × D)	mm	145 × 90 × 30
Weight	g	150

13-6. Wired remote controller (UTY-RNNYM: Optional part)

■ Overview



Display panel




NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.


- 1 START/STOP button**
Starts and stops operation.
- 2 SET TEMP. button**
Selects the setting temperature.
- 3 MODE button**
Selects the operating mode (AUTO , HEAT , FAN , COOL , and DRY).
- 4 FAN button**
Selects the fan speed AUTO , QUIET , LOW , MED , and HIGH .
- 5 ECONOMY (THERMO SENSOR) button**
Turns the economy-efficient mode on and off.
- 6 TIMER MODE (CLOCK ADJUST) button**
Selects the timer mode (off timer, on timer, and weekly timer). Sets the current time.
- 7 DAY (DAY OFF) button**
Temporarily cancels one day timer.
- 8 SET BACK button**
Selects the set back timer.
- 9 Set time button**
Pressed to set time.
- 10 TIMER DELETE button**
Deletes the weekly timer schedule.
- 11 TIMER SET button**
Sets the date, hour, minute, and on-off time.
- 12 Vertical airflow direction and swing button**
Push for 2 seconds to change the swing mode.
- 13 Horizontal airflow direction and swing button**
Push for 2 seconds to change the swing mode.
- 14 FILTER RESET button**
- 15 Operation lamp**
Lights during operation and when the timer is on.
- 16 Timer and clock indicator**
- 17 Operation mode indicator**
- 18 Fan speed indicator**
- 19 Operation lock indicator**
- 20 Temperature indicator**
- 21 Function indicators**
 - Defrost indicator
 - Thermo sensor indicator
 - Economy indicator
 - Vertical swing indicator
 - Horizontal swing indicator
 - Filter indicator

■ System diagram

1 remote controller:



2 remote controllers:




A, B, C: Remote controller cable

$A \leq 500\text{ m}; B + C \leq 500\text{ m}$


■ Electrical wiring

1 remote controller:



Remote controller


2 remote controllers:



Remote controllers

■ Specifications

Dimensions and other specifications on the wired remote controller are as follows.

			Unit: mm
	Front view		Side view
Size (H × W × D)	mm		120 × 120 × 18
Weight	g		160
Cable length (accessory)	m		10
Power	V		12

● Wiring specifications


Use	Cable size	Wire type	Remarks
Remote controller cable	0.33 mm ² (22 AWG)	Polar 3-core	Use sheathed PVC cable.

■ Installation

Connection pattern of wired remote controller varies by the type of the connected indoor unit.

● When connecting to terminal block (for Compact cassette, Slim duct, and Mini duct types)

Connect the end of remote controller cable directly to the exclusive terminal block.




NOTE: It may be failed if it is connected to the outdoor unit or the terminal block for power supply.

● When connecting to Communication kit (for KM models in Wall mounted type)

When connecting the remote controller to optional Communication kit, follow the procedures mentioned below.

1. Modify the remote controller cable as follows:


- Use a tool to cut off the terminal on the end of the remote controller cable and then remove the insulation from the cut end of the cable as shown in following figure.
- Connect the remote controller cable and connecting cable as shown in following figure.
- Be sure to insulate the connection between the cables.



2. Connect the remote controller cable.

- Connect the cable made in step 1. to the terminal^{*1} of optional Communication kit.
- Connect the cable from the terminal^{*2} of Communication kit to the indoor unit PCB.

^{*1}: CNC01 on UTY-TWBXF2
^{*2}: CND01 on UTY-TWBXF2




■ Required optional parts

Required optional parts for connecting the wired remote controller to the wall mounted type are as follows.


Part name	Model name
External connect kit	UTY-TWBXF2
Communication kit	UTY-XWZXZ5

13-7. Wired remote controller (UTY-RLRY: Optional part)

■ Overview



Display panel



NOTE: For individual icons in Setting screen and related functions, refer to the operation manual.

1 LED lamp (Operation indicator)

Lights while the indoor unit is operating. Blinks when an error occurred.

2 FAN button

Each time the button is pressed, fan speed switches as follows:



3 +, - buttons (Set temperature buttons)

Used to adjust temperature in Monitor mode screen.

+ button: Raise

- button: Lower

In Setting screen, used to select the setting items.

NOTE: When the operation mode is set to FAN, the temperature cannot be adjusted.

4 ENTER button

Used to enter setting items and settings.

5 Room temperature sensor (inside)

Senses ambient temperature of unit.

6 <, > buttons

Used to select setting items during the setting item selection screen is displayed.

7 MENU button

Used to display the setting item selection screen.

8 MODE button

Each time the button is pressed, operation mode switches as follows:



9 On/Off button

Starts or stops the operation.

NOTE: On/Off button cannot be operated at screens other than the Monitor mode screen.

10 Display panel

Displays Monitor mode screen or Setting screen.

Monitor mode screen is home screen of this controller, and the basic operation is performed in this screen.

In Setting screen, several settings are adjustable.

11 Temperature indicator

12 Fan speed indicator


13 Clock indicator

14 Airflow direction indicator


15 Operation mode indicator

■ System diagram

1 remote controller:



2 remote controllers:




A, B, C: Remote controller cable


$A \leq 500\text{ m}; B + C \leq 500\text{ m}$

■ Electrical wiring


1 remote controller:



2 remote controllers:




Group control:



NOTE: Group connection with Polar 3-wired remote controller is not allowed.

■ Specifications

Dimensions and other specifications on the wired remote controller are as follows.




● Wiring specifications

Use	Cable size	Wire type	Remarks
Remote controller cable	0.33 to 1.25 mm ²	Non-polar 2-core, Twisted pair	Use sheathed PVC cable.

■ Installation

Connect the end of remote controller cable directly to the exclusive terminal block.




NOTES:

- Layout of terminal block and PCB is varies depending on the type of indoor unit.
- Operation may fail if it is connected to the outdoor unit or the terminal block for power supply.

13-8. Wired remote controller (UTY-RVNYM: Optional part)


■ Overview



- 1** Display panel (with backlight)
- 2** Screen switch button (Left)
- 3** Menu button
- 4** Cancel button
- 5** Cursor button
- 6** Screen switch button (Right)
- 7** Power indicator
- 8** On/off button
- 9** Enter button


■ System diagram

1 remote controller: **2 remote controllers:**




■ Electrical wiring

1 remote controller:




2 remote controllers:



■ Controller combination

As for the combined usage of the controller, refer to following figures.

● Good



■ Specifications

Unit: mm

Front view
Side view

Size (H × W × D)	mm	120 × 120 × 21.3
Weight	g	220


● Wiring specifications

Use	Cable size	Wire type	Remarks
Remote controller cable	0.33 mm ²	Polar 3 core	Use sheathed PVC cable.

■ Installation (Remote control main unit)

Installation space:

Unit : mm




NOTE: Secure enough space where a flat-blade screwdriver to remove the case can be inserted.


Installation procedures:

- #### **1. Process the remote controller cable.**

Unit : mm




2. Insert the flat-blade screwdriver and twist it slightly to separate the front case and rear case.



3. Attach the remote controller.


• When attaching to switch box:

- Seal the wiring hole of the remote controller cable.
- Put a remote controller cable through the hole of the rear case.
- Fix the rear case by securing it with attached screws (2 places).




• When attaching to the wall directly:

- Seal the wiring hole of the remote controller cable.
- Put a remote controller cable through the back hole of the rear case of the main body.
- Fix the rear case by securing it with attached screws (2 places).




• When routing the cable on-wall:

- Cut off the cable guide of the front case with using a knife or a nipper.
- Deburr the edge of the cable guide.




- Fix the rear case by securing it with attached screws (2 places).




4. Connect the cable to the terminals on the front case.
 Fix the cable together with the sheath with the cable tie. Cut off the excess cable tie.

Tightening torque	
Terminal screw	0.8 to 1.2 N·m



To avoid an excessive tension or pressure to the terminal block, fix the remote controller cable with the cable tie properly.





⚠ CAUTION

- Be careful to avoid breaking the cable by over-tightening the cable tie.
- When connecting the remote controller cables, do not over-tighten the screws.

5. Attach the front case.

- Insert after adjusting upper part of front case.
- When insert the front case, do not pinch the cable.



⚠ CAUTION


Insert the upper case firmly. If improperly attached, it will cause the upper case to fall off.

■ Installation

Connection pattern of wired remote controller varies by the type of the connected indoor unit.

● When connecting to terminal block (for Compact cassette, Slim duct, and Mini duct types)

Connect the end of remote controller cable directly to the exclusive terminal block.




NOTE: It may be failed if it is connected to the outdoor unit or the terminal block for power supply.

● When connecting to Communication kit (for KM models in Wall mounted type)

When connecting the remote controller to optional Communication kit, follow the procedures mentioned below.

1. Modify the remote controller cable as follows:


- Use a tool to cut off the terminal on the end of the remote controller cable and then remove the insulation from the cut end of the cable as shown in following figure.
- Connect the remote controller cable and connecting cable as shown in following figure.
- Be sure to insulate the connection between the cables.



2. Connect the remote controller cable.

- Connect the cable made in step 1. to the terminal^{*1} of optional Communication kit.
- Connect the cable from the terminal^{*2} of Communication kit to the indoor unit PCB.

^{*1}: CNC01 on UTY-TWBXF2
^{*2}: CND01 on UTY-TWBXF2




■ Required optional parts

Required optional parts for connecting the wired remote controller to the wall mounted type are as follows.


Part name	Model name
External connect kit	UTY-TWBXF2
Communication kit	UTY-XWZXZ5

13-9. Wired remote controller (UTY-RNRYZ*: Optional part)

■ Overview



Display panel



1 Remote temperature sensor (inside)

2 On/off button

Operable only while displaying the "Monitor mode" screen.

3 LED lamp (operation indicator)

4 Touch panel display

5 Set temperature

Operating temperature can be set.

6 Remote controller group name

7 Mode

Operation mode can be set.

8 Status icons

9 Clock

10 Fan

Fan speed can be set.

11 Room temperature

12 Menu

Various settings can be set.


13 Status

Status of the indoor unit and error can be checked.


NOTE: Functions may differ by type of the indoor unit. For details, refer to the operation manual.

■ System diagram

1 remote controller:



2 remote controllers:




A, B, C: Remote controller cable


$A \leq 500\text{ m}; B + C \leq 500\text{ m}$

■ Electrical wiring


1 remote controller:



2 remote controllers:



Group control:




NOTE: Group connection with Polar 3-wired remote controller is not allowed.

■ Specifications

Dimensions and other specifications on the wired remote controller are as follows.

[Unit : mm]



Model name	UTY-RNRYZ*
------------	------------


Display	3.8-inch FSTN LCD (255 × 160 dots) with touch panel	
Dimensions (H × W × D)	mm	120 × 120 × 20.4
Weight	g	220
Input voltage	V	DC 12
Power consumption	W	Max. 0.3
Usage temperature range	°C	0 to 40
Usage humidity range	%	20 to 90 (no condensation)
Storage temperature range	°C	-10 to 60
Storage humidity range	%	20 to 90 (no condensation)

● Wiring specifications

Use	Cable size	Wire type	Remarks
Remote controller cable	0.33 to 1.25 mm ²	Non-polar 2-core, Twisted pair	Use sheathed PVC cable.

■ Installation

Connect the end of remote controller cable directly to the exclusive terminal block.




NOTES:


- Layout of terminal block and PCB is varies depending on the type of indoor unit.
- Operation may fail if it is connected to the outdoor unit or the terminal block for power supply.

13-10. Simple remote controller (UTY-RSNYM: Optional part)

■ Overview



Display panel



1 START/STOP button

Starts and stops operation.

2 Display backlight button

Lights during operation.

3 Operation lamp

Lights during operation.

4 FAN button

Selects the fan speed (AUTO A° , HIGH H° , MED M° , LOW L° , and QUIET Q°).

5 SET TEMP. button

Selects the setting temperature.

6 MODE button

Selects the operating mode (AUTO A° , COOL C° , DRY D° , FAN F° , HEAT H°).

7 Standby indicator

Indicates during the oil recovery and defrosting operation.

8 Power source indicator

Indicates the main power is on.

9 Central control indicator

Indicates when function is locked.

10 Fan speed indicator

Deletes the weekly timer schedule.

11 Set temperature

- Indicates error history number in error code history display mode.
- Indicates indoor unit address in address display mode.


12 Operating mode indicator

13 Indicator


- Upper:
 - Indicates the error code in error code history display mode and in self diagnosis mode.
 - Indicates the refrigerant system address in address display mode.
- Lower: Indicates the remote controller address in error code history display mode, address display mode, and self diagnosis mode.

■ System diagram

1 remote controller:



2 remote controllers:




A, B, C: Remote controller cable


$A \leq 500\text{ m}; B + C \leq 500\text{ m}$

■ Electrical wiring

1 remote controller:



2 remote controllers:



■ Specifications

Dimensions and other specifications on the wired remote controller are as follows.

Unit: mm

Front View	Side View	Rear View
Size (H × W × D)	mm	120 × 75 × 14
Weight	g	90
Cable length (accessory)	m	10
Power	V	12

● Wiring specifications


Use	Size	Wire type	Remarks
Remote controller cable	0.33 mm ²	Polar 3 core	Use sheathed PVC cable.

■ Installation

Connection pattern of wired remote controller varies by the type of the connected indoor unit.

● When connecting to terminal block (for Compact cassette, Slim duct, and Mini duct types)

Connect the end of remote controller cable directly to the exclusive terminal block.




NOTE: It may be failed if it is connected to the outdoor unit or the terminal block for power supply.

● When connecting to Communication kit (for KM models in Wall mounted type)

When connecting the remote controller to optional Communication kit, follow the procedures mentioned below.

1. Modify the remote controller cable as follows:


- Use a tool to cut off the terminal on the end of the remote controller cable and then remove the insulation from the cut end of the cable as shown in following figure.
- Connect the remote controller cable and connecting cable as shown in following figure.
- Be sure to insulate the connection between the cables.



2. Connect the remote controller cable.

- Connect the cable made in step 1. to the terminal^{*1} of optional Communication kit.
- Connect the cable from the terminal^{*2} of Communication kit to the indoor unit PCB.

^{*1}: CNC01 on UTY-TWBXF2
^{*2}: CND01 on UTY-TWBXF2




■ Required optional parts

Required optional parts for connecting the wired remote controller to the wall mounted type are as follows.


Part name	Model name
External connect kit	UTY-TWBXF2
Communication kit	UTY-XWZXZ5

13-11. Simple remote controller (UTY-RSRY and UTY-RHRY: Optional parts)

■ Overview



Display panel



¹: Available only for UTY-RSRY.

*²: Not available for a heat pump model unless it is set up as an administrative indoor unit.

*³: Not available for a heat pump model.

*⁴: Not available for a cooling-only model.

*⁵: Set the function setting of the indoor unit accordingly.

*⁶: During address display mode.

1 LED lamp

Lights during operation.

2 Louver button

Adjusts the airflow direction.

3 START/STOP button

Starts and stops operation.

4 FAN control button

Switches the fan speed as follows:



5 Room temperature sensor (inside)

Senses ambient temperature of unit.

6 Set temperature button

Selects the setting temperature. (18—30 °C [COOL], 10—30 °C [HEAT])

7 Operation mode button*¹

Switches the operation mode as follows:



8 Operating mode indicator

9 Airflow direction indicator

10 FAN speed indicator

11 Remote controller address indicator

12 Status icons

Mode mismatch

Filter sign *⁵

Defrost operation

Oil recovery operation

Under maintenance

Error

Special state

Conducting electricity

Emergency stop

Operation controlled

Forced stop

Remote controller sensor is enabled *⁵

Central controlled

Setting temperature range is enabled


Operation prohibited

13 Set temperature


Indicates indoor unit address. *⁶

■ System diagram

1 remote controller:



2 remote controllers:




A, B, C: Remote controller cable


$A \leq 500\text{ m}; B + C \leq 500\text{ m}$

■ Electrical wiring


1 remote controller:



2 remote controllers:




Group control:



NOTE: Group connection with Polar 3-wired remote controller is not allowed.

■ Specifications

Dimensions and other specifications on the wired remote controller are as follows.




● Wiring specifications

Use	Cable size	Wire type	Remarks
Remote controller cable	0.33 to 1.25 mm ²	Non-polar 2-core, Twisted pair	Use sheathed PVC cable.

■ Installation

Connect the end of remote controller cable directly to the exclusive terminal block.



14. Function settings

To adjust the functions of this product according to the installation environment, various types of function settings are available.

NOTE: Incorrect settings can cause a product malfunction.

14-1. Compact cassette, Mini duct, Slim duct types indoor unit (setting by DIP switch)


By using some components on the PCB, you can change the function settings.

Related components on the PCB and the applicable settings:

Component			Setting content
DIP switch	SW100	1	Remote controller address setting
		2	
		3	
		4	
	SW101	1	Drainage function setting
		2	Auto louver grille setting
		3	Fan delay setting

■ Component location

Components on the indoor unit main PCB used for the function settings are located as shown in the following figure.




■ DIP switch setting

- SW100: Remote controller address setting**

When operating a number of indoor units by using a wired remote controller, DIP switch setting for assigning unit number to each indoor unit is required.

The slide switches are normally set to make the unit number 00.

Remote controller address	Switch number				Factory setting
	1	2	3	4	
00	OFF	OFF	OFF	OFF	♦
01	ON	OFF	OFF	OFF	
02	OFF	ON	OFF	OFF	
03	ON	ON	OFF	OFF	
04	OFF	OFF	ON	OFF	
05	ON	OFF	ON	OFF	
06	OFF	ON	ON	OFF	
07	ON	ON	ON	OFF	
08	OFF	OFF	OFF	ON	
09	ON	OFF	OFF	ON	
10	OFF	ON	OFF	ON	
11	ON	ON	OFF	ON	
12	OFF	OFF	ON	ON	
13	ON	OFF	ON	ON	
14	OFF	ON	ON	ON	
15	ON	ON	ON	ON	



- SW101-Switch 1: Drainage function setting**

Switch 1	Drainage function	Factory setting
ON	Disabled	
OFF	Enabled	♦

- SW101-Switch 2: Auto louver grille setting**

When Auto louver grille kit (optional parts) is attached, set to “Enabled”.

Switch 2	Auto louver grille setting	Factory setting
ON	Enabled	
OFF	Disabled	♦

- SW101-Switch 3: Fan delay setting**

When the indoor unit is stopped while operating in conjunction with auxiliary heater, the indoor unit fan operation will continue for 1 minute.

Switch 3	Fan delay	Factory setting
ON	Enabled	
OFF	Disabled	♦

14-2. Indoor unit (setting by wireless remote controller)

⚠ CAUTION


This setting changes the function settings used to control the indoor unit according to the installation conditions. Incorrect settings can cause a product malfunction.

- After the power is turned on, perform the “Function setting” according to the installation conditions using the remote controller.
- The settings may be selected between the following two: Function number or Setting number.
- Settings will not be changed if invalid numbers or setting numbers are selected.

■ Preparation

Before connecting the power supply of the indoor unit, reconfirm following items:


- Piping air tight test and vacuuming have been performed firmly.
- There is no wiring mistake. Then, connect the power supply of the indoor unit.



■ AR-REM4E (for Wall mounted type KGTB), AR-REW4E (for Wall mounted type KETA), AR-REW2E (for Wall mounted type KMTB), and AR-REM7E (for Floor type)

● Button name and function

During address setting mode, indoor unit reject the any operation command from remote controller.




NOTE: The number of buttons varies by the remote controller model.

● Function setting procedure

1. Connect the power supply of the outdoor unit.

2. To enter the function setting mode, while holding down the POWERFUL and TEMP. \wedge button, press the RESET button.




3. Select the function number by pressing the \wedge or the \vee buttons. Each time the 10 °C HEAT button is pressed, it switches between the right digit and the left digit.




4. Proceed to the setting number by pressing the POWERFUL button. (To return to the function number selection, press the POWERFUL button again.)




5. Select the function number by pressing the \wedge or the \vee button. Each time the 10 °C HEAT button is pressed, it switches between the right digit and the left digit.



6. Press the MODE button once to transmit the function mode information.




7. Press the \odot/I button once to transmit the function setting information. 2 short beeps will be emitted from the indoor unit when the signal is received correctly. If wrong code is set, no beep sound will be emitted.




NOTE: Press \odot/I button within 30 seconds after pressing MODE button.

For the function details, refer to Chapter 14-5. "[Function details](#)" on page 246.

8. Exit the function setting mode by pressing the RESET button.



● Setting up each indoor unit



Repeat step from 1. to 8. to set up each indoor unit. If the custom code is other than "R", steps from 1. to 2. and 8. need to be performed.

● Resetting the power after setting up all indoor units

Important:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

Once the RESET button is pressed on the remote controller, the operation mode will be set to the AUTO MODE.

Adjust the operation mode to either cooling or heating before starting the operation of the air conditioner.

NOTE: If custom code other than "R" is set, the remote control must be set accordingly to the indoor unit setting.

● Remote controller custom code setting

Custom code setting of wireless remote controller needs to be same as the setting of the indoor unit. When you change the custom code setting of the wireless remote controller, do as follows:

1. Press the START/STOP button until only the clock is displayed on the display.



2. Press the MODE button for at least 5 seconds to display the current custom code (initially set to A).



3. Press the TEMP. " ^ " or the " v " button to change the custom code between A → b → c → d.



4. Press the MODE button again to return to the clock display. The custom code will be changed.




- If no buttons are pressed within 30 seconds after the custom code is displayed, the system returns to the original clock display. In this case, start again from step 1.
- The air conditioner custom code is set to A prior to shipment.
- If you do not know the air conditioner custom code setting, try each of the custom codes (A → b → c → d) until you find the code which operates the air conditioner.

■ AR-REB1E (for Wall mounted type KMCC)


● Button name and function

During address setting mode, indoor unit reject the any operation command from remote controller.



● Function setting procedure

1. Connect the power supply of the outdoor unit.
2. To enter the function setting mode, while holding down the POWERFUL and SET TEMP. ▲ buttons, press the RESET button.




3. Select the function number by pressing the \wedge or the \vee buttons. Each time the 10°C HEAT button is pressed, it switches between the right digit and the left digit.




4. Proceed to the setting number by pressing the POWERFUL button. (To return to the function number selection, press the POWERFUL button again.)




5. Select the function number by pressing the \wedge or the \vee button. Each time the 10°C HEAT button is pressed, it switches between the right digit and the left digit.



6. Press the MODE button once to transmit the function mode information.




7. Press the \odot/I button once to transmit the function setting information. 2 short beeps will be emitted from the indoor unit when the signal is received correctly. If wrong code is set, no beep sound will be emitted.




NOTE: Press \odot/I button within 30 seconds after pressing MODE button.

For the function details, refer to Chapter 14-5. "Function details" on page 246.

8. Exit the function setting mode by pressing the RESET button.



● Setting up each indoor unit



Repeat step from 1. to 8. to set up each indoor unit. If the custom code is other than "H", steps from 1. to 2. and 8. need to be performed.

● Resetting the power after setting up all indoor units

Important:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

Once the RESET button is pressed on the remote controller, the operation mode will be set to the AUTO MODE.

Adjust the operation mode to either cooling or heating before starting the operation of the air conditioner.

NOTE: If custom code other than "R" is set, the remote control must be set accordingly to the indoor unit setting.

● Remote controller custom code setting

Custom code setting of wireless remote controller needs to be same as the setting of the indoor unit. When you change the custom code setting of the wireless remote controller, do as follows:

1. Press the START/STOP button until only the clock is displayed on the display.



2. Press the MODE button for at least 5 seconds to display the current custom code (initially set to A).



3. Press the SET TEMP. "▲" or the "▼" button to change the custom code between $\text{A} \rightarrow \text{B} \rightarrow \text{C} \rightarrow \text{D}$.



4. Press the MODE button again to return to the clock display. The custom code will be changed.




- If no buttons are pressed within 30 seconds after the custom code is displayed, the system returns to the original clock display. In this case, start again from step 1.
- The air conditioner custom code is set to A prior to shipment.
- If you do not know the air conditioner custom code setting, try each of the custom codes ($\text{A} \rightarrow \text{B} \rightarrow \text{C} \rightarrow \text{D}$) until you find the code which operates the air conditioner.

■ UTY-LNTY (for Compact cassette type) or AR-REJ1E (included in UTY-LBTYM for Duct type)


● Button name and function

During address setting mode, indoor unit reject the any operation command from remote controller.



● Function setting procedure

1. Connect the power supply of the outdoor unit.
2. To enter the function setting mode, while holding down the ECONOMY and SET TEMP. ▲ buttons, press the RESET button.




3. Select the function number by pressing the \wedge or the \vee buttons. Each time the 10°C HEAT button is pressed, it switches between the right digit and the left digit.




4. Proceed to the setting number by pressing the ECONOMY button. (To return to the function number selection, press the ECONOMY button again.)




5. Select the function number by pressing the \wedge or the \vee button. Each time the 10°C HEAT button is pressed, it switches between the right digit and the left digit.



6. Press the MODE button once to transmit the function mode information.




7. Press the \odot/I button once to transmit the function setting information. 1 short beep will be emitted from the indoor unit or the IR receiver when the signal is received correctly. If wrong code is set, no beep sound will be emitted.




NOTE: Press \odot/I button within 30 seconds after pressing MODE button.

For the function details, refer to Chapter 14-5. "[Function details](#)" on page 246.

8. Exit the function setting mode by pressing the RESET button.



● Setting up each indoor unit



Repeat step from 1. to 8. to set up each indoor unit. If the custom code is other than "H", steps from 1. to 2. and 8. need to be performed.

● Resetting the power after setting up all indoor units

Important:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

Once the RESET button is pressed on the remote controller, the operation mode will be set to the AUTO MODE.

Adjust the operation mode to either cooling or heating before starting the operation of the air conditioner.

NOTE: If custom code other than "H" is set, the remote control must be set accordingly to the indoor unit setting.

● Remote controller custom code setting

Custom code setting of wireless remote controller needs to be same as the setting of the indoor unit. When you change the custom code setting of the wireless remote controller, do as follows:

1. Press the START/STOP button until only the clock is displayed on the display.




2. Press the MODE button for at least 5 seconds to display the current custom code (initially set to A).

3. Press the SET TEMP. “ \wedge ” or the “ \vee ” button to change the custom code between $A \rightarrow B \rightarrow C \rightarrow D$.



4. Press the MODE button again to return to the clock display. The custom code will be changed.



- If no buttons are pressed within 30 seconds after the custom code is displayed, the system returns to the original clock display. In this case, start again from step 1.
- The air conditioner custom code is set to A prior to shipment.
- If you do not know the air conditioner custom code setting, try each of the custom codes ($A \rightarrow B \rightarrow C \rightarrow D$) until you find the code which operates the air conditioner.


14-3. Indoor unit (setting by wired remote controller)

- The function settings of the control of the indoor unit can be changed by this procedure according to the installation conditions. Incorrect settings can cause the indoor unit malfunction.
- After the power is turned on, perform the “Function setting” according to the installation conditions using the remote controller.
- The settings may be selected between the following two: Function number or Setting number.
- Settings will not be changed if invalid numbers or setting numbers are selected.
- This function cannot be used on the secondary units.

■ Preparation

Before connecting the power supply of the indoor unit, reconfirm following items:


- Piping air tight test and vacuuming have been performed firmly.
- There is no wiring mistake. Then, connect the power supply of the indoor unit.



■ UTY-RNNYM

● Button name and function

During address setting mode, indoor unit reject the any operation command from remote controller.




● Function setting procedure


1. Connect the power supply of the outdoor unit.

2. Switch to the function setting mode.


To enter the function setting mode, hold down the 3 buttons of SET TEMP. V, SET TEMP. Λ, and FAN at the same time for 5 seconds or longer.



3. Select the function number by pressing the SET TIME < or the SET TIME > button.




4. Select the setting number by pressing the SET TEMP. Λ or the SET TEMP. V button.
The display flashes during setting number selection.




5. Confirm the setting by pressing the TIMER SET button.

The data will be transferred to the indoor unit.



Function details: Refer to Chapter 14-5. "Function details" on page 246.

6. Exit the function setting mode by holding 3 buttons of SET TEMP. \vee , SET TEMP. \wedge and FAN at the same time.



If no button is pressed within 60 seconds after buttons mentioned above are pressed, it will automatically exit the function setting mode.

If you exit the function setting mode unintentionally during setting, enter the mode again according to the procedure in step 2.

● Setting up each indoor unit

Repeat the procedures from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

■ UTY-RLRY

● Setting procedure by using wired remote controller

The function number and the associated setting value are displayed on the LCD of the remote controller. Follow the instructions written in the local setup procedure supplied with the remote controller, and select appropriate setting according to the installation environment.


Before connecting the power supply of the indoor unit, reconfirm following items:

- Piping air tight test and vacuuming have been performed firmly.


- There is no wiring mistake.

- Connect the power supply.


- To activate the address setting mode, hold down the three buttons of "MENU", "<", and "ENTER" at the same time for 2 seconds or longer. Menu 2 setting screen is displayed.



- Select the "13" in Menu 2 settings. Then press the "ENTER" button.




- Pressing the "+" or "-" button, select a remote controller address (select the indoor unit you want to operate). Then press the "ENTER" button.




Example: When remote controller address "01" is selected.

5. Pressing the "+" or "-" button, to select the function number. Then press the "ENTER" button.



6. Pressing the "+" or "-" button, to select the setting number. Then press the "ENTER" button.



- When the data was not set up on the indoor unit
(" -- " is displayed.)

- Set up the data again.

- When the data was normally set up on the indoor unit.

Pressing the "ENTER" button to return to the address selection screen.

If setting has been completed, pressing the "MENU" button to return to the Menu 2 item selection screen.

● Setting up each indoor unit

Repeat the procedure from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:


- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

■ UTY-RVNYM


● Function setting procedure

1. Connect the power supply of the outdoor unit.
2. Switch to the function setting mode.


When [Menu button] is pressed twice while "Monitor" screen is displayed, it switches to the "Submenu" screen. If [Menu button] is pressed while the "Submenu" screen is displayed, the display returns to the "Monitor" screen.




Press the [Screen switch button (Left)] and [Screen switch button (Right)] simultaneously for 5 seconds to switch to "Service" screen.




Select [Function setting] with pressing the [Cursor button (Up/Down)], and press the [Enter button].




3. Select the [Function No.] with pressing the [Cursor button (Left/Right)], and select the Function No. to be set with pressing the [Cursor button (Up/Down)].



4. Select the [Setting No.] with pressing the [Cursor button (Left/Right)], and select the Setting No. to be set with pressing the [Cursor button (Up/Down)].




5. Pressing the [Enter button], confirm the setting.
The data will be transferred to the indoor unit.



Function details: Refer to Chapter 14-5. "[Function details](#)" on page 246.

6. When [Cancel button] is pressed twice while “Function setting” screen is displayed, it switches to the “Submenu” screen.



If no button is pressed within 60 seconds after buttons mentioned above are pressed, it will automatically exit the function setting mode.

If you exit the function setting mode unintentionally during setting, enter the mode again according to the procedure in step 2.

● Setting up each indoor unit

Repeat the procedures from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

■ UTY-RNRYZ*


● Setting procedure by using wired remote controller

The function number and the associated setting value are displayed on the LCD of the remote controller. Follow the instructions written in the local setup procedure supplied with the remote controller, and select appropriate setting according to the installation environment.

Before connecting the power supply of the indoor unit, reconfirm following items:


- Piping air tight test and vacuuming have been performed firmly.
- There is no wiring mistake.

1. Connect the power supply.
2. When the “Function Setting” on the “Maintenance” screen is touched, the “Installer Password Verification” screen is displayed. After enter the installer password, and touch the “OK”, “Function Setting” screen is displayed.




Address setting mode initial display

3. Touch the “Address” on the “Function Setting” screen.




4. “Address” screen is displayed. Select the address of the indoor unit whose function number is to be set by touching ▲ or ▼. When setting at all the indoor units, touch “All”.




When the “OK” is touched, the display returns to the “Function Setting” screen.

5. Touch the “Function No.” on the “Function Setting” screen.




6. “Function No.” screen is displayed. Set the “Function No.” with ▲ or ▼.




When the “OK” is touched, the display returns to the “Function Setting” screen.

7. Touch the “Function No.” on the “Function Setting” screen.



NOTE: *1: When “All” is chosen by “5”, and different set up “Setting No.” from two or more indoor units, “-” is displayed on “Setting No.”.


8. Setting screen of “Setting No.” is displayed. Set the “Function No.” with ▲ or ▼.




Example: Function number: 30, Setting Number: 01

When the “OK” is touched, the “Function Setting” verification screen is displayed.

9. Touch the “Yes” of the verification screen.



10. When the “Back” on the “Function Setting” screen is touched, the display returns to the “Maintenance” screen.



● Setting up each indoor unit

Repeat the procedure from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.


14-4. Indoor unit (setting by simple remote controller)

- The function settings of the control of the indoor unit can be changed by this procedure according to the installation conditions. Incorrect settings can cause the indoor unit malfunction.
- After the power is turned on, perform the “Function setting” according to the installation conditions using the remote controller.
- The settings may be selected between the following two: Function number or Setting number.
- Settings will not be changed if invalid numbers or setting numbers are selected.
- This function cannot be used on the secondary units.

■ Preparation

Before connecting the power supply of the indoor unit, reconfirm following items:


- Piping air tight test and vacuuming have been performed firmly.
- There is no wiring mistake. Then, connect the power supply of the indoor unit.



■ UTY-RSNYM

● Button name and function


During address setting mode, indoor unit reject the any operation command from remote controller.



● Function setting procedure


1. Connect the power supply of the outdoor unit.
2. Switch to the function setting mode.

To enter the function setting mode, hold down the 3 buttons of SET TEMP. ▲, SET TEMP. ▼ and FAN at the same time for 5 seconds or longer.





3. Press the FAN button.

The Function number indicator flashes. Then, press either the SET TEMP. ▲ button or the SET TEMP. ▼ button to set up the function number.





4. Select the setting number by pressing the SET TEMP. ▲ or SET TEMP. ▼ button.
The setting number indicator flashes during setting number selection.




Example) Function number : 30, Setting number : 01


5. Confirm the setting by pressing the TIMER SET button.
The data will be transferred to the indoor unit.



Good



Not good




Data is correctly set up on the indoor unit.

- Data is not set up on the indoor unit correctly (-- is displayed.)
- Set up the data again according to the procedure in step 3, 4 above.

Function details: Refer to Chapter 14-5. "Function details" on page 246.

6. Exit the function setting mode by pressing the 3 buttons of SET TEMP. ▲, SET TEMP. ▼, and FAN at the same time for 5 seconds or longer.
After exiting the function setting mode, the display returns to the normal mode.



Normal mode display

If no button is pressed within 60 seconds after buttons mentioned above are pressed, it will automatically exit the function setting mode.

If you exit the function setting mode unintentionally during setting, enter the mode again according to the procedure in step 2.

● Setting up each indoor unit

Repeat the procedures from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

■ UTY-RSRY/UTY-RHRY

● Setting procedure by using wired remote controller


The function number and the associated setting value are displayed on the LCD of the remote controller. Follow the instructions written in the local setup procedure supplied with the remote controller, and select appropriate setting according to the installation environment.

Before connecting the power supply of the indoor unit, reconfirm following items:


- Piping air tight test and vacuuming have been performed firmly.
- There is no wiring mistake.

NOTE: Set only one Master remote controller.


1. Connect the power supply.
2. With "Monitor mode" screen displayed, press and hold the SET TEMP. \wedge button and FAN \vee button simultaneously for at least 2 seconds.



3. The Menu 1 screen is displayed. Press and hold the SET TEMP. \wedge button at least 2 seconds. Setting mode selection screen is displayed.




4. Press the SET TEMP. \wedge or SET TEMP. \vee button to select F1 (Menu 2-F1) setting mode or F2 (Menu 2-F2) setting mode.




F1: Initial settings mode

F2: Maintenance settings mode


5. Press the \odot/I button. Setting item selection screen is displayed. (Item No. is displayed.)




6. Select the item number to be set with the SET TEMP. \wedge or SET TEMP. \vee button, and press the \odot/I button to switch to the setting screen.



7. Select the "13" in Menu 2-F1 settings. Then, press the \odot/I button.




8. Select the 2-wire remote controller address with the SET TEMP. \wedge or SET TEMP. \vee button. Then press the \odot/I button.




Select the 2-wire remote controller address (Ex. Select the 002-03)

9. Set the function number with the SET TEMP. \wedge or SET TEMP. \vee button. Then press the \odot/I button.




Function number

10. Set the setting number with the SET TEMP. \wedge or SET TEMP. \vee button. Then press the \odot/I button.



Setting number

11. Setting results are displayed after data transmission.



12. Press the P/I button to return to the 2-wire remote controller address selection screen of step 9. If setting has been completed, press the FAN V button to return to the Menu 2-F1 item selection screen.



● Setting up each indoor unit

Repeat the procedure from step 1 to 6, and set up the indoor units requiring function setting.

● Resetting the power after setting up function of all indoor units

NOTES:

- If the reset is not performed, function cannot be read correctly.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes.
 - After the 2 minutes has passed, power can be restored.
 - The set function is stored in the PCB and will remain in memory even when the power of indoor unit is turned off.
However setting function is effective after disconnecting the power supply and then reconnecting it.
- Record the latest configuration of the indoor unit function setting on a label, and put the label on the unit so it can be used for after-sales service operations.

14-5. Function details

■ Contents of function setting

Each function setting listed in this section is adjustable in accordance with the installation environment.

NOTE: Setting will not be changed if invalid numbers or setting values are selected.

● Function setting list

	Function no.	Functions	Compact cassette	Mini duct	Slim duct	Wall mounted			Ceiling	Floor
						KG	KM	KE		
1)	00	Remote controller address setting	—	—	—	●	●	●	—	—
2)	11	Filter sign	●	●	●	●	●	●	●	●
3)	20	Ceiling height	●	—	—	—	—	—	●	—
4)	22	Outlet directions	●	—	—	—	—	—	—	—
5)	26	Static pressure	—	●	●	—	—	—	—	—
6)	28	Horizontal louver direction switching for dew condensation prevention	—	—	—	—	—	—	●	—
7)	30/31	Room temperature control for indoor unit sensor	●	●	●	●	●	●	●	●
8)	35/36	Room temperature control for wired remote controller sensor	●	●	●	●	●	●	●	—
9)	40	Auto restart	●	●	●	●	●	●	●	●
10)	42	Room temperature sensor switching	●	●	●	●	●	●	●	●
11)	44	Remote controller custom code	●	●	●	●	●	●	●	●
12)	46	External input control	●	●	●	●	●	●	●	●
13)	48	Room temperature sensor switching (Aux.)	●	●	●	●	●	●	●	—
14)	49	Indoor unit fan control for energy saving for cooling	●	●	●	●	●	●	●	—
15)	60	Switching functions for external output terminal	●	●	●	●	—	—	●	●

1) Remote controller address setting (for Wall-mounted type only)

NOTES:

- Because this setting is normally done automatically when 2-wire-type wired remote controller is installed, setting is unnecessary.
- This setting is configurable only by wireless remote controller, but not configurable by Polar 3-wired remote controller.

Multiple indoor units can be operated by using one wired remote controller.

Set the unit number of each indoor unit.

Function number	Setting value	Setting description	Factory setting
00	00	Unit no. 0	◆
	01	Unit no. 1	
	02	Unit no. 2	
	03	Unit no. 3	
	04	Unit no. 4	
	05	Unit no. 5	
	06	Unit no. 6	
	07	Unit no. 7	
	08	Unit no. 8	
	09	Unit no. 9	
	10	Unit no. 10	
	11	Unit no. 11	
	12	Unit no. 12	
	13	Unit no. 13	
	14	Unit no. 14	
	15	Unit no. 15	

NOTES:

- When connecting Polar 3-wired remote controller, set the remote controller address in the order of 0, 1, 2,, and 15.
- When different type of indoor units (such as wall mounted type and cassette type, cassette type and duct type, or other combinations) are connected using group control system, some functions may no longer be available.

2) Filter sign

Select appropriate intervals for displaying the filter sign on the indoor unit according to the estimated amount of dust in the air of the room.

If the indication is not required, select "No indication" (03).

Function number	Setting value	Setting description	Factory setting
11	00	Standard	
	01	Long interval	
	02	Short interval	
	03	No indication	◆

Setting description	Compact cassette	Mini duct	Slim duct	Wall mounted
Standard	2,500 hours		400 hours	
Long interval	4,400 hours		1,000 hours	
Short interval	1,250 hours		200 hours	

3) Ceiling height (for Compact cassette type and Ceiling type only)

Select the appropriate ceiling height according to the place of installation.

Function number	Setting value	Setting description	Factory setting
20	00	Standard	◆
	01	High ceiling	

For the specific height for each setting value, refer to "Installation space" in Chapter 3. "[Dimensions](#)" on page 17.

In case of cassette type models:

The ceiling height values are for the 4-way outlet. Do not change this setting in the 3-way outlet mode.

7,000 or 9,000 Btu/h models cannot be installed in high ceilings. Do not change this setting.

4) Outlet directions (for Compact cassette type only)

Select the appropriate number of outlet directions according to the installation conditions.

Function number	Setting value	Setting description	Factory setting
22	00	4-way	◆
	01	3-way	

5) Static pressure (for Mini duct type and Slim duct type)

Select the appropriate static pressure according to the installation conditions.

For mini duct type:

Function number	Setting value	Setting description	Factory setting
26	00	0 Pa	
	01	10 Pa	
	02	20 Pa	
	03	30 Pa	
	04	40 Pa	
	05	50 Pa	
	31	Standard (10 Pa: 07; 09; 12 models, 15 Pa: 14; 18 models)	◆

NOTES:

- Range of static pressure is different by model.

Model	Range of static pressure
07, 09, 12 models	0 to 30 Pa
14, 18 models	0 to 50 Pa

- Setting number in 07, 09, 12 models is “04 to 30”: Operation is same as that “03”.
- Setting number in 14, 18 models is “06 to 30”: Operation is same as that “05”.
- Setting number value cannot be set to 32 or more.

For slim duct type:

Function number	Setting value	Setting description	Factory setting
26	00	0 Pa	
	01	10 Pa	
	02	20 Pa	
	03	30 Pa	
	04	40 Pa	
	05	50 Pa	
	06	60 Pa	
	07	70 Pa	
	08	80 Pa	
	09	90 Pa	
	31	Standard (25 Pa)	◆

6) Horizontal louver direction switching for dew condensation prevention (for KE model in Wall-mounted type only)

Automatically switches the position of the horizontal louver if the airflow direction is set at lower than the dew condensation limit position in cooling or drying operation.

Select suitable adjustment position according to the customer's preference.

Function number	Setting value	Setting description	Factory setting
28	00	Adjust to dew condensation limit position	◆
	01	Adjust to cooling standard position	

7) Room temperature control for indoor unit sensor (for other than Floor type)

Depending on the installed environment, correction of the room temperature sensor may be required. Select the appropriate control setting according to the installed environment.

The temperature of the room temperature sensor is corrected as follows:

Corrected temp. = Temp. of the room temp. sensor - Correction temp. value

Example of correction:

When the temperature of the room temp. sensor is 26°C and the setting value is "03" (-1.0°C), corrected temp. will be 27°C (26°C - [-1.0°C]).

The temperature correction values show the difference from the Standard setting "00" (manufacturer's recommended value).

Function number	Setting value	Setting description	Factory setting
30 (For cooling)	31 (For heating)	00	Standard setting
		01	No correction 0.0 °C
		02	-0.5 °C
		03	-1.0 °C
		04	-1.5 °C
		05	-2.0 °C
		06	-2.5 °C
		07	-3.0 °C
		08	-3.5 °C
		09	-4.0 °C
		10	+0.5 °C
		11	+1.0 °C
		12	+1.5 °C
		13	+2.0 °C
		14	+2.5 °C
		15	+3.0 °C
		16	+3.5 °C
		17	+4.0 °C

8) Room temperature control for wired remote controller sensor (for other than Floor type)

Depending on the installed environment, correction of the wire remote temperature sensor may be required. Select the appropriate control setting according to the installed environment.

To change this setting, set Function 42 to Both “01”.

Ensure that the Thermo Sensor icon is displayed on the remote controller screen.

Function number	Setting value	Setting description	Factory setting
35 (For cooling)	36 (For heating)	00	Standard setting
		01	No correction 0.0°C
		02	-0.5 °C
		03	-1.0 °C
		04	-1.5 °C
		05	-2.0 °C
		06	-2.5 °C
		07	-3.0 °C
		08	-3.5 °C
		09	-4.0 °C
		10	+0.5 °C
		11	+1.0 °C
		12	+1.5 °C
		13	+2.0 °C
		14	+2.5 °C
		15	+3.0 °C
		16	+3.5 °C
		17	+4.0 °C

9) Auto restart

Enables or disables automatic restart after a power interruption

Function number	Setting value	Setting description	Factory setting
40	00	Enable	◆
	01	Disable	

NOTE: Auto restart is an emergency function such as for power outage etc. Do not attempt to use this function in normal operation. Be sure to operate the unit by remote controller or external device.

10) Room temperature sensor switching

When using the wired remote controller temperature sensor, change the setting to "Both" (01).

Function number	Setting value	Setting description	Factory setting
42	00	Indoor unit	♦
	01	Both	

00: Sensor on the indoor unit is active.

01: Sensors on both indoor unit and wired remote controller are active.

NOTE: Remote controller sensor must be turned on by using the remote controller.

11) Remote controller custom code

(Only for wireless remote controller)

The indoor unit custom code can be changed. Select the appropriate custom code.

Function number	Setting value	Setting description	Factory setting
44	00	A	◆
	01	B	
	02	C	
	03	D	

12) External input control

"Operation/Stop" mode or "Forced stop" mode can be selected.

Function number	Setting value	Setting description	Factory setting
46	00	Operation/Stop mode 1	◆
	01	(Setting prohibited)	
	02	Forced stop mode	
	03	Operation/Stop mode 2	

13) Room temperature sensor switching (Aux.) (for other than Floor type)

To use the temperature sensor on the wired remote controller only, change the setting to "Wired remote controller" (01).

This function will only work if the function setting 42 is set at "Both" (01).

When the setting value is set to "Both" (00), more suitable control of the room temperature is possible by setting function setting 30 and 31 too.

Function number	Setting value	Setting description	Factory setting
48	00	Both	◆
	01	Wired remote controller	

14) Indoor unit fan control for energy saving for cooling (for other than Floor type)

Enables or disables the power-saving function by controlling the indoor unit fan rotation when the outdoor unit is stopped during cooling operation.

Function number	Setting value	Setting description	Factory setting
49	00	Disable	
	01	Enable	
	02	Remote controller	◆

00: When the outdoor unit is stopped, the indoor unit fan operates continuously following the setting on the remote controller.

01: When the outdoor unit is stopped, the indoor unit fan operates intermittently at a very low speed.

02: Enable or disable this function by remote controller setting.

NOTES:

- As the factory setting, this setting is initially activated.
- Set to "00" or "01" when connecting a remote controller that cannot set the Fan control for energy saving function or connecting a network converter.
To confirm if the remote controller has this setting, refer to the operating manual of each remote controller.

15) Switching functions for external output terminal (For other than KM and KE models in Wall-mounted type)

Functions of the external output terminal can be switched. For details, refer to "External input and output".


Function number	Setting value	Setting description	Factory setting
60	00	Operation status	♦
	01—08	(Setting prohibited)	
	09	Error status	
	10	Indoor unit fan operation status	
	11	External heater	

14-6. Wired remote controller (UTY-RNNYM)

DIP switch 1	SW1	Prohibited
	SW2	Dual remote controller setting
	SW3	Prohibited
	SW4	°F/°C switch
	SW5	Prohibited
	SW6	Memory backup setting

* Do not use DIP switch 2.

■ Switch location




■ DIP switch 1 setting

● SW2: Dual remote controller setting

Set the remote controller SW2 according to the following table.

Number of remote controller	Primary unit	Secondary unit	Factory setting
	SW2	SW2	
1 (Normal)	OFF	—	♦
2 (Dual)	OFF	ON	



● SW4: Switching temperature unit °F / °C

Displayed temperature unit can be switched between Fahrenheit (°F) and Celsius (°C).

SW4	Fahrenheit (°F) / Celsius (°C)	Factory setting
OFF	°C	♦
ON	°F	

● SW6: Memory backup setting

Set to “ON” to use batteries for the memory backup.


When batteries are not used, all of settings stored in memory will be deleted if there is a power failure.

SW6	Memory backup	Factory setting
OFF	Disable	♦
ON	Enable	

14-7. Wired remote controller (UTY-RVNYM)

DIP switch 1	SW1	Memory backup setting
	SW2	Dual remote controller setting

■ Switch location



■ DIP switch setting

● SW1: Memory backup setting

Set to "ON" to use batteries for the memory backup.


When batteries are not used, all of settings stored in memory will be deleted if there is a power failure.

SW1	Memory backup	Factory setting
OFF	Disable	◆
ON	Enable	

● SW2: Dual remote controller setting

Set the remote controller SW2 according to the following table.


Number of remote controller	Primary unit	Secondary unit	Factory setting
	SW2	SW2	
1 (Normal)	OFF	—	◆
2 (Dual)	OFF	ON	



14-8. Wired remote controller (UTY-RLRY)

DIP switch	Memory backup setting
------------	-----------------------

■ Switch location



■ Dip switch setting

● SW1: Memory backup setting

Set to "ON" to use batteries for the memory backup.


When batteries are not used, all of settings stored in memory will be deleted if there is a power failure.

SW1	Memory backup	Factory setting
OFF	Disable	♦
ON	Enable	

14-9. Wired remote controller (UTY-RNRYZ*)

DIP switch	Memory backup setting
------------	-----------------------

■ Switch location



■ Dip switch setting

● SW1: Memory backup setting

Set to "ON" to use batteries for the memory backup.


When batteries are not used, all of settings stored in memory will be deleted if there is a power failure.

SW1	Memory backup	Factory setting
OFF	Disable	♦
ON	Enable	

14-10. Simple remote controller (UTY-RSNYM)

DIP switch	SW1	Prohibited
	SW2	Dual remote controller setting
	SW3	°F/°C switch
	SW4	Prohibited
	SW5	Prohibited
	SW6	Prohibited

■ Switch location




■ DIP switch setting

● SW2: Dual remote controller setting

Set the remote controller SW2 according to the following table.

Number of remote controller	Primary unit	Secondary unit	Factory setting
	SW2	SW2	
1 (Normal)	OFF	—	◆
2 (Dual)	OFF	ON	



● SW3: Switching temperature unit °F / °C



Displayed temperature unit can be switched between Fahrenheit (°F) and Celsius (°C).

SW3	Fahrenheit (°F) / Celsius (°C)	Factory setting
OFF	°C	◆
ON	°F	

15. Accessories







15-1. Compact cassette type

■ Models: AUXG07KVLA, AUXG09KVLA, AUXG12KVLA, AUXG14KVLA, and AUXG18KVLA





Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Drain hose insulation		1
Operating manual (CD-ROM)		1	Hose band		1
Installation manual		1	Coupler heat insulation (large)		1
Template (Carton top)		1	Coupler heat insulation (small)		1
M10 nut A (with flange)		4	Cable tie		2
M10 nut B (with spring lock washer)		4	Wire crammer		1
Drain hose		1			

15-2. Mini duct type

■ Models: ARXG07KSLAP, ARXG09KSLAP, ARXG12KSLAP, and ARXG14KSLAP



Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Drain hose		1
Operating manual (CD-ROM)		1	Hose band		1
Installation manual		1	Drain hose insulation B		1
Installation template (Carton top)		1	Washer		8
Cable tie (large)		4	Coupler heat insulation (large)		1
Cable tie (medium)		3	Coupler heat insulation (small)		1
Filter (small)		2	Insulation (For electrical wiring)		2

■ Model: ARXG18KSLAP

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Drain hose		1
Operating manual (CD-ROM)		1	Hose band		1
Installation manual		1	Drain hose insulation B		1
Installation template (Carton top)		1	Washer		8
Cable tie (large)		4	Coupler heat insulation (large)		1
Cable tie (medium)		3	Coupler heat insulation (small)		1
Filter (large)		2	Insulation (For electrical wiring)		2





15-3. Slim duct type

■ Models: ARXG07KLLAP, ARXG09KLLAP, ARXG12KLLAP, ARXG14KLLAP, and ARXG18KLLAP




Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Cable tie (Large)		4
Installation manual		1	Cable tie (Small)		3
Installation template		1	Drain hose		1
Washer		8	Hose band		1
Coupler heat insulation (Large)		1	Drain hose insulation B		1
Coupler heat insulation (Small)		1	Remote controller		1
Filter (Small) (For 9/12 models)		2	Remote controller cable		1
Filter (Large) (For 18 models)		2	Tapping screw		2

15-4. Wall mounted type







■ Models: ASYG07-14KGTB and ASYG07-14KMCC

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Cloth tape		1
Operating manual (CD-ROM)		1	Tapping screw (large)		5
Installation manual		1	Tapping screw (small)		2
Remote controller		1	Wall hook bracket		1
Battery		2	Filter holder		2
Remote controller holder		1	Air cleaning filters		1

■ Model: ASYG18KMTB





Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Tapping screw (large)		5
Installation manual		1	Tapping screw (small)		2
Remote controller		1	Battery		2
Remote controller holder		1	Filter holder		2
Cloth tape		1	Air cleaning filters		1
Wall hook bracket		1			

**■ Models: ASYG07KETA, ASYG09KETA, ASYG12KETA,
ASYG14KETA, ASYG07KETA-B, ASYG09KETA-B,
ASYG12KETA-B, and ASYG14KETA-B**

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Cloth tape		1
Operating manual (CD-ROM)		1	Tapping screw (large)		5
Installation manual		1	Tapping screw (small)		2
Remote controller		1	Wall hook bracket		1
Battery		2	Filter holder		2
Remote controller holder		1	Air cleaning filters		1
Template (for pipe cover cutting)		1			





15-5. Ceiling type

■ Model: ABYG18KRTA

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Insulation		1
Operating manual (CD-ROM)		1	Drain hose		1
Installation manual		1	Hose band		1
Template		1	Cable tie (large)		4
M10 nut A (with flange)		4	Cable tie (small)		1
M10 nut B (with spring lock washer)		4	Remote controller cable hole cap		1
Washer		8	Tapping screw (White)		6
Coupler heat insulation (large)		1	Tapping screw		3
Coupler heat insulation (small)		1			

15-6. Floor type

■ Models: AGYG09KVCA, AGYG12KVCA, and AGYG14KVCA

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Operating manual (CD-ROM)		1
Installation manual		1	Cloth tape		1
Wall hook bracket		1	Tapping screws (large)		9
Remote controller		1	Tapping screws (small)		2
Battery		2	Air cleaning filters		1
Remote controller holder		1			

16. Optional parts

16-1. Controllers

■ Lineup

Indoor unit type		Type									
		Wireless remote controller						Wired remote controller			
		AR-REM4E	AR-REM7E	AR-REB1E	AR-REW2E	AR-REW4E	UTY-LNTY	UTY-RNNYM	UTY-RVNYM	UTY-RLRY	UTY-RNRYZ*
Compact cassette	—	—	—	—	—	—	○	○	○	○	○
Mini duct	—	—	—	—	—	—	—	○	○	○	○
Slim duct	—	—	—	—	—	—	—	○	○	○	○
Wall mounted	KG	●	—	—	—	—	—	—	—	○ ^{*2}	○ ^{*2}
	KMTB	—	—	—	●	—	—	—	—	○ ^{*2}	○ ^{*2}
	KMCC	—	—	●	—	—	—	○ ^{*1}	○ ^{*1}	—	—
	KE	—	—	—	—	●	—	—	—	○ ^{*2}	○ ^{*2}
Ceiling	—	—	—	—	—	—	—	—	—	○	○
Floor	—	●	—	—	—	—	—	—	—	○ ^{*3}	○ ^{*3}

Indoor unit type		Type								
		IR receiver kit with Wireless remote controller			Simple remote controller					
		UTY-LBTYM			UTY-RSNYM	UTY-RSRY	UTY-RHRY			
Compact cassette	—	—	—	—	○	○	○	○	○	○
Mini duct	○	—	—	—	○	○	○	○	○	○
Slim duct	○	—	—	—	○	○	○	○	○	○
Wall mounted	KG	—	—	—	—	—	○ ^{*2}	○ ^{*2}	○ ^{*2}	○ ^{*2}
	KMTB	—	—	—	—	—	○ ^{*2}	—	○ ^{*2}	○ ^{*2}
	KMCC	—	—	—	—	○ ^{*1}	—	—	—	—
	KE	—	—	—	—	—	○ ^{*2}	—	○ ^{*2}	○ ^{*2}
Ceiling	○	—	—	—	—	—	○	○	○	○
Floor	—	—	—	—	—	—	○ ^{*3}	—	○ ^{*3}	○ ^{*3}

●: Accessory, ○: Optional, —: Not applicable

- *1: Optional Communication kit (UTY-TWBXF2) is necessary for the installation.
- *2: Optional Communication kit (UTY-TWRXZ2) is necessary for the installation.
- *3: Optional Communication kit (UTY-TWRXZ3) is necessary for the installation.

■ Parts

Wireless remote controller



AR-REW4E



AR-REM4E



AR-REB1E



UTY-LNTY

Wireless remote controller




AR-REW2E




AR-REM7E


Wired remote controller



UTY-RNNYM



UTY-RVNYM



UTY-RLRY



UTY-RNRYZ*

IR receiver kit with Wireless remote controller



UTY-LBTYM



UTY-RSRY



UTY-RHRY


Simple remote controller

16-2. Cassette grille

■ Lineup

Indoor unit type	Model
Compact cassette	UTG-UFYF-W

■ Part



16-3. Others

■ Lineup

Indoor unit type	Type					
	Air outlet shutter plate	Insulation kit for high humidity	Fresh air intake kit	External input and output PCB		External switch controller
	UTR-YDZB	UTZ-KXGC	UTZ-VXAA	UTY-XCSXZ2	UTY-XCSX	UTY-TERX
Compact cassette	○	○	○	—	—	○
Mini duct	—	—	—	—	—	○
Slim duct	—	—	—	—	—	○
Wall mounted	KG	—	—	○	—	○*2
	KMTB	—	—	○	—	○*2
	KMCC	—	—	—	—	○*1
	KE	—	—	○	—	○*2
Ceiling	—	—	—	—	○	○
Floor	—	—	—	—	—	○*3

Indoor unit type	Type						
	Auto louver grille kit	External connect kit			KNX converter	Split system converter	
	UTD-GXTA-W UTD-GXTB-W	UTY-XWZX	UTY-XWZXZ5	UTY-XWZXZG	UTY-VKSX	UTY-VTGX	UTY-VTGXV
Compact cassette	—	—	—	○	○	○	○
Mini duct	○	—	—	○	○	○	○
Slim duct	○	—	—	○	○	○	○
Wall mounted	KG	—	○	—	—	○	○*2
	KMTB	—	—	○	—	○	○*2
	KMCC	—	—	○	—	○	○*1
	KE	—	—	○	—	○	○*2
Ceiling	—	—	—	○	○	○	○
Floor	—	—	○	—	○	○	○*3





Indoor unit type	Type							
	MODBUS converter	Remote sensor unit	Communication kit			Wireless LAN adapter*4		
	UTY-VMSX	UTY-XSZX	UTY-TWBXF2	UTY-TWRXZ2	UTY-TWRXZ3	UTY-TFSXW1	UTY-TFSXF2	UTY-TFSXZ1
Compact cassette	○	—	—	—	—	—	—	○
Mini duct	○	○	—	—	—	—	—	○
Slim duct	○	○	—	—	—	—	—	○
Wall mounted	KG	○	—	—	○	—	○	—
	KMTB	○	—	—	○	—	○	—
	KMCC	○	—	○	—	○	—	—
	KE	—	—	—	○	—	○	—
Ceiling	○	—	—	—	—	—	—	○
Floor	○	—	—	—	○	—	—	○

●:Accessory, ○: Optional, —: Not applicable

- *1: Optional Communication kit (UTY-TWBXF2) is necessary for the installation.
- *2: Optional Communication kit (UTY-TWRXZ2) is necessary for the installation.
- *3: Optional Communication kit (UTY-TWRXZ3) is necessary for the installation.
- *4: For details of WLAN control, refer to “Design & Technical manual” or “Setting manual” of WLAN control system.

NOTE: Combined use of MODBUS converter, KNX converter, and Wireless LAN adapter (UTY-TFSXZ1 only) is not allowed.

■ Parts

Air outlet shutter plate Model: UTR-YDZB	Insulation kit for high humidity Model: UTZ-KXGC
	 Insulation kit
Fresh air intake kit Model: UTZ-VXAA	External connect kit Model: UTY-XWZXZG
	
External connect kit Model: UTY-XWZX	External connect kit Model: UTY-XWZXZ5
 (x 1)  (x 1)	 (x 1)  (x 2)
External input and output PCB Model: UTY-XCSXZ2	External input and output PCB Model: UTY-XCSX
	
Communication kit Model: UTY-TWRXZ2	Communication kit Model: UTY-TWRXZ3
	
Communication kit Model: UTY-TWBXF2	MODBUS converter Model: UTY-VMSX
	

Split system converter Model: UTY-VTGX	Split system converter Model: UTY-VTGXV
	
KNX converter Model: UTY-VKSX	External switch controller Models: UTY-TERX
	
Remote sensor unit Model: UTY-XSZX	Auto louver grille kit Models: UTD-GXTA-W and UTD-GXTB-W
	
Wireless LAN adapter Models: UTY-TFSXZ1	Wireless LAN adapter Models: UTY-TFSXW1
	
Wireless LAN adapter Models: UTY-TFSXF2	
	

17. Indoor unit installation precautions

NOTE: The information listed below are general precautions.

Some models also include items that do not apply.

17-1. Places where prohibited for use

- Places where there is a danger of combustible gas leakage.
- Places where sulfur gas, chlorine gas, acid, alkali, or other matter which effects equipment is generated.
- Places where there is a lot of oil splash and steam such as kitchen or machinery room.
- Places where machinery which generates high frequencies is used.
- Ocean beaches and other areas where there is a lot of salt.
- Places where carbon fibers or any kind of powder suspended in the air.
- Inside of vehicles, ships, and other conveyances.
- Places where voltage fluctuations are large such as a factory.

17-2. Points to remember when installing

- The product shall be installed at a place which can withstand the weight and vibration of the indoor.
- To allow maintenance after refrigerant piping, drain piping, and electric wiring connection and installation, provide an installation service space and an inspection port, as required.
*Installation service space is shown on "[Dimensions](#)" on page 17.
- Be careful when installing the unit at the following places.

Condition	Contents	Countermeasures (Reference)
When the ceiling is high.	If the indoor unit is installed where the installation height given in the installation manual is exceeded, the temperature difference between the floor and ceiling of the room will be large and the heating effect will be poor. Moreover, even if the indoor unit is installed within the installation height, a similar phenomena will occur when installed in a room in which the doors are opened and closed frequently and hot air circulation is obstructed by furniture such as desks or chairs.	<ol style="list-style-type: none"> Switch the setting to the high ceiling mode. Install a circulator. Arrange the furniture in the room so that it does not obstruct the hot air.
When lower level directly contacts the outside air.	When the lower level of the room is a semi-open space such as warehouse or parking lot the surface temperature of the flooring will become low and the radiation of cold from the floor will increase. In this case, even if the room temperature is suitable, you may feel the foot level is cold.	
When the airflow distribution is poor.	When an indoor unit is installed in a position where the outlet airflow will directly contact people, a draft may be felt. In addition, when there are obstructions in the path of the intake and outlet airflow, the air distribution may become extremely bad.	<ol style="list-style-type: none"> Adjust the louver fins or take other measures matched to the site. Change the indoor unit outlet.

Condition	Contents	Countermeasures (Reference)
When inside the ceiling is high temperature and high humidity.	When the indoor unit is installed where the inside of the ceiling is 30 °C RH80% or greater, the dew point temperature of the outer perimeter may become higher than the cabinet surface temperature and moisture will condense on the surface of the cabinet and water drops may fall inside the room. ("Figure 17-1 Moist air curve") In addition, the humidity may vary considerably the same as when the inside of the ceiling is close to hermetically sealed and used as the outside air intake path.	<ol style="list-style-type: none"> 1. Add heat insulating material to the outside of the indoor unit cabinet. *Regarding the cassette type, use of optional High humidity correspondence kit is recommended. 2. Strengthen the heat insulating material of the refrigerant piping and drain piping too. ("Figure 17-2 Work method when reinforcing the heat insulation of on-site piping") 3. When the humidity inside the ceiling changes considerably, install a ventilation port.
When using an external duct.	When using an external duct to take in new fresh air, etc., condensation may form on the surface of the duct due to the effect of the outside air temperature and the humidity inside the ceiling.	Always perform heat insulation processing. (Heat insulating material: Glass wool 25 mm thick or more.)
When the remote controller installation site is bad.	If the cold or warm air blown out from the air conditioner directly contacts the thermostat section of the remote controller, the outlet temperature of the air conditioner may be sensed and room temperature control will be different from the room temperature, and "not cooled" or "not heated" or other trouble may occur. In addition, there is the possibility that the same kind of trouble may also occur when the remote controller is effected by direct sunlight.	<ol style="list-style-type: none"> 1. Install the remote controller where it will not be directly exposed to the cold or hot air. 2. Install the remote controller where it will not be directly exposed to sunlight or strong lighting.
When installation environment is quiet.	When the wall mounted type was installed in a bedroom, living room, or other quiet place, the sound of the refrigerant flow may be sensed as noise and must be taken into account.	<ol style="list-style-type: none"> 1. Plan installation of a model with external expansion valve. 2. Plan installation of a branch box farther from indoor unit. 3. Plan installation using another air conditioner.
When installing duct type in ceiling chamber system.	In the case of the ceiling chamber system (duct is not installed at indoor unit inlet side and room air is sucked into the indoor unit through the inside of the ceiling), the thermistor inside the indoor unit may not correctly detect the room temperature. <ul style="list-style-type: none"> • Heating operation: Room is not heated because the indoor unit is easily turned off by the thermostat. • Cooling operation: Room is too cold because the indoor unit is difficult to turn off by the thermostat. 	Replace the indoor unit thermistor with optional Remote sensor unit, and install the sensor where the room temperature can be correctly detected.
When the outlet air is sucked in at duct type.	Cooling operation does not cool the room and heating operation does not heat the room because the short circuited indoor unit is not turned on by the thermostat.	<ol style="list-style-type: none"> 1. Reconsider the ventilation port construction. 2. Replace the indoor unit thermistor with optional Remote sensor unit, and install the sensor where the room temperature can be correctly detected.
When using the wireless remote controller.	Signals may not be received when using it in a room illuminated by an inverter fluorescent lamp.	Turn on the fluorescent lamp and check if the indoor unit receives the signals from the remote controller. If the indoor unit does not receive the signals, consult an authorized service personnel.
When installing the inverter type.	It may generate noise in TV sets, stereos and PCs.	The inverter type should be installed at a sufficient distance from these equipments.




Figure 17-1 **Moist air curve**




Figure 17-2 **Work method when reinforcing the heat insulation of on-site piping**

Part 2. OUTDOOR UNIT (3 UNITS TYPE)

MULTI-SPLIT TYPE:

AOYG18KBTA3

AOYG24KBTA3

1. Specifications

Type	Inverter heat pump						
Model name	AOYG18KBTA3		AOYG24KBTA3				
Power source	230 V 50 Hz						
Available voltage range	198—264V						
Standard combination of indoor unit	Wall mounted ASYG07KMCC ×3		Wall mounted ASYG09KMCC ASYG09KMCC ×2				
Capacity	Cooling	Rated	kW	5.4	6.8		
		Btu/h		18,400	23,200		
		Min.—Max.	kW	1.8—7	1.8—8.5		
			Btu/h	6,100—23,800	6,100—29,000		
	Heating	Rated	kW	6.8	8.0		
		Btu/h		23,200	27,300		
		Min.—Max.	kW	2.0—8.0	2.0—9.2		
			Btu/h	6,800—27,300	6,800—31,400		
Input power	Cooling	Rated	kW	1.13	1.74		
		Max.		1.90	2.65		
	Heating	Rated		1.39	1.82		
		Max.		1.85	2.35		
Current	Cooling	Rated	A	5.1	7.7		
	Heating	Rated		6.2	8.1		
EER	Cooling		kW/kW	4.78	3.90		
COP	Heating			4.89	4.40		
Starting current			A	6.2	8.1		
Maximum operating current *1			A	12.0	14.5		
Fan	Type × Q'ty			Propeller × 1			
	Airflow rate	Cooling	m³/h	2,220	2,270		
		Heating		2,160	2,730		
Sound pressure level *2	Motor output			W	49		
	Cooling		dB (A)	46	48		
	Heating			49	53		
Heat exchanger	Dimension (H × W × D)			Main1: 672 × 881 × 18.19 Main2: 672 × 851 × 18.19			
	Fin pitch				1.3		
	Rows × Stages			Main1: 1 × 32 Main2: 1 × 32			
	Pipe type (Material)			Copper tube			
Compressor	Fin type (Material)			Aluminum			
	Type		DC twin rotary				
Refrigerant	Motor output	W		1,200			
	Type		R32 (675)				
Refrigerant oil	Charge	g		1,800			
	Type		RmM68AF				
Enclosure	Amount	cm³		550			
	Material		Steel sheet				
Dimensions (H × W × D)	Color		Beige (Approximate color of Munsell 10YR 7.5/1.0 NN)				
	Net	mm	716 × 820 × 315				
Weight	Gross		890 × 1,027 × 445				
	Net	kg	46				
Connection pipe	Gross		55				
	Size	mm (in)	Ø6.35 (Ø1/4) × 3				
Operation range	Gas		Ø9.52 (Ø3/8) × 3				
	Method		Ø9.52 (Ø3/8) × 2, Ø12.70 (Ø1/2) × 1				
	Pre-charge length (Total)	m	Flare				
	Maximum length (Total)		30				
	Maximum length (Each)		50				
	Minimum length (Total)		25				
	Minimum length (Each)		10				
	Maximum height difference between outdoor unit and each indoor units.		2.5				
	Maximum height difference between indoor units.		15				
Drain hose	Material		10				
	Tip diameter	mm	Ø13.0 (I.D.), Ø16.0 to Ø16.8 (O.D.)				

NOTES:


- Specifications are based on the following conditions:
 - Power source of specifications: 230 V
 - Pipe length: 5 m, Height difference: 0 m [Outdoor unit—Indoor unit]
 - Cooling: Indoor temperature of 27.0 °CDB/19.0 °CWB, and outdoor temperature of 35 °CDB/24.0 °CWB.
 - Heating: Indoor temperature of 20.0 °CDB/15.0 °CWB, and outdoor temperature of 7.0 °CDB/6.0 °CWB.
- *1: Maximum operating current is the total current of the indoor unit and the outdoor unit.
- *2: Sound pressure level
 - Measured values in manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- For other combination, refer to the combination table.
- The protective function might work when using it outside the operation range.
- This data is based on EN 14511 standard.

Specifications for ErP Lot10

Model name		AOYG18KBTA3		AOYG24KBTA3	
Energy efficiency class		A+++		A++	
Pdesign		Cooling	5.4 (35 °C)	6.8 (35 °C)	
SEER	Heating (Average)		5.0 (-10 °C)	6.0 (-10 °C)	
	Cooling	kWh/kWh	8.60	8.50	
SCOP		Heating (Average)	4.70	4.60	
Annual energy consumption	QCE	kWh/a	220	280	
	QHE (Average)		1,486	1,826	
Sound power level		Cooling	59	61	
		Heating	dB (A)	61	67
		HIGH			

2. Dimensions

2-1. Models: AOYG18KBTA3 and AOYG24KBTA3



3. Installation space

3-1. Models: AOYG18KBTA3 and AOYG24KBTA3

■ Space requirement

Provide sufficient installation space for product safety.

⚠ CAUTION

Keep the space shown in the installation examples.


If the installation is not performed accordingly, it could cause a short circuit and result in a lack of operating performance.

● Single outdoor unit installation


- When the upper space is open:

Unit: mm


Obstacles at rear only




Obstacles at rear and sides



Obstacles at front




Obstacles at front and rear




- When an obstruction in the upper space:

Unit: mm

Obstacles at rear and above



Obstacles at rear, sides, and above




● Multiple outdoor unit installation

- Provide at least 250 mm of space between the outdoor units if multiple units are installed.
 - When routing the piping from the side of an outdoor unit, provide space for piping.
 - No more than 3 units must be installed side by side.
- When 4 units or more are arranged in a line, provide the space as shown in the following example **"When an obstruction in the upper space:"**.


- When the upper space is open:**

Unit: mm


Obstacles at rear only



Obstacles at front only




Obstacles at front and rear



- When an obstruction in the upper space:**

Unit: mm


Obstacles at rear and above.





● Outdoor units installation in multi-row

Unit: mm

Single parallel unit arrangement




Multiple parallel unit arrangement

OUTDOOR UNIT
AOYG18-24KBTA3


4. Refrigerant circuit

4-1. Models: AOYG18KBTA3 and AOYG24KBTA3

OUTDOOR UNIT
AOYG18-24KBTA3OUTDOOR UNIT
AOYG18-24KBTA3 TH_D : THERMISTOR(DISCHARGE TEMP.) TH_o : THERMISTOR(OUTDOOR TEMP.) TH_{p0} : THERMISTOR(PIPE TEMP.) TH_c : THERMISTOR(COMPRESSOR TEMP.) TH_r : THERMISTOR(ROOM TEMP.) TH_{p1} : THERMISTOR(PIPE TEMP.) TH_{HM} : THERMISTOR(HEAT EXCHANGER MIDDLE TEMP.)

5. Wiring diagram

5-1. Models: AOYG18KBTA3 and AOYG24KBTA3



6. Capacity table

6-1. Combinations

■ Model: AOYG18KBTA3

● Cooling

Combination of indoor unit			Rated capacity for each indoor unit (kW)			Total capacity (kW)			Input power (kW)			EER (W/W)	Seasonal data			
Room		Total	Room			Min.	Rated	Max.	Min.	Rated	Max.		Pdesign (kW)	SEER (kWh/kWh)	Energy efficiency class	
1	2		1	2	3											
7	7	—	14	2.00	2.00	—	1.8	4.00	5.0	0.35	0.86	1.35	4.65	4.0	8.3	A++
7	9	—	16	2.00	2.50	—	1.8	4.50	5.7	0.35	1.03	1.54	4.36	4.5	8.2	A++
7	12	—	19	1.99	3.41	—	1.8	5.40	6.8	0.35	1.41	1.85	3.83	5.4	8.0	A++
7	14	—	21	1.80	3.60	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
9	9	—	18	2.50	2.50	—	1.8	5.00	6.4	0.35	1.23	1.74	4.06	5.0	8.1	A++
9	12	—	21	2.31	3.09	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
9	14	—	23	2.11	3.29	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
12	12	—	24	2.70	2.70	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
12	14	—	26	2.49	2.91	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
14	14	—	28	2.70	2.70	—	1.8	5.40	7.0	0.35	1.41	1.90	3.83	5.4	8.0	A++
7	7	7	21	1.80	1.80	1.80	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	7	9	23	1.64	1.64	2.12	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	7	12	26	1.45	1.45	2.50	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	7	14	28	1.35	1.35	2.70	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	9	9	25	1.52	1.94	1.94	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	9	12	28	1.35	1.74	2.31	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
7	9	14	30	1.26	1.62	2.52	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
9	9	9	27	1.80	1.80	1.80	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++
9	9	12	30	1.62	1.62	2.16	1.8	5.40	7.0	0.35	1.13	1.90	4.78	5.4	8.6	A+++

NOTES:

- 7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h
- The above is the value for connecting with wall-mounted type indoor unit.
- 2 or more indoor units should be connected.
- Cooling: Indoor temperature of 27 °CDB/19 °CWB and outdoor temperature of 35 °CDB.
- Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- The total ability of connected indoor unit is from 14,000 Btu/h up to 30,000 Btu/h.

● Heating

Combination of indoor unit			Rated capacity for each indoor unit (kBtu/h)			Total capacity (kBtu/h)			Input power (kW)			COP (W/W)	Seasonal data			
Room		Total	Room			Min.	Rated	Max.	Min.	Rated	Max.		Pdesign (kW)	SCOP (kWh/kWh)	Energy efficiency class	
1	3		1	2	3											
7	7	—	14	2.40	2.40	—	2.0	4.80	5.6	0.25	1.00	1.30	4.80	4.0	4.2	A+
7	9	—	16	2.40	3.00	—	2.0	5.40	6.4	0.25	1.21	1.48	4.45	4.0	4.2	A+
7	12	—	19	2.40	4.20	—	2.0	6.60	7.6	0.25	1.66	1.76	3.98	5.0	4.0	A+
7	14	—	21	2.27	4.53	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
9	9	—	18	3.00	3.00	—	2.0	6.00	7.2	0.25	1.44	1.67	4.17	4.5	4.1	A+
9	12	—	21	2.91	3.89	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
9	14	—	23	2.66	4.14	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
12	12	—	24	3.40	3.40	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
12	14	—	26	3.14	3.66	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
14	14	—	28	3.40	3.40	—	2.0	6.80	8.0	0.25	1.77	1.85	3.84	5.0	4.0	A+
7	7	7	21	2.27	2.27	2.27	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	7	9	23	2.07	2.07	2.66	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	7	12	26	1.83	1.83	3.14	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	7	14	28	1.70	1.70	3.40	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	9	9	25	1.90	2.45	2.45	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	9	12	28	1.70	2.19	2.91	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
7	9	14	30	1.59	2.04	3.17	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
9	9	9	27	2.27	2.27	2.27	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++
9	9	12	30	2.04	2.04	2.72	2.0	6.80	8.0	0.25	1.39	1.85	4.89	5.0	4.7	A++

NOTES:

- 7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h
- The above is the value for connecting with wall-mounted type indoor unit.
- 2 or more indoor units should be connected.
- Heating: Indoor temperature of 20 °CDB, and outdoor temperature of 7 °CDB/6 °CWB.
- Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- The total ability of connected indoor unit is from 14,000 Btu/h up to 30,000 Btu/h.

■ Model: AOYG24KBTA3

● Cooling

OUTDOOR UNIT
AOYG18-24KBTA3OUTDOOR UNIT
AOYG18-24KBTA3

Combination of indoor unit			Rated capacity for each indoor unit (kW)			Total capacity (kW)			Input power (kW)			EER (W/W)	Seasonal data			
Room		Total	Room			Min.	Rated	Max.	Min.	Rated	Max.		Pdesign (kW)	SEER (kWh/kWh)	Energy efficiency class	
1	2		1	2	3											
7	7	—	14	2.00	2.00	—	1.8	4.00	5.0	0.35	0.86	1.35	4.65	4.0	8.3	A++
7	9	—	16	2.00	2.50	—	1.8	4.50	5.7	0.35	1.03	1.54	4.36	4.5	8.2	A++
7	12	—	19	2.00	3.50	—	1.8	5.50	6.8	0.35	1.46	1.85	3.77	5.5	8.0	A++
7	14	—	21	2.00	4.00	—	1.8	6.00	7.5	0.35	1.73	2.20	3.48	6.0	7.6	A++
7	18	—	25	1.90	4.90	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
9	9	—	18	2.50	2.50	—	1.8	5.00	6.4	0.35	1.23	1.74	4.06	5.0	8.1	A++
9	12	—	21	2.50	3.50	—	1.8	6.00	7.5	0.35	1.73	2.20	3.48	6.0	7.6	A++
9	14	—	23	2.50	4.00	—	1.8	6.50	8.2	0.35	2.04	2.46	3.19	6.5	7.2	A++
9	18	—	27	2.27	4.53	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
12	12	—	24	3.40	3.40	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
12	14	—	26	3.14	3.66	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
12	18	—	30	2.72	4.08	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
14	14	—	28	3.40	3.40	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
14	18	—	32	2.98	3.82	—	1.8	6.80	8.5	0.35	2.26	2.65	3.01	6.8	6.9	A++
7	7	7	21	2.00	2.00	2.00	1.8	6.00	7.5	0.35	1.37	2.20	4.37	6.0	8.6	A+++
7	7	9	23	2.00	2.00	2.50	1.8	6.50	8.2	0.35	1.59	2.46	4.08	6.5	8.5	A+++
7	7	12	26	1.83	1.83	3.14	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	7	14	28	1.70	1.70	3.40	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	7	18	32	1.49	1.49	3.82	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	9	9	25	1.90	2.45	2.45	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	9	12	28	1.70	2.19	2.91	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	9	14	30	1.59	2.04	3.17	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	9	18	34	1.40	1.80	3.60	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	12	12	31	1.54	2.63	2.63	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	12	14	33	1.44	2.47	2.89	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
7	14	14	35	1.36	2.72	2.72	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	9	9	27	2.27	2.27	2.27	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	9	12	30	2.04	2.04	2.72	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	9	14	32	1.91	1.91	2.98	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	9	18	36	1.70	1.70	3.40	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	12	12	33	1.86	2.47	2.47	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
9	12	14	35	1.75	2.33	2.72	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++
12	12	12	36	2.27	2.27	2.27	1.8	6.80	8.5	0.35	1.74	2.65	3.90	6.8	8.5	A+++

NOTES:

- 7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h, 18: 18,000 Btu/h
- The above is the value for connecting with wall-mounted type indoor unit.
- 2 or more indoor units should be connected.
- Cooling: Indoor temperature of 27 °CDB/19 °CWB and outdoor temperature of 35 °CDB.
- Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- The total ability of connected indoor units is from 14,000 Btu/h up to 36,000 Btu/h.

● Heating

OUTDOOR UNIT
AOYG18-24KBTAA3OUTDOOR UNIT
AOYG18-24KBTAA3

Combination of indoor unit			Rated capacity for each indoor unit (kW)			Total capacity (kW)			Input power (kW)			COP (W/W)	Seasonal data			
Room		Total	Room			Min.	Rated	Max.	Min.	Rated	Max.		Pdesign (kW)	SEER (kWh/kWh)	Energy efficiency class	
1	2		1	2	3											
7	7	—	14	2.40	2.40	—	2.0	4.80	5.6	0.25	1.00	1.30	4.80	4.0	4.2	A+
7	9	—	16	2.40	3.00	—	2.0	5.40	6.4	0.25	1.21	1.48	4.45	4.0	4.2	A+
7	12	—	19	2.40	4.20	—	2.0	6.60	7.6	0.25	1.66	1.76	3.98	5.0	4.0	A+
7	14	—	21	2.40	4.80	—	2.0	7.20	8.4	0.25	1.86	2.07	3.87	5.4	4.0	A+
7	18	—	25	2.16	5.54	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
9	9	—	18	3.00	3.00	—	2.0	6.00	7.2	0.25	1.44	1.67	4.17	4.5	4.1	A+
9	12	—	21	3.00	4.20	—	2.0	7.20	8.4	0.25	1.86	2.07	3.87	5.4	4.0	A+
9	14	—	23	2.96	4.74	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
9	18	—	27	2.57	5.13	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
12	12	—	24	3.85	3.85	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
12	14	—	26	3.55	4.15	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
12	18	—	30	3.08	4.62	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
14	14	—	28	3.85	3.85	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
14	18	—	32	3.37	4.33	—	2.0	7.70	9.2	0.25	2.01	2.35	3.83	5.8	4.0	A+
7	7	7	21	2.40	2.40	2.40	2.0	7.20	8.4	0.25	1.61	2.07	4.48	5.4	4.7	A++
7	7	9	23	2.40	2.40	3.00	2.0	7.80	9.2	0.25	1.76	2.35	4.42	5.8	4.6	A++
7	7	12	26	2.15	2.15	3.70	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	7	14	28	2.00	2.00	4.00	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	7	18	32	1.75	1.75	4.50	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	9	9	25	2.24	2.88	2.88	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	9	12	28	2.00	2.57	3.43	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	9	14	30	1.87	2.40	3.73	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	9	18	34	1.65	2.12	4.23	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	12	12	31	1.80	3.10	3.10	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	12	14	33	1.70	2.91	3.39	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
7	14	14	35	1.60	3.20	3.20	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	9	9	27	2.67	2.67	2.67	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	9	12	30	2.40	2.40	3.20	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	9	14	32	2.25	2.25	3.50	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	9	18	36	2.00	2.00	4.00	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	12	12	33	2.18	2.91	2.91	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
9	12	14	35	2.06	2.74	3.20	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++
12	12	12	36	2.67	2.67	2.67	2.0	8.00	9.2	0.25	1.82	2.35	4.40	6.0	4.6	A++

NOTES:

- 7: 7,000 Btu/h, 9: 9,000 Btu/h, 12: 12,000 Btu/h, 14: 14,000 Btu/h, 18: 18,000 Btu/h
- The above is the value for connecting with wall-mounted type indoor unit.
- 2 or more indoor units should be connected.
- Heating: Indoor temperature of 20 °CDB, and outdoor temperature of 7 °CDB/6 °CWB.
- Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- The total ability of connected indoor units is from 14,000 Btu/h up to 36,000 Btu/h.

6-2. Cooling capacity

NOTE: Values mentioned in the table are calculated based on the maximum capacity.

■ Model: AOYG18KBTA3

Indoor unit connecting capacity	Outdoor temperature	Indoor temperature											
		18.0 °CDB		21.0 °CDB		23.0 °CDB		27.0 °CDB		29.0 °CDB		32.0 °CDB	
		12.0 °CWB		15.0 °CWB		16.0 °CWB		19.0 °CWB		21.0 °CWB		23.0 °CWB	
kBtu/h	°CDB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
30	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	35.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
	40.0	4.2	1.66	4.8	1.69	5.0	1.71	5.4	1.72	5.8	1.74	6.0	1.75
28	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
27	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
26	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
25	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
24	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
23	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
	46.0	4.2	1.66	4.8	1.69	5.0	1.71	5.4	1.72	5.8	1.74	6.0	1.75

Indoor unit connect-ing capacity	Outdoor temperature	Indoor temperature											
		18.0 °CDB		21.0 °CDB		23.0 °CDB		27.0 °CDB		29.0 °CDB		32.0 °CDB	
		12.0 °CWB		15.0 °CWB		16.0 °CWB		19.0 °CWB		21.0 °CWB		23.0 °CWB	
kBtu/h	°CDB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
21	-10.0	5.5	0.88	6.2	0.89	6.5	0.90	7.0	0.91	7.5	0.92	7.7	0.92
	0.0	5.5	1.04	6.2	1.06	6.5	1.07	7.0	1.08	7.5	1.10	7.7	1.10
	5.0	5.5	1.11	6.2	1.13	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.17
	10.0	5.5	1.21	6.2	1.23	6.5	1.24	7.0	1.25	7.5	1.27	7.7	1.28
	15.0	5.5	1.12	6.2	1.14	6.5	1.14	7.0	1.16	7.5	1.17	7.7	1.18
	20.0	5.5	1.05	6.2	1.07	6.5	1.07	7.0	1.09	7.5	1.10	7.7	1.10
	25.0	5.5	1.28	6.2	1.31	6.5	1.32	7.0	1.33	7.5	1.35	7.7	1.35
	30.0	5.5	1.48	6.2	1.50	6.5	1.51	7.0	1.53	7.5	1.55	7.7	1.56
	35.0	5.5	1.84	6.2	1.87	6.5	1.89	7.0	1.91	7.5	1.93	7.7	1.94
	40.0	4.9	1.75	5.5	1.78	5.8	1.80	6.2	1.82	6.6	1.84	6.8	1.85
19	46.0	4.2	1.66	4.8	1.69	5.0	1.71	5.4	1.72	5.8	1.74	6.0	1.75
	-10.0	5.3	0.84	6.0	0.86	6.4	0.86	6.8	0.87	7.3	0.88	7.5	0.89
	0.0	5.3	1.00	6.0	1.02	6.4	1.03	6.8	1.04	7.3	1.05	7.5	1.06
	5.0	5.3	1.07	6.0	1.09	6.4	1.10	6.8	1.11	7.3	1.12	7.5	1.13
	10.0	5.3	1.16	6.0	1.18	6.4	1.19	6.8	1.20	7.3	1.22	7.5	1.22
	15.0	5.3	1.07	6.0	1.09	6.4	1.10	6.8	1.11	7.3	1.12	7.5	1.13
	20.0	5.3	1.00	6.0	1.02	6.4	1.03	6.8	1.04	7.3	1.05	7.5	1.06
	25.0	5.3	1.23	6.0	1.25	6.4	1.26	6.8	1.28	7.3	1.29	7.5	1.30
	30.0	5.3	1.41	6.0	1.44	6.4	1.45	6.8	1.47	7.3	1.48	7.5	1.49
	35.0	5.3	1.76	6.0	1.79	6.4	1.81	6.8	1.83	7.3	1.85	7.5	1.86
18	40.0	4.7	1.68	5.3	1.71	5.6	1.72	6.0	1.74	6.4	1.76	6.6	1.77
	46.0	4.7	1.59	5.3	1.62	5.6	1.63	6.0	1.65	6.4	1.67	6.6	1.68
	-10.0	5.0	0.79	5.7	0.80	6.0	0.81	6.4	0.82	6.8	0.83	7.1	0.83
	0.0	5.0	0.94	5.7	0.96	6.0	0.97	6.4	0.98	6.8	0.99	7.1	0.99
	5.0	5.0	1.00	5.7	1.02	6.0	1.03	6.4	1.04	6.8	1.05	7.1	1.06
	10.0	5.0	1.09	5.7	1.11	6.0	1.12	6.4	1.13	6.8	1.14	7.1	1.15
	15.0	5.0	1.00	5.7	1.02	6.0	1.03	6.4	1.04	6.8	1.05	7.1	1.06
	20.0	5.0	0.94	5.7	0.96	6.0	0.97	6.4	0.98	6.8	0.99	7.1	1.00
	25.0	5.0	1.16	5.7	1.18	6.0	1.19	6.4	1.20	6.8	1.21	7.1	1.22
	30.0	5.0	1.33	5.7	1.35	6.0	1.36	6.4	1.38	6.8	1.39	7.1	1.40
16	35.0	5.0	1.66	5.7	1.68	6.0	1.70	6.4	1.72	6.8	1.74	7.1	1.75
	40.0	4.4	1.58	5.0	1.60	5.3	1.62	5.7	1.64	6.1	1.65	6.2	1.66
	46.0	4.4	1.50	5.0	1.52	5.3	1.54	5.7	1.55	6.1	1.57	6.2	1.58
	-10.0	4.5	0.70	5.1	0.71	5.3	0.72	5.7	0.73	6.1	0.73	6.3	0.74
	0.0	4.5	0.83	5.1	0.85	5.3	0.86	5.7	0.87	6.1	0.88	6.3	0.88
	5.0	4.5	0.89	5.1	0.91	5.3	0.91	5.7	0.92	6.1	0.93	6.3	0.94
	10.0	4.5	0.97	5.1	0.98	5.3	0.99	5.7	1.00	6.1	1.01	6.3	1.02
	15.0	4.5	0.89	5.1	0.91	5.3	0.91	5.7	0.92	6.1	0.93	6.3	0.94
	20.0	4.5	0.84	5.1	0.85	5.3	0.86	5.7	0.87	6.1	0.88	6.3	0.88
	25.0	4.5	1.02	5.1	1.04	5.3	1.05	5.7	1.06	6.1	1.07	6.3	1.08
14	30.0	4.5	1.18	5.1	1.20	5.3	1.21	5.7	1.22	6.1	1.24	6.3	1.24
	35.0	4.5	1.47	5.1	1.49	5.3	1.51	5.7	1.52	6.1	1.54	6.3	1.55
	40.0	4.0	1.40	4.5	1.42	4.7	1.43	5.0	1.45	5.4	1.47	5.6	1.47
	46.0	4.0	1.33	4.5	1.35	4.7	1.36	5.0	1.38	5.4	1.39	5.6	1.40
	-10.0	3.9	0.63	4.4	0.64	4.7	0.65	5.0	0.65	5.3	0.66	5.5	0.66
	0.0	3.9	0.75	4.4	0.76	4.7	0.77	5.0	0.78	5.3	0.79	5.5	0.79
	5.0	3.9	0.80	4.4	0.81	4.7	0.82	5.0	0.83	5.3	0.84	5.5	0.84
	10.0	3.9	0.87	4.4	0.88	4.7	0.89	5.0	0.90	5.3	0.91	5.5	0.92
	15.0	3.9	0.80	4.4	0.82	4.7	0.82	5.0	0.83	5.3	0.84	5.5	0.85
	20.0	3.9	0.75	4.4	0.77	4.7	0.77	5.0	0.78	5.3	0.79	5.5	0.79
12	25.0	3.9	0.92	4.4	0.94	4.7	0.95	5.0	0.96	5.3	0.97	5.5	0.97
	30.0	3.9	1.06	4.4	1.08	4.7	1.09	5.0	1.10	5.3	1.11	5.5	1.12
	35.0	3.9	1.32	4.4	1.34	4.7	1.35	5.0	1.37	5.3	1.39	5.5	1.39
	40.0	3.5	1.26	3.9	1.28	4.1	1.29	4.4	1.30	4.7	1.32	4.9	1.33
	46.0	3.5	1.19	3.9	1.21	4.1	1.22	4.4	1.24	4.7	1.25	4.9	1.26

NOTES:

- TC: Total Capacity (kW), IP: Input Power (kW)
- Values mentioned in the table are based on the following conditions:
 - Power source of specifications: 230 V
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- 2 or more indoor units should be connected.
- The total ability of connected indoor unit is from 14,000 Btu/h up to 30,000 Btu/h.
- Input in the table are calculated based on the maximum indoor unit input combinations.

● Compact cassette type

Model: AUXG07KVLA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
0.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
5.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
10.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
15.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
20.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
25.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
30.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
35.0	1.96	1.32	2.22	1.51	2.34	1.74	2.50	1.95	2.67	2.13	2.76	2.44
40.0	1.74	1.05	1.97	1.19	2.08	1.37	2.23	1.54	2.38	1.69	2.45	1.94
46.0	1.51	0.78	1.71	0.89	1.80	1.03	1.93	1.16	2.06	1.26	2.12	1.45

Model: AUXG09KVLA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
0.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
5.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
10.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
15.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
20.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
25.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
30.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
35.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
40.0	2.23	1.32	2.52	1.51	2.66	1.74	2.85	1.95	3.04	2.13	3.14	2.45
46.0	1.93	0.99	2.18	1.13	2.30	1.30	2.46	1.46	2.63	1.60	2.72	1.83

Model: AUXG12KVLA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
0.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
5.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
10.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
15.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
20.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
25.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
30.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
35.0	3.37	2.22	3.81	2.53	4.02	2.91	4.30	3.27	4.60	3.57	4.74	4.10
40.0	3.00	1.76	3.39	2.00	3.57	2.30	3.83	2.59	4.09	2.83	4.22	3.24
46.0	2.60	1.31	2.93	1.50	3.09	1.72	3.31	1.94	3.54	2.12	3.65	2.43

Model: AUXG14KVLA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
0.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
5.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
10.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
15.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
20.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
25.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
30.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
35.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
40.0	3.26	1.81	3.68	2.06	3.88	2.37	4.16	2.66	4.44	2.91	4.58	3.34
46.0	2.82	1.35	3.19	1.54	3.36	1.77	3.60	1.99	3.84	2.18	3.96	2.50

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Mini duct type

Model: ARXG07KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
0.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
5.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
15.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
20.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
25.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
30.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
35.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
40.0	1.74	1.07	1.97	1.22	2.08	1.41	2.23	1.58	2.38	1.73	2.45	1.99
46.0	1.51	0.80	1.71	0.92	1.80	1.06	1.93	1.19	2.06	1.30	2.12	1.49

Model: ARXG09KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
0.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
5.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
10.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
15.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
20.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
25.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
30.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
35.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
40.0	2.23	1.27	2.52	1.45	2.66	1.67	2.85	1.88	3.04	2.05	3.14	2.35
46.0	1.93	0.95	2.18	1.09	2.30	1.25	2.46	1.40	2.63	1.54	2.72	1.76

Model: ARXG12KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
0.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
5.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
15.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
20.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
25.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
30.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
35.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
40.0	3.00	1.71	3.39	1.95	3.57	2.24	3.83	2.52	4.09	2.76	4.22	3.16
46.0	2.60	1.28	2.93	1.46	3.09	1.68	3.31	1.89	3.54	2.06	3.65	2.36

Model: ARXG14KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
0.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
5.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
10.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
15.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
20.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
25.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
30.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
35.0	3.66	2.25	4.14	2.56	4.36	2.95	4.67	3.32	4.99	3.63	5.15	4.15
40.0	3.26	1.78	3.68	2.03	3.88	2.34	4.16	2.63	4.44	2.87	4.58	3.29
46.0	2.82	1.33	3.19	1.52	3.36	1.75	3.60	1.97	3.84	2.15	3.96	2.46

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m [Outdoor unit—Indoor unit]

● Slim duct type

Model: ARXG07KLLAP

Outdoor temperature (�b0;CDB)	Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>0.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>5.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>10.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>15.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>20.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>25.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>30.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>35.0</td><td>1.96</td><td>1.36</td><td>2.22</td><td>1.55</td><td>2.34</td><td>1.78</td><td>2.50</td><td>2.00</td><td>2.67</td><td>2.19</td><td>2.76</td><td>2.51</td></tr> <tr><td>40.0</td><td>1.74</td><td>1.07</td><td>1.97</td><td>1.22</td><td>2.08</td><td>1.41</td><td>2.23</td><td>1.58</td><td>2.38</td><td>1.73</td><td>2.45</td><td>1.99</td></tr> <tr><td>46.0</td><td>1.51</td><td>0.80</td><td>1.71</td><td>0.92</td><td>1.80</td><td>1.06</td><td>1.93</td><td>1.19</td><td>2.06</td><td>1.30</td><td>2.12</td><td>1.49</td></tr> </tbody> </table> </div> <div data-bbox="101 242 306 258" data-label="Text"> <p>Model: ARXG09KLLAP</p> </div> <div data-bbox="102 264 925 414" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>0.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>5.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>10.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>15.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>20.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>25.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>30.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>35.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>40.0</td><td>2.23</td><td>1.32</td><td>2.52</td><td>1.51</td><td>2.66</td><td>1.74</td><td>2.85</td><td>1.95</td><td>3.04</td><td>2.13</td><td>3.14</td><td>2.45</td></tr> <tr><td>46.0</td><td>1.93</td><td>0.99</td><td>2.18</td><td>1.13</td><td>2.30</td><td>1.30</td><td>2.46</td><td>1.46</td><td>2.63</td><td>1.60</td><td>2.72</td><td>1.83</td></tr> </tbody> </table> </div> <div data-bbox="101 425 306 440" data-label="Text"> <p>Model: ARXG12KLLAP</p> </div> <div data-bbox="102 446 925 600" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>0.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>5.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>10.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>15.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>20.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>25.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>30.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>35.0</td><td>3.37</td><td>2.27</td><td>3.81</td><td>2.59</td><td>4.02</td><td>2.99</td><td>4.30</td><td>3.35</td><td>4.60</td><td>3.67</td><td>4.74</td><td>4.20</td></tr> <tr><td>40.0</td><td>3.00</td><td>1.80</td><td>3.39</td><td>2.05</td><td>3.57</td><td>2.36</td><td>3.83</td><td>2.66</td><td>4.09</td><td>2.91</td><td>4.22</td><td>3.33</td></tr> <tr><td>46.0</td><td>2.60</td><td>1.35</td><td>2.93</td><td>1.54</td><td>3.09</td><td>1.77</td><td>3.31</td><td>1.99</td><td>3.54</td><td>2.17</td><td>3.65</td><td>2.49</td></tr> </tbody> </table> </div> <div data-bbox="101 609 306 625" data-label="Text"> <p>Model: ARXG14KLLAP</p> </div> <div data-bbox="102 631 925 774" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>0.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>5.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>10.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>15.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>20.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>25.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>30.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>35.0</td><td>3.66</td><td>2.34</td><td>4.14</td><td>2.67</td><td>4.36</td><td>3.08</td><td>4.67</td><td>3.46</td><td>4.99</td><td>3.78</td><td>5.15</td><td>4.33</td></tr> <tr><td>40.0</td><td>3.26</td><td>1.86</td><td>3.68</td><td>2.12</td><td>3.88</td><td>2.44</td><td>4.16</td><td>2.74</td><td>4.44</td><td>2.99</td><td>4.58</td><td>3.43</td></tr> <tr><td>46.0</td><td>2.82</td><td>1.39</td><td>3.19</td><td>1.58</td><td>3.36</td><td>1.82</td><td>3.60</td><td>2.05</td><td>3.84</td><td>2.24</td><td>3.96</td><td>2.57</td></tr> </tbody> </table> </div> <div data-bbox="101 784 176 799" data-label="Section-Header"> <h3>NOTES:</h3> </div> <div data-bbox="111 801 704 853" data-label="List-Group"> • TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW) • Values mentioned in the table are based on the following conditions: – Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit) </div> <div data-bbox="66 967 167 980" data-label="Page-Footer">6-2. Cooling capacity</div> <div data-bbox="477 960 520 973" data-label="Page-Footer">- 296 -</div> <div data-bbox="847 967 933 980" data-label="Page-Footer">6. Capacity table</div> <div data-bbox="0 125 39 215" data-label="Page-Footer">OUTDOOR UNIT AOYG18-24KBTA3</div> <div data-bbox="960 125 1000 215" data-label="Page-Footer">OUTDOOR UNIT AOYG18-24KBTA3</div>
-------------------------------------	---

● Wall mounted type

Model: ASYG07KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.74	0.87	1.97	1.00	2.08	1.15	2.23	1.29	2.38	1.41	2.45	1.61
46.0	1.51	0.65	1.71	0.74	1.80	0.86	1.93	0.96	2.06	1.05	2.12	1.21

Model: ASYG09KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.23	1.12	2.52	1.27	2.66	1.47	2.85	1.65	3.04	1.80	3.14	2.06
46.0	1.93	0.84	2.18	0.95	2.30	1.10	2.46	1.23	2.63	1.35	2.72	1.55

Model: ASYG12KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	3.00	1.50	3.39	1.71	3.57	1.97	3.83	2.21	4.09	2.42	4.22	2.77
46.0	2.60	1.12	2.93	1.28	3.09	1.47	3.31	1.66	3.54	1.81	3.65	2.08

Model: ASYG14KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
0.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
5.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
15.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
20.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
25.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
30.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
35.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
40.0	3.26	1.63	3.68	1.86	3.88	2.14	4.16	2.40	4.44	2.63	4.58	3.01
46.0	2.82	1.22	3.19	1.39	3.36	1.60	3.60	1.80	3.84	1.97	3.96	2.26

Model: ASYG07KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.74	0.87	1.97	1.00	2.08	1.15	2.23	1.29	2.38	1.41	2.45	1.61
46.0	1.51	0.65	1.71	0.74	1.80	0.86	1.93	0.96	2.06	1.05	2.12	1.21

Model: ASYG09KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.23	1.12	2.52	1.27	2.66	1.47	2.85	1.65	3.04	1.80	3.14	2.06
46.0	1.93	0.84	2.18	0.95	2.30	1.10	2.46	1.23	2.63	1.35	2.72	1.55

Model: ASYG12KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	3.00	1.50	3.39	1.71	3.57	1.97	3.83	2.21	4.09	2.42	4.22	2.77
46.0	2.60	1.12	2.93	1.28	3.09	1.47	3.31	1.66	3.54	1.81	3.65	2.08

Model: ASYG14KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
0.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
5.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
15.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
20.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
25.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
30.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
35.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
40.0	3.26	1.63	3.68	1.86	3.88	2.14	4.16	2.40	4.44	2.63	4.58	3.01
46.0	2.82	1.22	3.19	1.39	3.36	1.60	3.60	1.80	3.84	1.97	3.96	2.26

Model: ASYG07KETA, ASYG07KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.74	0.87	1.97	1.00	2.08	1.15	2.23	1.29	2.38	1.41	2.45	1.61
46.0	1.51	0.65	1.71	0.74	1.80	0.86	1.93	0.96	2.06	1.05	2.12	1.21

Model: ASYG09KETA, ASYG09KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.23	1.12	2.52	1.27	2.66	1.47	2.85	1.65	3.04	1.80	3.14	2.06
46.0	1.93	0.84	2.18	0.95	2.30	1.10	2.46	1.23	2.63	1.35	2.72	1.55

Model: ASYG12KETA, ASYG12KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	3.00	1.50	3.39	1.71	3.57	1.97	3.83	2.21	4.09	2.42	4.22	2.77
46.0	2.60	1.12	2.93	1.28	3.09	1.47	3.31	1.66	3.54	1.81	3.65	2.08

Model: ASYG14KETA, ASYG14KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
0.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
5.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
10.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
15.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
20.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
25.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
30.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
35.0	3.66	2.06	4.14	2.35	4.36	2.70	4.67	3.04	4.99	3.32	5.15	3.80
40.0	3.26	1.63	3.68	1.86	3.88	2.14	4.16	2.40	4.44	2.63	4.58	3.01
46.0	2.82	1.22	3.19	1.39	3.36	1.60	3.60	1.80	3.84	1.97	3.96	2.26

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Floor type

Model: AGYG09KVCA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
0.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
5.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
10.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
15.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
20.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
25.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
30.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
35.0	2.51	1.71	2.84	1.95	2.99	2.25	3.20	2.53	3.42	2.76	3.53	3.17
40.0	2.23	1.36	2.52	1.55	2.66	1.78	2.85	2.00	3.04	2.19	3.14	2.51
46.0	1.93	1.02	2.18	1.16	2.30	1.33	2.46	1.50	2.63	1.64	2.72	1.88

Model: AGYG12KVCA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
0.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
5.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
15.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
20.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
25.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
30.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
35.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
40.0	3.00	1.71	3.39	1.95	3.57	2.24	3.83	2.52	4.09	2.76	4.22	3.16
46.0	2.60	1.28	2.93	1.46	3.09	1.68	3.31	1.89	3.54	2.06	3.65	2.36

Model: AGYG14KVCA

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
0.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
5.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
10.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
15.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
20.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
25.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
30.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
35.0	3.66	2.28	4.14	2.60	4.36	2.99	4.67	3.36	4.99	3.68	5.15	4.21
40.0	3.26	1.81	3.68	2.06	3.88	2.37	4.16	2.66	4.44	2.91	4.58	3.34
46.0	2.82	1.35	3.19	1.54	3.36	1.77	3.60	1.99	3.84	2.18	3.96	2.50

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

■ Model: AOYG24KBTA3

OUTDOOR UNIT
AOYG18-24KBTAV

OUTDOOR UNIT
AOYG18-24KBTA3

Indoor unit connect-ing capacity	Outdoor temperature	Indoor temperature											
		18.0 °CDB		21.0 °CDB		23.0 °CDB		27.0 °CDB		29.0 °CDB		32.0 °CDB	
		12.0 °CWB		15.0 °CWB		16.0 °CWB		19.0 °CWB		21.0 °CWB		23.0 °CWB	
kBtu/h	°CDB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
28	-10.0	6.7	1.23	7.5	1.25	7.9	1.26	8.5	1.27	9.1	1.29	9.4	1.30
	0.0	6.7	1.46	7.5	1.49	7.9	1.50	8.5	1.52	9.1	1.54	9.4	1.55
	5.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	10.0	6.7	1.70	7.5	1.73	7.9	1.74	8.5	1.76	9.1	1.78	9.4	1.79
	15.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	20.0	6.7	1.47	7.5	1.49	7.9	1.51	8.5	1.52	9.1	1.54	9.4	1.55
	25.0	6.7	1.80	7.5	1.83	7.9	1.84	8.5	1.87	9.1	1.89	9.4	1.90
	30.0	6.7	2.07	7.5	2.10	7.9	2.12	8.5	2.15	9.1	2.17	9.4	2.18
	35.0	6.7	2.57	7.5	2.61	7.9	2.64	8.5	2.7	9.1	2.70	9.4	2.71
	40.0	5.5	2.12	6.2	2.16	6.5	2.17	7.0	2.20	7.5	2.22	7.7	2.24
27	46.0	4.3	1.67	4.8	1.70	5.1	1.71	5.5	1.73	5.8	1.75	6.0	1.76
	-10.0	6.7	1.23	7.5	1.25	7.9	1.26	8.5	1.27	9.1	1.29	9.4	1.30
	0.0	6.7	1.46	7.5	1.49	7.9	1.50	8.5	1.52	9.1	1.54	9.4	1.55
	5.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	10.0	6.7	1.70	7.5	1.73	7.9	1.74	8.5	1.76	9.1	1.78	9.4	1.79
	15.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	20.0	6.7	1.47	7.5	1.49	7.9	1.51	8.5	1.52	9.1	1.54	9.4	1.55
	25.0	6.7	1.80	7.5	1.83	7.9	1.84	8.5	1.87	9.1	1.89	9.4	1.90
	30.0	6.7	2.07	7.5	2.10	7.9	2.12	8.5	2.15	9.1	2.17	9.4	2.18
	35.0	6.7	2.57	7.5	2.61	7.9	2.64	8.5	2.7	9.1	2.70	9.4	2.71
26	40.0	5.5	2.12	6.2	2.16	6.5	2.17	7.0	2.20	7.5	2.22	7.7	2.24
	46.0	4.3	1.67	4.8	1.70	5.1	1.71	5.5	1.73	5.8	1.75	6.0	1.76
	-10.0	6.7	1.23	7.5	1.25	7.9	1.26	8.5	1.27	9.1	1.29	9.4	1.30
	0.0	6.7	1.46	7.5	1.49	7.9	1.50	8.5	1.52	9.1	1.54	9.4	1.55
	5.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	10.0	6.7	1.70	7.5	1.73	7.9	1.74	8.5	1.76	9.1	1.78	9.4	1.79
	15.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	20.0	6.7	1.47	7.5	1.49	7.9	1.51	8.5	1.52	9.1	1.54	9.4	1.55
	25.0	6.7	1.80	7.5	1.83	7.9	1.84	8.5	1.87	9.1	1.89	9.4	1.90
	30.0	6.7	2.07	7.5	2.10	7.9	2.12	8.5	2.15	9.1	2.17	9.4	2.18
25	35.0	6.7	2.57	7.5	2.61	7.9	2.64	8.5	2.7	9.1	2.70	9.4	2.71
	40.0	5.5	2.12	6.2	2.16	6.5	2.17	7.0	2.20	7.5	2.22	7.7	2.24
	46.0	4.3	1.67	4.8	1.70	5.1	1.71	5.5	1.73	5.8	1.75	6.0	1.76
	-10.0	6.7	1.23	7.5	1.25	7.9	1.26	8.5	1.27	9.1	1.29	9.4	1.30
	0.0	6.7	1.46	7.5	1.49	7.9	1.50	8.5	1.52	9.1	1.54	9.4	1.55
	5.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	10.0	6.7	1.70	7.5	1.73	7.9	1.74	8.5	1.76	9.1	1.78	9.4	1.79
	15.0	6.7	1.56	7.5	1.59	7.9	1.60	8.5	1.62	9.1	1.64	9.4	1.65
	20.0	6.7	1.47	7.5	1.49	7.9	1.51	8.5	1.52	9.1	1.54	9.4	1.55
	25.0	6.7	1.80	7.5	1.83	7.9	1.84	8.5	1.87	9.1	1.89	9.4	1.90
24	30.0	6.7	2.07	7.5	2.10	7.9	2.12	8.5	2.15	9.1	2.17	9.4	2.18
	35.0	6.7	2.57	7.5	2.61	7.9	2.64	8.5	2.7	9.1	2.70	9.4	2.71
	40.0	5.5	2.12	6.2	2.16	6.5	2.17	7.0	2.20	7.5	2.22	7.7	2.24
	46.0	4.3	1.67	4.8	1.70	5.1	1.71	5.5	1.73	5.8	1.75	6.0	1.76
	-10.0	6.7	1.21	7.5	1.23	7.9	1.24	8.5	1.26	9.1	1.27	9.4	1.28
	0.0	6.7	1.44	7.5	1.47	7.9	1.48	8.5	1.50	9.1	1.51	9.4	1.52
	5.0	6.7	1.54	7.5	1.57	7.9	1.58	8.5	1.60	9.1	1.61	9.4	1.62
	10.0	6.7	1.67	7.5	1.70	7.9	1.71	8.5	1.73	9.1	1.75	9.4	1.76
	15.0	6.7	1.54	7.5	1.57	7.9	1.58	8.5	1.60	9.1	1.62	9.4	1.63
	20.0	6.7	1.45	7.5	1.47	7.9	1.48	8.5	1.50	9.1	1.52	9.4	1.53
23	25.0	6.7	1.77	7.5	1.80	7.9	1.82	8.5	1.84	9.1	1.86	9.4	1.87
	30.0	6.7	2.04	7.5	2.07	7.9	2.09	8.5	2.11	9.1	2.14	9.4	2.15
	35.0	6.7	2.53	7.5	2.58	7.9	2.60	8.5	2.6	9.1	2.66	9.4	2.67
	40.0	5.5	2.09	6.2	2.13	6.5	2.14	7.0	2.17	7.5	2.19	7.7	2.20
	46.0	5.5	1.65	6.2	1.68	6.5	1.69	7.0	1.71	7.5	1.73	7.7	1.74
	-10.0	6.4	1.16	7.3	1.18	7.7	1.19	8.2	1.20	8.8	1.22	9.0	1.22
	0.0	6.4	1.38	7.3	1.41	7.7	1.42	8.2	1.43	8.8	1.45	9.0	1.46
	5.0	6.4	1.47	7.3	1.50	7.7	1.51	8.2	1.53	8.8	1.55	9.0	1.55
	10.0	6.4	1.60	7.3	1.63	7.7	1.64	8.2	1.66	8.8	1.68	9.0	1.69
	15.0	6.4	1.48	7.3	1.50	7.7	1.51	8.2	1.53	8.8	1.55	9.0	1.56
21	20.0	6.4	1.39	7.3	1.41	7.7	1.42	8.2	1.44	8.8	1.45	9.0	1.46
	25.0	6.4	1.70	7.3	1.73	7.7	1.74	8.2	1.76	8.8	1.78	9.0	1.79
	30.0	6.4	1.95	7.3	1.99	7.7	2.00	8.2	2.02	8.8	2.05	9.0	2.06
	35.0	6.4	2.42	7.3	2.47	7.7	2.49	8.2	2.5	8.8	2.54	9.0	2.56
	40.0	5.3	2.00	6.0	2.04	6.3	2.05	6.7	2.08	7.2	2.10	7.4	2.11
	46.0	5.3	1.58	6.0	1.60	6.3	1.62	6.7	1.64	7.2	1.65	7.4	1.66
	-10.0	5.9	1.04	6.6	1.06	7.0	1.07	7.5	1.08	8.0	1.09	8.3	1.10
	0.0	5.9	1.24	6.6	1.26	7.0	1.27	7.5	1.29	8.0	1.30	8.3	1.31
	5.0	5.9	1.32	6.6	1.35	7.0	1.36	7.5	1.37	8.0	1.39	8.3	1.39
	10.0	5.9	1.44	6.6	1.46	7.0	1.47	7.5	1.49	8.0	1.51	8.3	1.51
19	15.0	5.9	1.32	6.6	1.35	7.0	1.36	7.5	1.37	8.0	1.39	8.3	1.40
	20.0	5.9	1.24	6.6	1.27	7.0	1.28	7.5	1.29	8.0	1.30	8.3	1.31
	25.0	5.9	1.52	6.6	1.55	7.0	1.56	7.5	1.58	8.0	1.60	8.3	1.61
	30.0	5.9	1.75	6.6	1.78	7.0	1.80	7.5	1.82	8.0	1.84	8.3	1.85
	35.0	5.9	2.18	6.6	2.21	7.0	2.23	7.5	2.26	8.0	2.28	8.3	2.29
	40.0	4.8	1.79	5.5	1.83	5.7	1.84	6.2	1.86	6.6	1.88	6.8	1.89
	46.0	4.8	1.41	5.5	1.44	5.7	1.45	6.2	1.47	6.6	1.48	6.8	1.49
	-10.0	5.3	0.92	6.0	0.94	6.4	0.94	6.8	0.96	7.3	0.97	7.5	0.97
	0.0	5.3	1.10	6.0	1.12	6.4	1.13	6.8	1.14	7.3	1.15	7.5	1.16
	5.0	5.3	1.17	6.0	1.19	6.4	1.20	6.8	1.21	7.3	1.23	7.5	1.23
19	10.0	5.3	1.27	6.0	1								

Indoor unit connect-ing capacity	Outdoor temperature	Indoor temperature											
		18.0 °CDB		21.0 °CDB		23.0 °CDB		27.0 °CDB		29.0 °CDB		32.0 °CDB	
		12.0 °CWB		15.0 °CWB		16.0 °CWB		19.0 °CWB		21.0 °CWB		23.0 °CWB	
kBtu/h	°CDB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
18	-10.0	5.0	0.85	5.7	0.87	6.0	0.87	6.4	0.88	6.8	0.89	7.1	0.90
	0.0	5.0	1.02	5.7	1.03	6.0	1.04	6.4	1.05	6.8	1.07	7.1	1.07
	5.0	5.0	1.08	5.7	1.10	6.0	1.11	6.4	1.12	6.8	1.14	7.1	1.14
	10.0	5.0	1.18	5.7	1.20	6.0	1.21	6.4	1.22	6.8	1.24	7.1	1.24
	15.0	5.0	1.09	5.7	1.10	6.0	1.11	6.4	1.13	6.8	1.14	7.1	1.15
	20.0	5.0	1.02	5.7	1.04	6.0	1.05	6.4	1.06	6.8	1.07	7.1	1.08
	25.0	5.0	1.25	5.7	1.27	6.0	1.28	6.4	1.29	6.8	1.31	7.1	1.32
	30.0	5.0	1.44	5.7	1.46	6.0	1.47	6.4	1.49	6.8	1.51	7.1	1.51
	35.0	5.0	1.78	5.7	1.81	6.0	1.83	6.4	1.85	6.8	1.87	7.1	1.88
	40.0	4.1	1.47	4.7	1.50	4.9	1.51	5.3	1.53	5.6	1.54	5.8	1.55
16	46.0	4.1	1.16	4.7	1.18	4.9	1.19	5.3	1.20	5.6	1.22	5.8	1.22
	-10.0	4.5	0.73	5.1	0.75	5.3	0.75	5.7	0.76	6.1	0.77	6.3	0.77
	0.0	4.5	0.87	5.1	0.89	5.3	0.90	5.7	0.91	6.1	0.92	6.3	0.92
	5.0	4.5	0.93	5.1	0.95	5.3	0.96	5.7	0.97	6.1	0.98	6.3	0.98
	10.0	4.5	1.01	5.1	1.03	5.3	1.04	5.7	1.05	6.1	1.06	6.3	1.07
	15.0	4.5	0.93	5.1	0.95	5.3	0.96	5.7	0.97	6.1	0.98	6.3	0.99
	20.0	4.5	0.88	5.1	0.89	5.3	0.90	5.7	0.91	6.1	0.92	6.3	0.93
	25.0	4.5	1.07	5.1	1.09	5.3	1.10	5.7	1.11	6.1	1.13	6.3	1.13
	30.0	4.5	1.24	5.1	1.26	5.3	1.27	5.7	1.28	6.1	1.30	6.3	1.30
	35.0	4.5	1.53	5.1	1.56	5.3	1.57	5.7	1.59	6.1	1.61	6.3	1.62
14	40.0	3.7	1.27	4.1	1.29	4.4	1.30	4.7	1.31	5.0	1.33	5.2	1.34
	46.0	3.7	1.00	4.1	1.02	4.4	1.02	4.7	1.04	5.0	1.05	5.2	1.05
	-10.0	3.9	0.64	4.4	0.65	4.7	0.66	5.0	0.66	5.3	0.67	5.5	0.67
	0.0	3.9	0.76	4.4	0.78	4.7	0.78	5.0	0.79	5.3	0.80	5.5	0.80
	5.0	3.9	0.81	4.4	0.83	4.7	0.83	5.0	0.84	5.3	0.85	5.5	0.86
	10.0	3.9	0.88	4.4	0.90	4.7	0.91	5.0	0.92	5.3	0.93	5.5	0.93
	15.0	3.9	0.81	4.4	0.83	4.7	0.84	5.0	0.84	5.3	0.85	5.5	0.86
	20.0	3.9	0.76	4.4	0.78	4.7	0.78	5.0	0.79	5.3	0.80	5.5	0.81
	25.0	3.9	0.94	4.4	0.95	4.7	0.96	5.0	0.97	5.3	0.98	5.5	0.99
	30.0	3.9	1.08	4.4	1.10	4.7	1.11	5.0	1.12	5.3	1.13	5.5	1.14
10	35.0	3.9	1.34	4.4	1.36	4.7	1.37	5.0	1.39	5.3	1.40	5.5	1.41
	40.0	3.2	1.10	3.6	1.12	3.8	1.13	4.1	1.15	4.4	1.16	4.5	1.16
	46.0	3.2	0.87	3.6	0.89	3.8	0.89	4.1	0.90	4.4	0.91	4.5	0.92

NOTES:

- TC: Total Capacity (kW), IP: Input Power (kW)
- Values mentioned in the table are based on the following conditions:
 - Power source of specifications: 230 V
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- 2 or more indoor units should be connected.
- The total ability of connected indoor unit is from 14,000 Btu/h up to 36,000 Btu/h.
- Input in the table are calculated based on the maximum indoor unit input combinations.

● Compact cassette type

Model: AUXG07KVLA

Outdoor temperature (�b0;CDB)	Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>0.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>5.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>10.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>15.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>20.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>25.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>30.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>35.0</td><td>1.96</td><td>1.32</td><td>2.22</td><td>1.51</td><td>2.34</td><td>1.74</td><td>2.50</td><td>1.95</td><td>2.67</td><td>2.13</td><td>2.76</td><td>2.44</td></tr> <tr><td>40.0</td><td>1.61</td><td>0.89</td><td>1.82</td><td>1.01</td><td>1.91</td><td>1.17</td><td>2.05</td><td>1.31</td><td>2.19</td><td>1.43</td><td>2.26</td><td>1.64</td></tr> <tr><td>46.0</td><td>1.25</td><td>0.54</td><td>1.42</td><td>0.62</td><td>1.49</td><td>0.71</td><td>1.60</td><td>0.80</td><td>1.71</td><td>0.87</td><td>1.76</td><td>1.00</td></tr> </tbody> </table> </div> <div data-bbox="101 242 295 258" data-label="Text"> <p>Model: AUXG09KVLA</p> </div> <div data-bbox="102 264 925 414" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>0.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>5.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>10.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>15.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>20.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>25.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>30.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>35.0</td><td>2.51</td><td>1.67</td><td>2.84</td><td>1.90</td><td>2.99</td><td>2.19</td><td>3.20</td><td>2.46</td><td>3.42</td><td>2.69</td><td>3.53</td><td>3.09</td></tr> <tr><td>40.0</td><td>2.06</td><td>1.12</td><td>2.32</td><td>1.28</td><td>2.45</td><td>1.47</td><td>2.62</td><td>1.66</td><td>2.81</td><td>1.81</td><td>2.89</td><td>2.08</td></tr> <tr><td>46.0</td><td>1.61</td><td>0.68</td><td>1.81</td><td>0.78</td><td>1.91</td><td>0.90</td><td>2.05</td><td>1.01</td><td>2.19</td><td>1.10</td><td>2.26</td><td>1.26</td></tr> </tbody> </table> </div> <div data-bbox="101 425 295 441" data-label="Text"> <p>Model: AUXG12KVLA</p> </div> <div data-bbox="102 446 925 597" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>0.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>5.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>10.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>15.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>20.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>25.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>30.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>35.0</td><td>3.37</td><td>2.22</td><td>3.81</td><td>2.53</td><td>4.02</td><td>2.91</td><td>4.30</td><td>3.27</td><td>4.60</td><td>3.57</td><td>4.74</td><td>4.10</td></tr> <tr><td>40.0</td><td>2.76</td><td>1.49</td><td>3.12</td><td>1.70</td><td>3.29</td><td>1.96</td><td>3.53</td><td>2.20</td><td>3.77</td><td>2.40</td><td>3.89</td><td>2.75</td></tr> <tr><td>46.0</td><td>2.16</td><td>0.91</td><td>2.44</td><td>1.03</td><td>2.57</td><td>1.19</td><td>2.75</td><td>1.34</td><td>2.94</td><td>1.46</td><td>3.03</td><td>1.68</td></tr> </tbody> </table> </div> <div data-bbox="101 606 295 622" data-label="Text"> <p>Model: AUXG14KVLA</p> </div> <div data-bbox="102 628 925 777" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>0.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>5.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>10.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>15.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>20.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>25.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>30.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>35.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>40.0</td><td>3.21</td><td>1.64</td><td>3.63</td><td>1.87</td><td>3.83</td><td>2.15</td><td>4.10</td><td>2.42</td><td>4.38</td><td>2.65</td><td>4.52</td><td>3.03</td></tr> <tr><td>46.0</td><td>2.51</td><td>1.00</td><td>2.84</td><td>1.14</td><td>2.99</td><td>1.31</td><td>3.20</td><td>1.47</td><td>3.42</td><td>1.61</td><td>3.53</td><td>1.85</td></tr> </tbody> </table> </div> <div data-bbox="66 967 167 980" data-label="Page-Footer">6-2. Cooling capacity</div> <div data-bbox="477 961 520 974" data-label="Page-Footer">- 304 -</div> <div data-bbox="847 967 933 980" data-label="Page-Footer">6. Capacity table</div> <div data-bbox="0 125 37 215" data-label="Page-Footer">OUTDOOR UNIT AOYG18-24KBTA3</div> <div data-bbox="965 125 1000 215" data-label="Page-Footer">OUTDOOR UNIT AOYG18-24KBTA3</div>
-------------------------------------	--

Model: AUXG18KVLA

Outdoor temperature (°CDB)	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC
-10.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
0.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
5.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
10.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
15.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
20.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
25.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
30.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
35.0	4.80	2.91	5.42	3.31	5.72	3.81	6.12	4.28	6.54	4.69	6.74	5.37
40.0	3.93	1.95	4.45	2.23	4.69	2.56	5.02	2.88	5.36	3.15	5.53	3.61
46.0	3.07	1.19	3.47	1.36	3.66	1.56	3.92	1.75	4.19	1.92	4.32	2.20

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Mini duct type

Model: ARXG07KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
0.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
5.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
15.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
20.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
25.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
30.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
35.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
40.0	1.61	0.91	1.82	1.04	1.91	1.20	2.05	1.34	2.19	1.47	2.26	1.69
46.0	1.25	0.56	1.42	0.63	1.49	0.73	1.60	0.82	1.71	0.90	1.76	1.03

Model: ARXG09KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
0.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
5.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
10.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
15.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
20.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
25.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
30.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
35.0	2.51	1.61	2.84	1.83	2.99	2.11	3.20	2.37	3.42	2.59	3.53	2.97
40.0	2.06	1.08	2.32	1.23	2.45	1.42	2.62	1.59	2.81	1.74	2.89	2.00
46.0	1.61	0.66	1.81	0.75	1.91	0.86	2.05	0.97	2.19	1.06	2.26	1.22

Model: ARXG12KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
0.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
5.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
10.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
15.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
20.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
25.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
30.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
35.0	3.37	2.16	3.81	2.46	4.02	2.83	4.30	3.18	4.60	3.48	4.74	3.99
40.0	2.76	1.45	3.12	1.65	3.29	1.90	3.53	2.14	3.77	2.34	3.89	2.68
46.0	2.16	0.88	2.44	1.01	2.57	1.16	2.75	1.30	2.94	1.43	3.03	1.63

Model: ARXG14KSLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
0.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
5.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
10.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
15.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
20.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
25.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
30.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
35.0	3.92	2.41	4.43	2.74	4.67	3.16	5.00	3.55	5.35	3.88	5.51	4.45
40.0	3.21	1.62	3.63	1.85	3.83	2.12	4.10	2.39	4.38	2.61	4.52	2.99
46.0	2.51	0.99	2.84	1.12	2.99	1.29	3.20	1.45	3.42	1.59	3.53	1.82

Model: ARXG18KSLAP

Outdoor temperature (°CDB)	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC
-10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
0.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
5.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
15.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
20.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
25.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
30.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
35.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
40.0	3.93	2.01	4.45	2.29	4.69	2.64	5.02	2.96	5.36	3.24	5.53	3.71
46.0	3.07	1.22	3.47	1.40	3.66	1.61	3.92	1.80	4.19	1.97	4.32	2.26

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m [Outdoor unit—Indoor unit]

● Slim duct type

Model: ARXG07KLLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
0.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
5.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
10.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
15.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
20.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
25.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
30.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
35.0	1.96	1.36	2.22	1.55	2.34	1.78	2.50	2.00	2.67	2.19	2.76	2.51
40.0	1.61	0.91	1.82	1.04	1.91	1.20	2.05	1.34	2.19	1.47	2.26	1.69
46.0	1.25	0.56	1.42	0.63	1.49	0.73	1.60	0.82	1.71	0.90	1.76	1.03

Model: ARXG09KLLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
0.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
5.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
10.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
15.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
20.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
25.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
30.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
35.0	2.51	1.67	2.84	1.90	2.99	2.19	3.20	2.46	3.42	2.69	3.53	3.09
40.0	2.06	1.12	2.32	1.28	2.45	1.47	2.62	1.66	2.81	1.81	2.89	2.08
46.0	1.61	0.68	1.81	0.78	1.91	0.90	2.05	1.01	2.19	1.10	2.26	1.26

Model: ARXG12KLLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
0.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
5.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
10.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
15.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
20.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
25.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
30.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
35.0	3.37	2.27	3.81	2.59	4.02	2.99	4.30	3.35	4.60	3.67	4.74	4.20
40.0	2.76	1.53	3.12	1.74	3.29	2.01	3.53	2.26	3.77	2.47	3.89	2.83
46.0	2.16	0.93	2.44	1.06	2.57	1.22	2.75	1.37	2.94	1.50	3.03	1.72

Model: ARXG14KLLAP

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
0.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
5.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
10.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
15.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
20.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
25.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
30.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
35.0	3.92	2.51	4.43	2.86	4.67	3.29	5.00	3.70	5.35	4.05	5.51	4.64
40.0	3.21	1.69	3.63	1.92	3.83	2.21	4.10	2.49	4.38	2.72	4.52	3.12
46.0	2.51	1.03	2.84	1.17	2.99	1.35	3.20	1.52	3.42	1.66	3.53	1.90

Model: ARXG18KLLAP

Outdoor temperature (°CDB)	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC
-10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
0.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
5.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
15.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
20.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
25.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
30.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
35.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
40.0	3.93	2.01	4.45	2.29	4.69	2.64	5.02	2.96	5.36	3.24	5.53	3.71
46.0	3.07	1.22	3.47	1.40	3.66	1.61	3.92	1.80	4.19	1.97	4.32	2.26

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Wall mounted type

Model: ASYG07KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.61	0.74	1.82	0.84	1.91	0.97	2.05	1.09	2.19	1.20	2.26	1.37
46.0	1.25	0.45	1.42	0.51	1.49	0.59	1.60	0.67	1.71	0.73	1.76	0.83

Model: ASYG09KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.06	0.95	2.32	1.08	2.45	1.24	2.62	1.40	2.81	1.53	2.89	1.75
46.0	1.61	0.58	1.81	0.66	1.91	0.76	2.05	0.85	2.19	0.93	2.26	1.07

Model: ASYG12KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	2.76	1.27	3.12	1.45	3.29	1.67	3.53	1.88	3.77	2.06	3.89	2.35
46.0	2.16	0.78	2.44	0.89	2.57	1.02	2.75	1.14	2.94	1.25	3.03	1.43

Model: ASYG14KGTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
0.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
5.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
15.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
20.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
25.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
30.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
35.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
40.0	3.21	1.48	3.63	1.69	3.83	1.95	4.10	2.19	4.38	2.39	4.52	2.74
46.0	2.51	0.90	2.84	1.03	2.99	1.18	3.20	1.33	3.42	1.46	3.53	1.67

Model: ASYG18KMTB

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
0.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
5.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
10.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
15.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
20.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
25.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
30.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
35.0	4.80	3.24	5.42	3.69	5.72	4.25	6.12	4.77	6.54	5.22	6.74	5.98
40.0	3.93	2.18	4.45	2.48	4.69	2.86	5.02	3.21	5.36	3.51	5.53	4.02
46.0	3.07	1.33	3.47	1.51	3.66	1.74	3.92	1.96	4.19	2.14	4.32	2.45

Model: ASYG07KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.61	0.74	1.82	0.84	1.91	0.97	2.05	1.09	2.19	1.20	2.26	1.37
46.0	1.25	0.45	1.42	0.51	1.49	0.59	1.60	0.67	1.71	0.73	1.76	0.83

Model: ASYG09KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.06	0.95	2.32	1.08	2.45	1.24	2.62	1.40	2.81	1.53	2.89	1.75
46.0	1.61	0.58	1.81	0.66	1.91	0.76	2.05	0.85	2.19	0.93	2.26	1.07

Model: ASYG12KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	2.76	1.27	3.12	1.45	3.29	1.67	3.53	1.88	3.77	2.06	3.89	2.35
46.0	2.16	0.78	2.44	0.89	2.57	1.02	2.75	1.14	2.94	1.25	3.03	1.43

Model: ASYG14KMCC

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
0.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
5.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
15.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
20.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
25.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
30.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
35.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.5		

Model: ASYG07KETA, ASYG07KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
0.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
5.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
10.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
15.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
20.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
25.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
30.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
35.0	1.96	1.10	2.22	1.26	2.34	1.45	2.50	1.63	2.67	1.78	2.76	2.04
40.0	1.61	0.74	1.82	0.84	1.91	0.97	2.05	1.09	2.19	1.20	2.26	1.37
46.0	1.25	0.45	1.42	0.51	1.49	0.59	1.60	0.67	1.71	0.73	1.76	0.83

Model: ASYG09KETA, ASYG09KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
0.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
5.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
10.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
15.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
20.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
25.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
30.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
35.0	2.51	1.41	2.84	1.61	2.99	1.85	3.20	2.08	3.42	2.27	3.53	2.61
40.0	2.06	0.95	2.32	1.08	2.45	1.24	2.62	1.40	2.81	1.53	2.89	1.75
46.0	1.61	0.58	1.81	0.66	1.91	0.76	2.05	0.85	2.19	0.93	2.26	1.07

Model: ASYG12KETA, ASYG12KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
0.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
5.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
10.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
15.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
20.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
25.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
30.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
35.0	3.37	1.90	3.81	2.16	4.02	2.49	4.30	2.80	4.60	3.06	4.74	3.50
40.0	2.76	1.27	3.12	1.45	3.29	1.67	3.53	1.88	3.77	2.06	3.89	2.35
46.0	2.16	0.78	2.44	0.89	2.57	1.02	2.75	1.14	2.94	1.25	3.03	1.43

Model: ASYG14KETA, ASYG14KETA-B

Outdoor temperature	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
(°CDB)	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
0.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
5.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
10.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
15.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
20.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
25.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
30.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
35.0	3.92	2.20	4.43	2.51	4.67	2.89	5.00	3.25	5.35	3.55	5.51	4.07
40.0	3.21	1.48	3.63	1.69	3.83	1.95	4.10	2.19	4.38	2.39	4.52	2.74
46.0	2.51	0.90	2.84	1.03	2.99	1.18	3.20	1.33	3.42	1.46	3.53	1.67

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Ceiling type

Model: ABYG18KRTA

OUTDOOR UNIT
AOYG18-24KBTA3

OUTDOOR UNIT
AOYG18-24KBTA3

Outdoor temperature (°CDB)	Indoor temperature (°CDB / °CWB)											
	18.0 / 12.0		21.0 / 15.0		23.0 / 16.0		27.0 / 19.0		29.0 / 21.0		32.0 / 23.0	
TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	
-10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
0.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
5.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
10.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
15.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
20.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
25.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
30.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
35.0	4.80	2.99	5.42	3.41	5.72	3.92	6.12	4.41	6.54	4.82	6.74	5.52
40.0	3.93	2.01	4.45	2.29	4.69	2.64	5.02	2.96	5.36	3.24	5.53	3.71
46.0	3.07	1.22	3.47	1.40	3.66	1.61	3.92	1.80	4.19	1.97	4.32	2.26

NOTES:

- TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Floor type

Model: AGYG09KVCA

Outdoor temperature (�b0;CDB)	Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>0.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>5.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>10.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>15.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>20.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>25.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>30.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>35.0</td><td>2.51</td><td>1.71</td><td>2.84</td><td>1.95</td><td>2.99</td><td>2.25</td><td>3.20</td><td>2.53</td><td>3.42</td><td>2.76</td><td>3.53</td><td>3.17</td></tr> <tr><td>40.0</td><td>2.06</td><td>1.15</td><td>2.32</td><td>1.31</td><td>2.45</td><td>1.51</td><td>2.62</td><td>1.70</td><td>2.81</td><td>1.86</td><td>2.89</td><td>2.13</td></tr> <tr><td>46.0</td><td>1.61</td><td>0.70</td><td>1.81</td><td>0.80</td><td>1.91</td><td>0.92</td><td>2.05</td><td>1.04</td><td>2.19</td><td>1.13</td><td>2.26</td><td>1.30</td></tr> </tbody> </table> </div> <div data-bbox="101 242 298 258" data-label="Text"> <p>Model: AGYG12KVCA</p> </div> <div data-bbox="102 264 925 414" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>0.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>5.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>10.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>15.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>20.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>25.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>30.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>35.0</td><td>3.37</td><td>2.16</td><td>3.81</td><td>2.46</td><td>4.02</td><td>2.83</td><td>4.30</td><td>3.18</td><td>4.60</td><td>3.48</td><td>4.74</td><td>3.99</td></tr> <tr><td>40.0</td><td>2.76</td><td>1.45</td><td>3.12</td><td>1.65</td><td>3.29</td><td>1.90</td><td>3.53</td><td>2.14</td><td>3.77</td><td>2.34</td><td>3.89</td><td>2.68</td></tr> <tr><td>46.0</td><td>2.16</td><td>0.88</td><td>2.44</td><td>1.01</td><td>2.57</td><td>1.16</td><td>2.75</td><td>1.30</td><td>2.94</td><td>1.43</td><td>3.03</td><td>1.63</td></tr> </tbody> </table> </div> <div data-bbox="101 425 298 441" data-label="Text"> <p>Model: AGYG14KVCA</p> </div> <div data-bbox="102 446 925 598" data-label="Table"> <table border="1"> <thead> <tr> <th data-kind="parent" data-rs="2">Outdoor temperature (�b0;CDB)</th><th data-cs="12" data-kind="parent">Indoor temperature (�b0;CDB / �b0;CWB)</th><th data-kind="ghost"></th><th data-kind="ghost"></th></tr> <tr> <th data-kind="ghost"></th><th data-cs="2" data-kind="parent">18.0 / 12.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">21.0 / 15.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">23.0 / 16.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">27.0 / 19.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">29.0 / 21.0</th><th data-kind="ghost"></th><th data-cs="2" data-kind="parent">32.0 / 23.0</th><th data-kind="ghost"></th></tr> <tr> <th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th><th>TC</th><th>SHC</th></tr> </thead> <tbody> <tr><td>-10.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>0.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>5.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>10.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>15.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>20.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>25.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>30.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>35.0</td><td>3.92</td><td>2.44</td><td>4.43</td><td>2.78</td><td>4.67</td><td>3.20</td><td>5.00</td><td>3.60</td><td>5.35</td><td>3.94</td><td>5.51</td><td>4.51</td></tr> <tr><td>40.0</td><td>3.21</td><td>1.64</td><td>3.63</td><td>1.87</td><td>3.83</td><td>2.15</td><td>4.10</td><td>2.42</td><td>4.38</td><td>2.65</td><td>4.52</td><td>3.03</td></tr> <tr><td>46.0</td><td>2.51</td><td>1.00</td><td>2.84</td><td>1.14</td><td>2.99</td><td>1.31</td><td>3.20</td><td>1.47</td><td>3.42</td><td>1.61</td><td>3.53</td><td>1.85</td></tr> </tbody> </table> </div> <div data-bbox="101 606 176 622" data-label="Section-Header"> <h3>NOTES:</h3> </div> <div data-bbox="109 624 703 676" data-label="List-Group"> • TC: Total Capacity (kW), SHC: Sensible Heat Capacity (kW) • Values mentioned in the table are based on the following conditions: – Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit) </div> <div data-bbox="0 125 35 212" data-label="Page-Header">OUTDOOR UNIT AOYG18-24KBTA3</div> <div data-bbox="960 125 1000 212" data-label="Page-Header">OUTDOOR UNIT AOYG18-24KBTA3</div> <div data-bbox="66 965 167 977" data-label="Page-Footer">6-2. Cooling capacity</div> <div data-bbox="477 959 521 972" data-label="Page-Footer">- 314 -</div> <div data-bbox="847 965 933 977" data-label="Page-Footer">6. Capacity table</div>
-------------------------------------	--

6-3. Heating capacity

NOTE: Values mentioned in the table are calculated based on the maximum capacity.

■ Model: AOYG18KBTA3

Indoor unit connecting capacity	Outdoor temperature	Indoor temperature										
		16.0 °CDB		18.0 °CDB		20.0 °CDB		22.0 °CDB		24.0 °CDB		
kBtu/h	°CDB	°CWB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
30	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
28	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
27	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
26	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
25	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
24	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
23	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24
21	-15.0	-16.0	6.4	3.03	6.3	3.09	6.1	3.15	5.9	3.21	5.8	3.28
	-10.0	-11.0	7.2	3.21	7.1	3.27	6.9	3.34	6.7	3.41	6.5	3.47
	-5.0	-7.0	7.7	2.92	7.5	2.98	7.4	3.04	7.2	3.10	7.0	3.16
	0.0	-2.0	8.4	2.60	8.2	2.66	8.0	2.71	7.8	2.77	7.6	2.82
	5.0	3.0	8.4	2.02	8.2	2.07	8.0	2.11	7.8	2.15	7.6	2.19
	7.0	6.0	8.4	1.78	8.2	1.81	8.0	1.85	7.8	1.89	7.6	1.92
	10.0	8.0	8.4	1.67	8.2	1.70	8.0	1.74	7.8	1.77	7.6	1.81
	15.0	10.0	8.4	1.51	8.2	1.54	8.0	1.57	7.8	1.61	7.6	1.64
	20.0	15.0	8.4	1.28	8.2	1.30	8.0	1.33	7.8	1.36	7.6	1.38
	24.0	18.0	8.4	1.14	8.2	1.17	8.0	1.19	7.8	1.22	7.6	1.24

Indoor unit connecting capacity	Outdoor temperature	Indoor temperature										
		16.0 °CDB		18.0 °CDB		20.0 °CDB		22.0 °CDB		24.0 °CDB		
kBtu/h	°CDB	°CWB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
19	-15.0	-16.0	6.1	2.85	5.9	2.91	5.8	2.97	5.7	3.02	5.5	3.08
	-10.0	-11.0	6.9	3.02	6.7	3.08	6.5	3.14	6.4	3.20	6.2	3.27
	-5.0	-7.0	7.3	2.75	7.2	2.80	7.0	2.86	6.8	2.92	6.6	2.97
	0.0	-2.0	8.0	2.45	7.8	2.50	7.6	2.55	7.4	2.60	7.2	2.66
	5.0	3.0	8.0	1.90	7.8	1.94	7.6	1.98	7.4	2.02	7.2	2.06
	7.0	6.0	8.0	1.67	7.8	1.71	7.6	1.74	7.4	1.78	7.2	1.81
	10.0	8.0	8.0	1.57	7.8	1.60	7.6	1.64	7.4	1.67	7.2	1.70
	15.0	10.0	8.0	1.42	7.8	1.45	7.6	1.48	7.4	1.51	7.2	1.54
	20.0	15.0	8.0	1.20	7.8	1.23	7.6	1.25	7.4	1.28	7.2	1.30
	24.0	18.0	8.0	1.08	7.8	1.10	7.6	1.12	7.4	1.14	7.2	1.17
18	-15.0	-16.0	5.8	2.71	5.6	2.76	5.5	2.82	5.4	2.88	5.2	2.93
	-10.0	-11.0	6.5	2.87	6.3	2.93	6.2	2.99	6.0	3.05	5.9	3.11
	-5.0	-7.0	6.9	2.61	6.8	2.67	6.6	2.72	6.5	2.77	6.3	2.83
	0.0	-2.0	7.6	2.33	7.4	2.38	7.2	2.43	7.0	2.48	6.8	2.53
	5.0	3.0	7.6	1.81	7.4	1.85	7.2	1.89	7.0	1.92	6.8	1.96
	7.0	6.0	7.6	1.59	7.4	1.62	7.2	1.66	7.0	1.69	6.8	1.72
	10.0	8.0	7.6	1.49	7.4	1.52	7.2	1.56	7.0	1.59	6.8	1.62
	15.0	10.0	7.6	1.35	7.4	1.38	7.2	1.41	7.0	1.44	6.8	1.47
	20.0	15.0	7.6	1.14	7.4	1.17	7.2	1.19	7.0	1.21	6.8	1.24
	24.0	18.0	7.6	1.02	7.4	1.05	7.2	1.07	7.0	1.09	6.8	1.11
16	-15.0	-16.0	5.1	2.43	5.0	2.48	4.9	2.53	4.8	2.58	4.6	2.63
	-10.0	-11.0	5.8	2.57	5.6	2.63	5.5	2.68	5.4	2.73	5.2	2.79
	-5.0	-7.0	6.2	2.34	6.0	2.39	5.9	2.44	5.7	2.49	5.6	2.54
	0.0	-2.0	6.7	2.09	6.6	2.13	6.4	2.18	6.2	2.22	6.1	2.27
	5.0	3.0	6.7	1.62	6.6	1.66	6.4	1.69	6.2	1.73	6.1	1.76
	7.0	6.0	6.7	1.43	6.6	1.46	6.4	1.49	6.2	1.51	6.1	1.54
	10.0	8.0	6.7	1.34	6.6	1.37	6.4	1.40	6.2	1.42	6.1	1.45
	15.0	10.0	6.7	1.21	6.6	1.24	6.4	1.26	6.2	1.29	6.1	1.31
	20.0	15.0	6.7	1.02	6.6	1.05	6.4	1.07	6.2	1.09	6.1	1.11
	24.0	18.0	6.7	0.92	6.6	0.94	6.4	0.96	6.2	0.98	6.1	1.00
14	-15.0	-16.0	4.5	2.19	4.4	2.24	4.3	2.28	4.2	2.33	4.1	2.37
	-10.0	-11.0	5.1	2.32	4.9	2.37	4.8	2.42	4.7	2.46	4.6	2.51
	-5.0	-7.0	5.4	2.11	5.3	2.16	5.1	2.20	5.0	2.24	4.9	2.29
	0.0	-2.0	5.9	1.89	5.7	1.92	5.6	1.96	5.5	2.00	5.3	2.04
	5.0	3.0	5.9	1.46	5.7	1.49	5.6	1.53	5.5	1.56	5.3	1.59
	7.0	6.0	5.9	1.29	5.7	1.31	5.6	1.34	5.5	1.37	5.3	1.39
	10.0	8.0	5.9	1.21	5.7	1.23	5.6	1.26	5.5	1.28	5.3	1.31
	15.0	10.0	5.9	1.09	5.7	1.12	5.6	1.14	5.5	1.16	5.3	1.19
	20.0	15.0	5.9	0.92	5.7	0.94	5.6	0.96	5.5	0.98	5.3	1.00
	24.0	18.0	5.9	0.83	5.7	0.85	5.6	0.86	5.5	0.88	5.3	0.90

NOTES:

- TC: Total Capacity (kW), IP: Input Power (kW)
- Values mentioned in the table are based on the following conditions:
 - Power source of specifications: 230 V
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- 2 or more indoor units should be connected.
- The total ability of connected a indoor unit is from 14,000 Btu/h up to 30,000 Btu/h.
- Input in the table are calculated based on the maximum indoor unit input combinations.

● Compact cassette type

Model: AUXG07KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: AUXG09KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: AUXG12KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: AUXG14KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Mini duct type

Model: ARXG07KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ARXG09KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ARXG12KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ARXG14KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m [Outdoor unit—Indoor unit]

● Slim duct type

Model: ARXG07KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ARXG09KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ARXG12KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ARXG14KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Wall mounted type

Model: ASYG07KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

Model: ASYG07KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

Model: ASYG07KETA, ASYG07KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.23	2.18	2.13	2.07	2.02
-10.0	-11.0	2.53	2.47	2.41	2.35	2.29
-5.0	-7.0	2.70	2.64	2.58	2.51	2.45
0.0	-2.0	2.94	2.87	2.80	2.73	2.66
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KETA, ASYG09KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KETA, ASYG12KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KETA, ASYG14KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Floor type

Model: AGYG09KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.87	2.80	2.74	2.67	2.60
-10.0	-11.0	3.25	3.17	3.10	3.02	2.94
-5.0	-7.0	3.48	3.39	3.31	3.23	3.15
0.0	-2.0	3.78	3.69	3.60	3.51	3.42
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: AGYG12KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.83	3.74	3.65	3.56	3.47
-10.0	-11.0	4.33	4.23	4.13	4.02	3.92
-5.0	-7.0	4.64	4.53	4.42	4.31	4.20
0.0	-2.0	5.04	4.92	4.80	4.68	4.56
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: AGYG14KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.25	4.15	4.05	3.95	3.85
-10.0	-11.0	4.81	4.70	4.58	4.47	4.35
-5.0	-7.0	5.15	5.03	4.90	4.78	4.66
0.0	-2.0	5.60	5.46	5.33	5.20	5.06
5.0	3.0	5.60	5.46	5.33	5.20	5.06
7.0	6.0	5.60	5.46	5.33	5.20	5.06
10.0	8.0	5.60	5.46	5.33	5.20	5.06
15.0	10.0	5.60	5.46	5.33	5.20	5.06
20.0	15.0	5.60	5.46	5.33	5.20	5.06
24.0	18.0	5.60	5.46	5.33	5.20	5.06

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

■ Model: AOYG24KBTA3

OUTDOOR UNIT
AOYG18-24KBTAV

OUTDOOR UNIT
AOYG18-24KBTA3

Indoor unit connecting capacity	Outdoor temperature	Indoor temperature										
		16.0 °CDB		18.0 °CDB		20.0 °CDB		22.0 °CDB		24.0 °CDB		
kBtu/h	°CDB	°CWB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
27	-15.0	-16.0	6.5	3.05	6.3	3.12	6.2	3.18	6.0	3.25	5.9	3.31
	-10.0	-11.0	7.3	3.24	7.1	3.30	7.0	3.37	6.8	3.44	6.6	3.51
	-5.0	-7.0	7.8	2.95	7.6	3.01	7.4	3.07	7.2	3.13	7.1	3.19
	0.0	-2.0	8.9	2.63	8.7	2.68	8.5	2.74	8.3	2.79	8.1	2.85
	5.0	3.0	9.7	2.56	9.4	2.61	9.2	2.67	9.0	2.72	8.7	2.77
	7.0	6.0	9.7	2.25	9.4	2.30	9.2	2.34	9.0	2.39	8.7	2.44
	10.0	8.0	9.7	2.11	9.4	2.16	9.2	2.20	9.0	2.24	8.7	2.29
	15.0	10.0	9.7	1.91	9.4	1.95	9.2	1.99	9.0	2.03	8.7	2.07
	20.0	15.0	9.7	1.61	9.4	1.65	9.2	1.68	9.0	1.72	8.7	1.75
26	24.0	18.0	9.7	1.45	9.4	1.48	9.2	1.51	9.0	1.54	8.7	1.57
	-15.0	-16.0	6.5	3.05	6.3	3.12	6.2	3.18	6.0	3.25	5.9	3.31
	-10.0	-11.0	7.3	3.24	7.1	3.30	7.0	3.37	6.8	3.44	6.6	3.51
	-5.0	-7.0	7.8	2.95	7.6	3.01	7.4	3.07	7.2	3.13	7.1	3.19
	0.0	-2.0	8.9	2.63	8.7	2.68	8.5	2.74	8.3	2.79	8.1	2.85
	5.0	3.0	9.7	2.56	9.4	2.61	9.2	2.67	9.0	2.72	8.7	2.77
	7.0	6.0	9.7	2.25	9.4	2.30	9.2	2.34	9.0	2.39	8.7	2.44
	10.0	8.0	9.7	2.11	9.4	2.16	9.2	2.20	9.0	2.24	8.7	2.29
	15.0	10.0	9.7	1.91	9.4	1.95	9.2	1.99	9.0	2.03	8.7	2.07
25	20.0	15.0	9.7	1.61	9.4	1.65	9.2	1.68	9.0	1.72	8.7	1.75
	24.0	18.0	9.7	1.45	9.4	1.48	9.2	1.51	9.0	1.54	8.7	1.57
	-15.0	-16.0	6.5	3.05	6.3	3.12	6.2	3.18	6.0	3.25	5.9	3.31
	-10.0	-11.0	7.3	3.24	7.1	3.30	7.0	3.37	6.8	3.44	6.6	3.51
	-5.0	-7.0	7.8	2.95	7.6	3.01	7.4	3.07	7.2	3.13	7.1	3.19
	0.0	-2.0	8.9	2.63	8.7	2.68	8.5	2.74	8.3	2.79	8.1	2.85
	5.0	3.0	9.7	2.56	9.4	2.61	9.2	2.67	9.0	2.72	8.7	2.77
	7.0	6.0	9.7	2.25	9.4	2.30	9.2	2.34	9.0	2.39	8.7	2.44
	10.0	8.0	9.7	2.11	9.4	2.16	9.2	2.20	9.0	2.24	8.7	2.29
24	15.0	10.0	9.7	1.91	9.4	1.95	9.2	1.99	9.0	2.03	8.7	2.07
	20.0	15.0	9.7	1.61	9.4	1.65	9.2	1.68	9.0	1.72	8.7	1.75
	24.0	18.0	9.7	1.45	9.4	1.48	9.2	1.51	9.0	1.54	8.7	1.57
	-15.0	-16.0	6.5	3.01	6.3	3.07	6.2	3.13	6.0	3.19	5.9	3.26
	-10.0	-11.0	7.3	3.18	7.1	3.25	7.0	3.32	6.8	3.38	6.6	3.45
	-5.0	-7.0	7.8	2.90	7.6	2.96	7.4	3.02	7.2	3.08	7.1	3.14
	0.0	-2.0	8.9	2.59	8.7	2.64	8.5	2.70	8.3	2.75	8.1	2.80
	5.0	3.0	9.7	2.52	9.4	2.57	9.2	2.62	9.0	2.68	8.7	2.73
	7.0	6.0	9.7	2.21	9.4	2.26	9.2	2.31	9.0	2.35	8.7	2.40
23	10.0	8.0	9.7	2.08	9.4	2.12	9.2	2.16	9.0	2.21	8.7	2.25
	15.0	10.0	9.7	1.88	9.4	1.92	9.2	1.96	9.0	2.00	8.7	2.04
	20.0	15.0	9.7	1.59	9.4	1.62	9.2	1.66	9.0	1.69	8.7	1.72
	24.0	18.0	9.7	1.42	9.4	1.45	9.2	1.48	9.0	1.51	8.7	1.54
	-15.0	-16.0	6.5	3.01	6.3	3.07	6.2	3.13	6.0	3.19	5.9	3.26
	-10.0	-11.0	7.3	3.18	7.1	3.25	7.0	3.32	6.8	3.38	6.6	3.45
	-5.0	-7.0	7.8	2.90	7.6	2.96	7.4	3.02	7.2	3.08	7.1	3.14
	0.0	-2.0	8.9	2.59	8.7	2.64	8.5	2.70	8.3	2.75	8.1	2.80
	5.0	3.0	9.7	2.52	9.4	2.57	9.2	2.62	9.0	2.68	8.7	2.73
21	7.0	6.0	9.7	2.21	9.4	2.26	9.2	2.31	9.0	2.35	8.7	2.40
	10.0	8.0	9.7	2.08	9.4	2.12	9.2	2.16	9.0	2.21	8.7	2.25
	15.0	10.0	9.7	1.88	9.4	1.92	9.2	1.96	9.0	2.00	8.7	2.04
	20.0	15.0	9.7	1.59	9.4	1.62	9.2	1.66	9.0	1.69	8.7	1.72
	24.0	18.0	9.7	1.42	9.4	1.45	9.2	1.48	9.0	1.51	8.7	1.54
	-15.0	-16.0	5.9	2.72	5.8	2.78	5.6	2.84	5.5	2.89	5.3	2.95
	-10.0	-11.0	6.7	2.88	6.5	2.94	6.3	3.00	6.2	3.06	6.0	3.12
	-5.0	-7.0	7.1	2.62	6.9	2.68	6.8	2.73	6.6	2.79	6.4	2.84
	0.0	-2.0	8.1	2.34	7.9	2.39	7.7	2.44	7.6	2.49	7.4	2.54
19	5.0	3.0	8.8	2.28	8.6	2.33	8.4	2.38	8.2	2.42	8.0	2.47
	7.0	6.0	8.8	2.00	8.6	2.05	8.4	2.09	8.2	2.13	8.0	2.17
	10.0	8.0	8.8	1.88	8.6	1.92	8.4	1.96	8.2	2.00	8.0	2.04
	15.0	10.0	8.8	1.70	8.6	1.74	8.4	1.78	8.2	1.81	8.0	1.85
	20.0	15.0	8.8	1.44	8.6	1.47	8.4	1.50	8.2	1.53	8.0	1.56
	24.0	18.0	8.8	1.29	8.6	1.32	8.4	1.34	8.2	1.37	8.0	1.40
	-15.0	-16.0	5.3	2.44	5.2	2.49	5.1	2.54	5.0	2.59	4.8	2.64
	-10.0	-11.0	6.0	2.58	5.9	2.64	5.7	2.69	5.6	2.74	5.5	2.80
	-5.0	-7.0	6.4	2.35	6.3	2.40	6.1	2.45	6.0	2.50	5.8	2.55
18	0.0	-2.0	7.4	2.10	7.2	2.14	7.0	2.19	6.8	2.23	6.7	2.27
	5.0	3.0	8.0	2.04	7.8	2.09	7.6	2.13	7.4	2.17	7.2	2.21
	7.0	6.0	8.0	1.80	7.8	1.83	7.6	1.87	7.4	1.91	7.2	1.95
	10.0	8.0	8.0	1.69	7.8	1.72	7.6	1.76	7.4	1.79	7.2	1.83
	15.0	10.0	8.0	1.53	7.8	1.56	7.6	1.59	7.4	1.62	7.2	1.65
	20.0	15.0	8.0	1.29	7.8	1.32	7.6	1.34	7.4	1.37	7.2	1.40
	24.0	18.0	8.0	1.16	7.8	1.18	7.6	1.20	7.4	1.23	7.2	1.25
	-15.0	-16.0	5.1	2.30	4.9	2.34	4.8	2.39	4.7	2.44	4.6	2.49
	-10.0	-11.0	5.7	2.43	5.6	2.48	5.4	2.53	5.3	2.58	5.2	2.64
16	-5.0	-7.0	6.1	2.21	6.0	2.26	5.8	2.31	5.7	2.35	5.5	2.40
	0.0	-2.0	7.0	1.98	6.8	2.02	6.6	2.06	6.5	2.10	6.3	2.14
	5.0	3.0	7.6	1.92	7.4	1.96	7.2	2.00	7.0	2.04	6.8	2.08
	7.0	6.0	7.6	1.69	7.4	1.73	7.2	1.76	7.0	1.80	6.8	1.83
	10.0	8.0	7.6	1.59	7.4	1.62	7.2	1.65	7.0	1.69	6.8	1.72
	15.0	10.0	7.6	1.44	7.4	1.47	7.2	1.50	7.0	1.53	6.8	1.56
	20.0	15.0	7.6	1.21	7.4	1.24	7.2	1.26	7.0	1.29	6.8	1.32
	24.0	18.0	7.6	1.09	7.4	1.11	7.2	1.13	7.0	1.16	6.8	1.18
	-15.0	-16.0	4.5	2.01	4.4	2.05	4.3	2.10	4.2	2.14	4.1	2.18
15	-10.0	-11.0	5.1	2.13	5.0	2.18	4.8	2.22	4.7	2.27	4.6	2.31
	-5.0	-7.0	5.4	1.94	5.3	1.98	5.2	2.02	5.0	2.06	4.9	2.10
	0.0	-2.0	6.2	1.73	6.0	1.77	5.9	1.80	5.8	1.84	5.6	1.88
	5.0	3.0	6.7	1.69	6.6	1.72	6.4	1.76	6.2	1.79	6.1	1.83
	7.0	6.0	6.7	1.48	6.6	1.51	6.4	1.54	6.2	1.57	6.1	1.61
	10.0	8.0	6.7	1.39	6.6	1.42	6.4	1.45	6.2	1.48	6.1	1.51
	15.0	10.0	6.7	1.26	6.6	1.29	6.4	1.31	6.2	1.34	6.1	1.37
	20.0	15.0	6.7	1.06	6.6	1.09	6.4	1.11	6.2	1.13	6.1	

Indoor unit connecting capacity	Outdoor temperature	Indoor temperature										
		16.0 °CDB		18.0 °CDB		20.0 °CDB		22.0 °CDB		24.0 °CDB		
kBtu/h	°CDB	°CWB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
14	-15.0	-16.0	3.9	1.77	3.8	1.81	3.8	1.84	3.7	1.88	3.6	1.92
	-10.0	-11.0	4.4	1.87	4.3	1.91	4.2	1.95	4.1	1.99	4.0	2.03
	-5.0	-7.0	4.7	1.71	4.6	1.74	4.5	1.78	4.4	1.81	4.3	1.85
	0.0	-2.0	5.4	1.52	5.3	1.55	5.2	1.59	5.0	1.62	4.9	1.65
	5.0	3.0	5.9	1.48	5.7	1.51	5.6	1.54	5.5	1.58	5.3	1.61
	7.0	6.0	5.9	1.30	5.7	1.33	5.6	1.36	5.5	1.38	5.3	1.41
	10.0	8.0	5.9	1.22	5.7	1.25	5.6	1.27	5.5	1.30	5.3	1.32
	15.0	10.0	5.9	1.11	5.7	1.13	5.6	1.15	5.5	1.18	5.3	1.20
	20.0	15.0	5.9	0.94	5.7	0.95	5.6	0.97	5.5	0.99	5.3	1.01
	24.0	18.0	5.9	0.84	5.7	0.86	5.6	0.87	5.5	0.89	5.3	0.91

NOTES:

- TC: Total Capacity (kW), IP: Input Power (kW)
- Values mentioned in the table are based on the following conditions:
 - Power source of specifications: 230 V
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)
- 2 or more indoor units should be connected.
- The total ability of connected a indoor unit is from 14,000 Btu/h up to 36,000 Btu/h.
- Input in the table are calculated based on the maximum indoor unit input combinations.

● Compact cassette type

Model: AUXG07KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: AUXG09KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: AUXG12KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: AUXG14KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

Model: AUXG18KVLA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.66	4.55	4.44	4.32	4.21
-10.0	-11.0	5.28	5.16	5.03	4.91	4.78
-5.0	-7.0	5.63	5.50	5.36	5.23	5.09
0.0	-2.0	6.39	6.24	6.09	5.94	5.79
5.0	3.0	6.95	6.79	6.62	6.45	6.29
7.0	6.0	6.95	6.79	6.62	6.45	6.29
10.0	8.0	6.95	6.79	6.62	6.45	6.29
15.0	10.0	6.95	6.79	6.62	6.45	6.29
20.0	15.0	6.95	6.79	6.62	6.45	6.29
24.0	18.0	6.95	6.79	6.62	6.45	6.29

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Mini duct type

Model: ARXG07KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ARXG09KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ARXG12KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ARXG14KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

Model: ARXG18KSLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.66	4.55	4.44	4.32	4.21
-10.0	-11.0	5.28	5.16	5.03	4.91	4.78
-5.0	-7.0	5.63	5.50	5.36	5.23	5.09
0.0	-2.0	6.39	6.24	6.09	5.94	5.79
5.0	3.0	6.95	6.79	6.62	6.45	6.29
7.0	6.0	6.95	6.79	6.62	6.45	6.29
10.0	8.0	6.95	6.79	6.62	6.45	6.29
15.0	10.0	6.95	6.79	6.62	6.45	6.29
20.0	15.0	6.95	6.79	6.62	6.45	6.29
24.0	18.0	6.95	6.79	6.62	6.45	6.29

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m [Outdoor unit—Indoor unit]

● Slim duct type

Model: ARXG07KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ARXG09KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ARXG12KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ARXG14KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

Model: ARXG18KLLAP

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.66	4.55	4.44	4.32	4.21
-10.0	-11.0	5.28	5.16	5.03	4.91	4.78
-5.0	-7.0	5.63	5.50	5.36	5.23	5.09
0.0	-2.0	6.39	6.24	6.09	5.94	5.79
5.0	3.0	6.95	6.79	6.62	6.45	6.29
7.0	6.0	6.95	6.79	6.62	6.45	6.29
10.0	8.0	6.95	6.79	6.62	6.45	6.29
15.0	10.0	6.95	6.79	6.62	6.45	6.29
20.0	15.0	6.95	6.79	6.62	6.45	6.29
24.0	18.0	6.95	6.79	6.62	6.45	6.29

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Wall mounted type

Model: ASYG07KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KGTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

Model: ASYG18KMTB

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.66	4.55	4.44	4.32	4.21
-10.0	-11.0	5.28	5.16	5.03	4.91	4.78
-5.0	-7.0	5.63	5.50	5.36	5.23	5.09
0.0	-2.0	6.39	6.24	6.09	5.94	5.79
5.0	3.0	6.95	6.79	6.62	6.45	6.29
7.0	6.0	6.95	6.79	6.62	6.45	6.29
10.0	8.0	6.95	6.79	6.62	6.45	6.29
15.0	10.0	6.95	6.79	6.62	6.45	6.29
20.0	15.0	6.95	6.79	6.62	6.45	6.29
24.0	18.0	6.95	6.79	6.62	6.45	6.29

Model: ASYG07KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KMCC

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

Model: ASYG07KETA, ASYG07KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	1.97	1.92	1.88	1.83	1.78
-10.0	-11.0	2.23	2.18	2.13	2.07	2.02
-5.0	-7.0	2.38	2.32	2.27	2.21	2.15
0.0	-2.0	2.70	2.64	2.58	2.51	2.45
5.0	3.0	2.94	2.87	2.80	2.73	2.66
7.0	6.0	2.94	2.87	2.80	2.73	2.66
10.0	8.0	2.94	2.87	2.80	2.73	2.66
15.0	10.0	2.94	2.87	2.80	2.73	2.66
20.0	15.0	2.94	2.87	2.80	2.73	2.66
24.0	18.0	2.94	2.87	2.80	2.73	2.66

Model: ASYG09KETA, ASYG09KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: ASYG12KETA, ASYG12KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56

Model: ASYG14KETA, ASYG14KETA-B

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Ceiling type

Model: ABYG18KRTA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	4.66	4.55	4.44	4.32	4.21
-10.0	-11.0	5.28	5.16	5.03	4.91	4.78
-5.0	-7.0	5.63	5.50	5.36	5.23	5.09
0.0	-2.0	6.39	6.24	6.09	5.94	5.79
5.0	3.0	6.95	6.79	6.62	6.45	6.29
7.0	6.0	6.95	6.79	6.62	6.45	6.29
10.0	8.0	6.95	6.79	6.62	6.45	6.29
15.0	10.0	6.95	6.79	6.62	6.45	6.29
20.0	15.0	6.95	6.79	6.62	6.45	6.29
24.0	18.0	6.95	6.79	6.62	6.45	6.29

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

● Floor type

Model: AGYG09KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	2.53	2.47	2.41	2.35	2.29
-10.0	-11.0	2.87	2.80	2.74	2.67	2.60
-5.0	-7.0	3.06	2.99	2.92	2.84	2.77
0.0	-2.0	3.48	3.39	3.31	3.23	3.15
5.0	3.0	3.78	3.69	3.60	3.51	3.42
7.0	6.0	3.78	3.69	3.60	3.51	3.42
10.0	8.0	3.78	3.69	3.60	3.51	3.42
15.0	10.0	3.78	3.69	3.60	3.51	3.42
20.0	15.0	3.78	3.69	3.60	3.51	3.42
24.0	18.0	3.78	3.69	3.60	3.51	3.42

Model: AGYG12KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.38	3.30	3.22	3.14	3.06
-10.0	-11.0	3.83	3.74	3.65	3.56	3.47
-5.0	-7.0	4.08	3.99	3.89	3.79	3.69
0.0	-2.0	4.64	4.53	4.42	4.31	4.20
5.0	3.0	5.04	4.92	4.80	4.68	4.56
7.0	6.0	5.04	4.92	4.80	4.68	4.56
10.0	8.0	5.04	4.92	4.80	4.68	4.56
15.0	10.0	5.04	4.92	4.80	4.68	4.56
20.0	15.0	5.04	4.92	4.80	4.68	4.56
24.0	18.0	5.04	4.92	4.80	4.68	4.56


Model: AGYG14KVCA

Outdoor temperature		Indoor temperature (°CDB)				
		16.0	18.0	20.0	22.0	24.0
(°CDB)	(°CWB)	TC	TC	TC	TC	TC
-15.0	-16.0	3.94	3.85	3.75	3.66	3.56
-10.0	-11.0	4.47	4.36	4.26	4.15	4.04
-5.0	-7.0	4.76	4.65	4.54	4.42	4.31
0.0	-2.0	5.41	5.28	5.15	5.02	4.89
5.0	3.0	5.88	5.74	5.60	5.46	5.32
7.0	6.0	5.88	5.74	5.60	5.46	5.32
10.0	8.0	5.88	5.74	5.60	5.46	5.32
15.0	10.0	5.88	5.74	5.60	5.46	5.32
20.0	15.0	5.88	5.74	5.60	5.46	5.32
24.0	18.0	5.88	5.74	5.60	5.46	5.32

NOTES:

- TC: Total Capacity (kW)
- Values mentioned in the table are based on the following conditions:
 - Pipe length: 5 m, Height difference: 0 m (Outdoor unit—Indoor unit)

7. Capacity compensation rate for pipe length and height difference



7-1. Models: AOYG18KBTA3 and AOYG24KBTA3

NOTE: Values mentioned in the table are calculated based on the maximum capacity.

■ Indoor unit: 7,000 Btu/h

Cooling		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.956	0.942	0.928
		10	—	—	0.977	0.963	0.950	0.936
		5	—	0.992	0.985	0.971	0.957	0.943
		2.5	0.999	0.996	0.989	0.975	0.961	0.947
		0	1.003	1.000	0.993	0.979	0.965	0.951
	Indoor unit is lower than outdoor unit *2	-2.5	1.003	1.000	0.993	0.979	0.965	0.951
		-5	—	1.000	0.993	0.979	0.965	0.951
		-10	—	—	0.993	0.979	0.965	0.951
		-15	—	—	—	0.979	0.965	0.951

Heating		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.977	0.958	0.939
		10	—	—	0.993	0.977	0.958	0.939
		5	—	1.000	0.993	0.977	0.958	0.939
		2.5	0.990	1.000	0.993	0.977	0.958	0.939
		0	0.990	1.000	0.993	0.977	0.958	0.939
	Indoor unit is lower than outdoor unit *2	-2.5	0.988	0.997	0.991	0.975	0.956	0.937
		-5	—	0.995	0.988	0.972	0.953	0.934
		-10	—	—	0.983	0.967	0.948	0.930
		-15	—	—	—	0.962	0.944	0.925

■ Indoor unit: 9,000 Btu/h

OUTDOOR UNIT
AOYG18-24KBTA3OUTDOOR UNIT
AOYG18-24KBTA3

Cooling		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.956	0.942	0.928
		10	—	—	0.977	0.963	0.950	0.936
		5	—	0.992	0.985	0.971	0.957	0.943
		2.5	1.003	0.996	0.989	0.975	0.961	0.947
	Indoor unit is lower than outdoor unit *2	0	1.007	1.000	0.993	0.979	0.965	0.951
		-2.5	1.007	1.000	0.993	0.979	0.965	0.951
		-5	—	1.000	0.993	0.979	0.965	0.951
		-10	—	—	0.993	0.979	0.965	0.951
		-15	—	—	—	0.979	0.965	0.951

Heating		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.977	0.958	0.939
		10	—	—	0.993	0.977	0.958	0.939
		5	—	1.000	0.993	0.977	0.958	0.939
		2.5	0.993	1.000	0.993	0.977	0.958	0.939
	Indoor unit is lower than outdoor unit *2	0	0.993	1.000	0.993	0.977	0.958	0.939
		-2.5	0.991	0.997	0.991	0.975	0.956	0.937
		-5	—	0.995	0.988	0.972	0.953	0.934
		-10	—	—	0.983	0.967	0.948	0.930
		-15	—	—	—	0.962	0.944	0.925

■ Indoor unit: 12,000 Btu/h

Cooling		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.933	0.899	0.859
		10	—	—	0.970	0.940	0.906	0.866
		5	—	0.992	0.978	0.948	0.913	0.873
		2.5	1.010	0.996	0.982	0.952	0.917	0.876
	Indoor unit is lower than outdoor unit *2	0	1.014	1.000	0.986	0.956	0.921	0.880
		-2.5	1.014	1.000	0.986	0.956	0.921	0.880
		-5	—	1.000	0.986	0.956	0.921	0.880
		-10	—	—	0.986	0.956	0.921	0.880
		-15	—	—	—	0.956	0.921	0.880

Heating		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.975	0.957	0.940
		10	—	—	0.990	0.975	0.957	0.940
		5	—	1.000	0.990	0.975	0.957	0.940
		2.5	0.995	1.000	0.990	0.975	0.957	0.940
	Indoor unit is lower than outdoor unit *2	0	0.995	1.000	0.990	0.975	0.957	0.940
		-2.5	0.993	0.997	0.988	0.973	0.955	0.938
		-5	—	0.995	0.985	0.970	0.952	0.936
		-10	—	—	0.980	0.965	0.947	0.931
		-15	—	—	—	0.960	0.943	0.926

■ Indoor unit: 14,000 Btu/h

Cooling		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.969	0.962	0.953
		10	—	—	0.982	0.977	0.970	0.961
		5	—	0.992	0.990	0.985	0.977	0.968
		2.5	0.998	0.996	0.994	0.989	0.981	0.972
	Indoor unit is lower than outdoor unit *2	0	1.002	1.000	0.998	0.993	0.985	0.976
		-2.5	1.002	1.000	0.998	0.993	0.985	0.976
		-5	—	1.000	0.998	0.993	0.985	0.976
		-10	—	—	0.998	0.993	0.985	0.976
		-15	—	—	—	0.993	0.985	0.976

Heating		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.967	0.943	0.917
		10	—	—	0.990	0.967	0.943	0.917
		5	—	1.000	0.990	0.967	0.943	0.917
		2.5	1.010	1.000	0.990	0.967	0.943	0.917
	Indoor unit is lower than outdoor unit *2	0	1.010	1.000	0.990	0.967	0.943	0.917
		-2.5	1.008	0.997	0.988	0.965	0.941	0.915
		-5	—	0.995	0.985	0.962	0.938	0.912
		-10	—	—	0.980	0.957	0.934	0.908
		-15	—	—	—	0.952	0.929	0.903

■ Indoor unit: 18,000 Btu/h

Cooling		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.977	0.968	0.953
		10	—	—	0.986	0.985	0.976	0.960
		5	—	0.992	0.994	0.993	0.984	0.968
		2.5	0.993	0.996	0.998	0.998	0.988	0.972
	Indoor unit is lower than outdoor unit *2	0	0.997	1.000	1.002	1.002	0.992	0.976
		-2.5	0.997	1.000	1.002	1.002	0.992	0.976
		-5	—	1.000	1.002	1.002	0.992	0.976
		-10	—	—	1.002	1.002	0.992	0.976
		-15	—	—	—	1.002	0.992	0.976

Heating		Pipe length						
		m	2.5	5	10	15	20	25
Height difference H (m)	Indoor unit is higher than outdoor unit *1	15	—	—	—	0.964	0.939	0.913
		10	—	—	0.988	0.964	0.939	0.913
		5	—	1.000	0.988	0.964	0.939	0.913
		2.5	1.008	1.000	0.988	0.964	0.939	0.913
	Indoor unit is lower than outdoor unit *2	0	1.008	1.000	0.988	0.964	0.939	0.913
		-2.5	1.006	0.997	0.986	0.962	0.937	0.911
		-5	—	0.995	0.983	0.959	0.934	0.908
		-10	—	—	0.978	0.954	0.930	0.904
		-15	—	—	—	0.950	0.925	0.899

8. Additional charge calculation

8-1. Model: AOYG18KBTA3

Refrigerant type	R32			
Refrigerant amount	g	1,800		

Refrigerant charge					
Total pipe length	m	30 or less	40	50 (Max.)	20 g/m
Additional charge amount	g	0	200	400	

8-2. Model: AOYG24KBTA3

Refrigerant type	R32			
Refrigerant amount	g	1,800		

Refrigerant charge					
Total pipe length	m	30 or less	40	50 (Max.)	20 g/m
Additional charge amount	g	0	200	400	

9. Airflow

9-1. Model: AOYG18KBTA3

● Cooling

m^3/h	2,220
l/s	617
CFM	1,307

● Heating

m^3/h	2,160
l/s	600
CFM	1,271

9-2. Model: AOYG24KBTA3

● Cooling

m^3/h	2,270
l/s	631
CFM	1,336

● Heating


m^3/h	2,730
l/s	758
CFM	1,607

10. Operation noise (sound pressure)


10-1. Noise level curve

■ Model: AOYG18KBTA3

● Cooling




● Heating




■ Model: AOYG24KBTA3


● Cooling



● Heating



10-2. Sound level check point



NOTE: Detailed shape of the actual outdoor unit might be slightly different from the one illustrated above.

11. Electrical characteristics

Model name			AOYG18KBTA3	AOYG24KBTA3
Power supply	Voltage	V	230 ~	
	Frequency	Hz	50	
Maximum operating current *1			A	12.0 14.5
Starting current			A	6.2 8.1
Wiring spec. *2	Main fuse (Circuit breaker) current	A	15	20
	Power cable	mm ²	2.5	
	Connection cable *3	Cross-sectional area	1.5	
	Limited wiring length	m	26	

*1: Maximum operating current is the total current of the indoor unit and the outdoor unit.

*2: Selected sample based on Japan Electrotechnical Standards and Codes Committee E0005. As the regulations of wire size and circuit breaker differ in each country or region, select appropriate devices complied to the regional standard.

*3: This is the wiring length in case voltage descent is less than 2%. When the wiring length becomes longer, select the wiring of a more larger diameter.

12. Safety devices

Type of protection	Protection form	Model	
		AOYG18KBTA3	AOYG24KBTA3
Circuit protection	Current fuse (Main PCB)	250 V, 5 A 250 V, 20 A 250 V, 3.15 A	250 V, 5 A 250 V, 25 A 250 V, 3.15 A
Fan motor protection	Thermal protector	Activate	125 ±10°C Fan motor stop
		Reset	120 ±10°C Fan motor restart
Compressor protection	Temperature thermistor (Discharge temp.)	Activate	110°C Compressor stop
		Reset	After 7 minutes Compressor restart
	Temperature thermistor (Compressor bottom temp.)	Activate	— 108°C Compressor stop
		Reset	— After 3 minutes, and 80°C or less Compressor restart
	Thermal protection program (Outdoor temp.) (Only in COOL or DRY mode)	Activate	-20°C Compressor stop
		Reset	-15°C Compressor restart

13. Function settings

13-1. Setting methods


⚠ WARNING

Never touch electrical components such as the terminal blocks or reactor except the switch on the display board. It may cause a serious accident such as electric shock.

⚠ CAUTION


- Once refrigerant charging is completed, be sure to open the valve prior to performing the local settings. Otherwise, the compressor may fail.
- Discharge any static electricity from your body before touching the push switches. Never touch any terminal or pattern of any parts on the control board.

The positions of the switches on the outdoor unit control board are shown in the figure below.



■ Setting method

Various settings can be adjusted by changing DIP switches and push switches on the PCB of the outdoor unit.



1. Be sure to disconnect the power supply or turn off the breaker.
2. Change the DIP switch setting according to the required setting.

■ Description of display

LED lamp			Function or operation method
(1) POWER/MODE		Green	<ul style="list-style-type: none"> Turns on when the power supply is ON (Including when error occurs). Indicate the MODE by the number of flashes when the installation function is active.
(2) ERROR		Red	Flashes at high-speed when there is an error.
(3) MONITOR	A	Red	<ul style="list-style-type: none"> Displays the location and contents of errors when there is an error. (Refer to Chapter 14-3. "Error code" on page 358 for details.) Displays when check run is activated. (Refer to Chapter 14-1. "Check run" on page 351 for details.)
	B	Red	
	C	Red	
	D	Red	
	E	Red	
	F	Red	

Switch		Function or operation method	Factory setting
SW1	Push	<ul style="list-style-type: none"> For the test run start and stop. For the pump down start and stop. 	—
SW2	Push	<ul style="list-style-type: none"> For when check run function is activated. For displaying the check run. For resetting the Automatic wiring correction memory. 	—
SET1-1	DIP	For selecting cooling or heating during test operation.	OFF
SET1-2	DIP	For switching SW1 operation.	OFF
SET1-3	DIP	(Prohibited)	OFF (Do not change)
SET1-4	DIP	For outdoor unit low noise operation function.	OFF
SET2-1	DIP	For selecting outdoor unit low noise operation function.	OFF
SET2-2	DIP	(Prohibited)	OFF (Do not change)
SET2-3	DIP	Changing the current limit	OFF
SET2-4	DIP		

Be sure to disconnect the power supply or turn off the breaker before changing the DIP switch setting.

13-2. Outdoor unit low noise operation function (option)

Change the outdoor unit low noise operation by using this setting.

⚠ CAUTION

- When the low noise operation function is working, cooling and heating capacity will decrease.
- When changing the settings, explain to the customer beforehand that the capacity decreases.

NOTES:

- When SET1-4 is OFF, optional Central remote controller is required to use this function.
- When SET1-4 is ON, “Operation” and “Non-operation” mode of this function cannot be switched from the Central remote controller.

SET1-4	Setting	Factory setting
ON	Continuous operation	
OFF	Follow the Central remote controller settings	◆

SET2-1	Setting	Factory setting
ON	Lower	
OFF	Low	◆

13-3. Changing the current limit function

Change the outdoor unit current limit function by using this setting.

⚠ CAUTION

- When the current limited function is working, cooling and heating capacity will decrease.
- When changing the settings, explain to the customer beforehand that the capacity decreases.

SET2-3	SET2-4	Current	Factory setting
OFF	OFF	Full	◆
ON	OFF	16.0 A	
OFF	ON	12.0 A	

14. Check and test

14-1. Check run

- The check run is a function to screen and detect any wiring errors.
- After carrying out the check run, you can use the automatic wiring correction function to correct the wiring.
- Normal operation is possible without using the check run. In this case, use the test run or forced cooling function of the indoor unit to confirm any wiring errors.

OUTDOOR UNIT
AOYG18-24KBTA3

■ Things to confirm before starting the check run

To ensure safety, check that the following work, inspections and operations have been completed.

Check item		Check column
1	Check that all work on the piping connecting the outdoor unit, indoor units has been completed.	
2	Check that all work on the wiring connecting the outdoor unit, indoor units has been completed.	
3	Is there a gas leakage? (At pipe connections [flange connections and brazed areas])	
4	Is the system charged with the specified volume of refrigerant?	
5	Is a breaker installed at the power supply cable of outdoor unit?	
6	Are the wires connected to the terminals without looseness, and in accordance with the specifications?	
7	Is the 3-way valve of the outdoor unit open? (Gas pipe and liquid pipe)	
8	Is the power supply connected for more than 12 hours?	

■ Restrictions applicable when performing the check run

- When the check run starts, all indoor units connected to the outdoor unit will start to run automatically. During the check run, you cannot check the operation of the indoor units separately. After the check run, check the operation of the indoor units separately in normal operation.
- The check run can be used when the temperature is within the operable temperature of the air conditioner.
- In the check run, the air conditioner will automatically switch between cooling and heating depending on the external temperature and internal temperature.
- The check run can be completed in about 30 minutes (cooling) or about 1 hour (heating), but may take more depending on the external and internal temperature conditions etc.
- Do not conduct the check run with all the windows in the room closed. Otherwise the room temperature could get too low or too high.
- Depending on the difference of the room temperature of each room, a judgment may be impossible.
- Check run is a special operation so there may be a noise louder than the normal refrigerant noise or a creaking noise.


■ Operating procedure for check run

⚠ CAUTION

Initiate check run after more than 12 hours after the power supply is connected.


NOTE: Be sure that the indoor unit and outdoor unit are not operating before starting the check run.

1. Press the CHECK switch for 3 seconds or more.



2. The number of indoor units (and the places) connected through the communication lines is displayed.
 - If the displayed number of units (places) and the installed number of units (places) is the same, proceed to step 3.
 - If the displayed number of units (places) and the installed number of units (places) is not the same, shut off the power and check whether the indoor and outdoor communication lines are properly connected.
 - If there is no operation for 1 minute, the LED will return to the original display. (POWER/MODE LED: ON)


Example: When 4 indoor units (A to D) are connected



3. Press the CHECK switch for 3 seconds or more again. Check run is initiated.
 - When check run is initiated, all LEDs from A to F will flash. (Preliminary operation)
 - The LED for each indoor unit will switch off in order as check for each unit is completed.

NOTE: To interrupt the check run, press the CHECK switch.


Example: When 4 indoor units (A to D) are connected



4. After the check run is completed, results will be displayed. Fill the displayed results in the result table accordingly.


- If the connection is correct (Example: When 4 indoor units are connected)**

After the number of connected units are displayed, the LED for each unit will light up in order from A to D.



- If the connection is incorrect (Example: When connection of B and C of the 4 units are reversed)**

After the number of connected units are displayed, B and C will light up in reverse.



NOTES:

- Automatic wiring correction will not be completed if the power supply is disconnected while displaying the results. To confirm the automatic wiring correction, be sure to carry out step 5.
- If frost is formed on the outdoor unit while displaying the results, automatic defrost function will be operated. Proceed to step 5 after the defrost function is finished.


[How to record the contents]

- Fill the displayed results according to the following example.

Example: When piping A to D is connected but the wires for B and C are connected in reverse.

<Displayed results>

The LEDs will light up in 7 second intervals in the following order.



<Example of result table>

- Write a ● where the LEDs light up in the order that they light up.

	A	B	C	D	E	F
1	●	●	●	●	○	○
2	●	○	○	○	○	○
3	○	○	●	○	○	○
4	○	●	○	○	○	○
5	○	○	○	●	○	○
6	○	○	○	○	○	○
7	○	○	○	○	○	○

- Based on the results of step (a), record as follows.

- Trace the dotted circle with a pen if multiple places light up.

A	B	C	D	E	F
○	○	○	○	○	○

- Write the order from A to D in which the LEDs lit up inside the circle.

A	B	C	D	E	F
(A)	(C)	(B)	(D)	()	()

c. Select the correction method.



Correct the wiring manually.*2
Proceed to step 6.

Use the Automatic wiring correction function.*1
Proceed to step 5.

Write down the same results in the label on the reverse side of the service panel.
The results recorded are needed at the time of servicing.


<Result Table>

	A	B	C	D	E	F
1	○	○	○	○	○	○
2	○	○	○	○	○	○
3	○	○	○	○	○	○
4	○	○	○	○	○	○
5	○	○	○	○	○	○
6	○	○	○	○	○	○
7	○	○	○	○	○	○

A	B	C	D	E	F
○	○	○	○	○	○

NOTES:

- *1: By using this function, the wiring is automatically corrected according to the piping.
 - *2: When correcting the wiring manually, please disconnect the power supply or turn off the breaker during results display, and then change the wiring manually according to the obtained test results.
- For example, in Example 1, the wirings connected to the terminals B and C is to be exchanged manually.
5. During results display, press the CHECK switch for 3 seconds or more.
After LEDs A to F have lit in turn, all LEDs will light up indicating that the automatic wiring correction is completed.



6. Disconnect the power supply or turn off the breaker and wait 10 minutes then turn the power back on and perform test run.

NOTE: If you do not disconnect the power supply or turn off the breaker, normal operation is not possible.


Notices:

- If an error occurs during check run it will be suspended. Correct the error and start check run again.
- After the check run, if automatic wiring correction is carried out, the indoor unit's position will be modified to match the piping. (Note that the display of the optional remote controller changes.)
- If you start check run again after the automatic wiring correction is finished, the modification will be reset.


■ Failure indication of check-run judgment

The check run stops when there is an error, and the LED shows the relevant error indication. When you encounter the errors described here, perform checking by using the cooling test run of the indoor unit.

- Temperature out of range judgment



- Wiring/piping number difference



■ Redisplaying the results of check run

- When checking the content of automatic wiring correction, push the CHECK switch. The results of the check run is displayed. You can compare the result that is recorded in step (4) of "Chapter 14-1-3. [Operating procedure for check run](#)" on page 352".
- If the automatic wiring correction is not completed, the POWER/MODE LED blinks twice and the MONITOR LED turns off.

■ Memory resetting of automatic wiring correction

⚠ CAUTION

When relocating the unit, reset the memory beforehand, or the unit may not function normally.

1. Push the CHECK switch.
The LED lights as shown in "[Redisplaying the results of check run](#)" on page 356".
2. When the LED is on, press the CHECK switch for more than 3 seconds.
3. The LEDs from A to F light in sequence, and then all LEDs light to indicate the completion of the memory resetting of automatic wiring correction.
4. Disconnect the power supply or turn off the breaker.

14-2. Test run

⚠ CAUTION


Always connect the power supply 12 hours prior to the start of the operation in order to protect the compressor.

1. Indoor unit
 - a. Is the drain normal?
 - b. Is there any abnormal noise and vibration during operation?
2. Outdoor unit
 - a. Is there any abnormal noise and vibration during operation?
 - b. Will noise, wind, or drain water from the unit disturb the neighbors?
 - c. Is there any gas leakage?
 - Do not operate the air conditioner in the test running state for a long time.
 - For the operation method of the test run for indoor unit and central remote controller, refer to the operating manual and perform operation check.


■ Test run method

Be sure to temporarily disconnect the power supply or turn off the breaker before changing the DIP switch settings.

1. Check the 3-way valves (both at the liquid side and gas side) are opened. Confirm that the DIP switch SET1-2 is switched off.
2. Set the operation mode to COOL or HEAT. When switching the DIP switch SET1-1 between HEAT and COOL, disconnect the power supply or turn off the circuit breaker beforehand.



- In the first test run, be sure to set the operation mode to COOL.
 - The operation mode cannot be switched between COOL and HEAT during the test run. To switch the operation mode between COOL and HEAT, stop the test run, switch the operation mode, and then start the test run again.
3. Push TEST RUN switch for more than 3 seconds. The POWER / MODE LED flashes once.



4. Confirm operating status.

5. Push TEST RUN switch for more than 3 seconds.




POWER/MODE LED will turn on, and test run stops.

14-3. Error code

If an error occurs, the LED lights to inform the relevant location and the code.


When error occurs, the error LED blinks at high speed.



■ Error location

LEDs A to F of MONITOR light and indicate the location of the error. In the case of an overall error, LEDs A to F of MONITOR do not light.


Example: Coil error on indoor unit B



■ Error code display

While the error is occurring, briefly push the SW1. The error code is displayed.

Example: Coil error (Error cord = 9A.1)



Error code	Error type
11.3	Serial communication error
11.4	Serial communication error during operation
16.5	Communication error between controller and outdoor unit
22.1	Indoor unit capacity error
23.1	Connection prohibited (Series error)
5U.1	Indoor unit error
62.1	PCB model information error
62.3	EEPROM access error
62.8	EEPROM data corruption error
63.1	Inverter error
65.3	IPM error (Trip terminal L error)
71.1	Discharge temp. sensor error
72.1	Compressor temp. sensor error
73.2	Heat exchanger middle temp. sensor error
73.3	Heat exchanger liquid temp. sensor error
74.1	Outdoor temp. sensor error
75.1	Suction gas temp. sensor error
76.1	Valve sensor error
76.2	
77.1	Heat sink temp. sensor error
84.1	Current sensor 1 error (stoppage permanently)
86.1	Discharge pressure sensor error
86.4	High pressure switch 1 error
94.1	Trip detection
95.1	Compressor motor control error (stoppage permanently)
97.3	Fan motor 1 error (Duty error)
98.3	Fan motor 2 error (Duty error)
99.1	4-way valve error
9A.1	Coil 1 (expansion valve 1) error
A1.1	Discharge temperature 1 error (stoppage permanently)
A3.1	Compressor 1 temperature error

14-4. Pump down


⚠ WARNING

During the pump down operation, make sure that compressor is off before you remove the refrigerant piping. Do not remove the connection pipe while the compressor is in operation with valve open. This may cause abnormal pressure in the refrigeration cycle that leads to breakage and even injury.


■ Pump down operation

When moving or discarding the air conditioner, in order to consider the environment and avoid the discharge of refrigerant to the atmosphere, pump down according to the following procedure.


1. Connect the pressure gauge to the charging port.
2. Change the DIP switch on the board (SET1-2) to ON.
*Be sure the power supply is disconnected on the breaker is turned off when changing the DIP switch.



3. To start operation, push the PUMP DOWN switch (SW1) for 3 seconds or push the switch after the power has been on for 3 minutes.




During pump down, the LED (POWER/MODE) blinks 3 times consecutively.




NOTE: If the PUMP DOWN switch (SW1) is pushed while the compressor is in operation, the compressor stops and the operation restart after about 3 minutes.

4. Close the liquid pipe valve.
5. When the value between 7.3 psi and 0 psi (0.05 Mpa to 0 Mpa) is shown, close the gas pipe valve.
6. Stop the pump down operation by pushing the PUMP DOWN switch (SW1) for 3 seconds. The LED light as follows.



7. Disconnect the power supply or turn off the breaker.

NOTE: • Even if the pump down operation is not stopped by pushing the switch as in step 6, the operation stops automatically after 15 minutes, and the LED light as follows.



- After completing the pump down operation, disconnect the power supply or turn off the breaker.
- If the pump down operation still continues, open the liquid pipe valve. Then perform the procedure again starting from step 3.
- To cancel the pump down operation, push the PUMP DOWN switch (SW1) again. The indication of the LED returns to the original state which is before starting the pump down operation.
(POWER/MODE LED: On)
- The pump down may stop before completion due to an error. To complete the pump down operation, correct the error, open the liquid pipe valve and then start from step 1 again. Otherwise, the refrigerant can be recovered from the service port.

15. Accessories

15-1. Model: AOYG18KBTA3

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Installation manual		1	Drain pipe		1

15-2. Model: AOYG24KBTA3

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Installation manual		1	Drain pipe		1
Adapter K: mm (in) 12.70 (1/2) to 9.52 (3/8)		1			

16. Outdoor unit installation precautions

NOTE: The information listed below are general precautions.

Some models also include items that do not apply.

16-1. Places where prohibited for use

- Places where there is a danger of combustible gas leakage.
- Places where sulfur gas, chlorine gas, acid, alkali, or other matter which effects equipment is generated.
- Places affected by heat radiation from other heat sources.
- Places where the air is stagnant.
- Places where machinery which generates high frequencies is used.
- Ocean beaches and other areas where there is a lot of salt.
- Inside of vehicles, ships, and other conveyances.
- Places where voltage fluctuations are large such as a factory.

16-2. Points to remember when installing

- The product shall be installed at a place which can withstand the weight and vibration of the outdoor unit.
- To allow maintenance after refrigerant piping, drain piping, and electric wiring connection and installation, provide an installation service space.
*Installation service space is shown in "[Installation space](#)" on page 283.
- Be careful when installing the set at the following places.

Condition	Contents	Countermeasures (Reference)
When installed near adjacent houses.	Perform installation work so that operating sound does not disturb the neighbors.	<ol style="list-style-type: none"> Install a soundproof barrier. Change the installation site.
When there is the possibility of strong wind.	<ul style="list-style-type: none"> If the outdoor unit is exposed to strong wind, capacity may drop, frost may form during heating, and operation may be stopped by high pressure rise. In addition, when a very strong wind blows, the fan may be damaged. When a very strong wind blows, there is the possibility of the outdoor unit being toppled over if held only by foundation bolts. 	<ol style="list-style-type: none"> Install the outdoor unit with keeping a sufficient distance between the outlet side of the unit and a facing wall or fence. Make the outlet direction and wind direction perpendicular. Fasten the outdoor unit using toppling prevention hardware (purchased locally).
When snow accumulates.	If the outdoor unit is covered by accumulated snow, it may not be able to operate.	<ol style="list-style-type: none"> Make the foundation as high as possible. Perform snow prevention work.
When installing the inverter type.	It may generate noise in TV sets, stereos and PCs.	The inverter type should be installed at a sufficient distance from these equipments.